



"Leader of Tomorrow"

ADNAN TEXTILE MILLS

L-20 C, Block 22, Federal B Industrial Area,

Karachi 75950, Pakistan.

Ph; 92 21 36821414

Fax; 92 21 36821118


SASME

Home Collections of Luxurious Terry Linen Bath Sheet



Available in 10 Colours;


Silver



Duck Egg



White



Blush



Cappuccino



Lavender



Dolphin Blue



Bordeaux



Royal



Anthracite



Terry Towel (Dimensions)

Bath Sheet;	80 x 140 cm	500 gr/m2
Bath Sheet;	90 x 150 cm	500 gr/m2
Bath Sheet;	80 x 200 cm	500 gr/m2
Bath Sheet;	100 x 150 cm	500 gr/m2
Bath Sheet;	100 x 170 cm	700 gr/m2

Composition:

100% Combed Cotton

Dyeing Process:

Reactive Dyed / Piece Dyed @ 60°C

Origin;

Pakistan

Instructions;

- To make sure that your towels stay fresh, you need to wash and dry them properly.
- Wash towels separately from all other items of clothing.
- Use warm water to wash towels in order to avoid color bleeding.
- Always use a mild detergent when washing towels.
- Always use a mild detergent when washing towels.
- Do not use fabric softeners as they decrease the life and fluffiness of your towel.
- Do not use bleach at any stage of washing and drying.
- Before drying your towels, toss them lightly to make the surface of towels stay fluffy.
- If you are using a dryer, should remove towels from dryer when they are 95%-97% dry.
- Hang them up afterward in an area with good air flow.
- Dry towels immediately after washing. Longer wait will grow more mildew on towels.
- It is best to dry your towels in direct sunlight. Do not use an iron on these towels.