



Inkjet Chip Catalogue

November, 2024

for Epson IX Series Inkjet Cartridge

Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-503BK/503C/503M/503Y	503BK/503C/503M/503Y	EUR	Epson WorkForce WF-2960DWF/WF-2965DWF	
AJE-503XLBK/503XLC/503XLM/503XLY	503XLBK/503XLC/503XLM/503XLY		Epson XP-5200/XP-5205 (N)	
AJE-503XLBK/503XLC/503XLM/503XLY	503XLBK/503XLC/503XLM/503XLY	AUS	Epson WorkForce WF-2960	
AJE-604BK/604C/604M/604Y	604BK/604C/604M/604Y	EUR	Epson WorkForce WF-2910DWF/WF-2930DWF/WF-2935DWF/WF-2950DWF	
AJE-604XLBK/604XLC/604XLM/604XLY	604XLBK/604XLC/604XLM/604XLY		Epson XP-2200/XP-2205/XP-3200/XP-3205/XP-4200/XP-4205 (N)	
AJE-604XLBK/604XLC/604XLM/604XLY	604XLBK/604XLC/604XLM/604XLY	AUS	Epson WorkForce WF-2910/WF-2930/WF-2950	
AJE-49XLBK/49XLC/49XLM/49XLY	49XLBK/49XLC/49XLM/49XLY		Epson Expression Home XP-4205/ XP-2205	
AJE-222XLBK/222BK/222C/222M/222Y	222XLBK/222BK/222C/222M/222Y	NA	Epson XP-5200	
AJE-232XLBK/232BK/232C/232M/232Y	232XLBK/232BK/232C/232M/232Y		Epson XP-4200/4205	
AJE-T10Y1	T10Y1		Epson WorkForce Pro WF-C5890/WF-C5390 (U)	
AJE-T10W1/T10W2/T10W3/T10W4	T10W1/T10W2/T10W3/T10W4			
AJE-T10S1/T10S2/T10S3/T10S4	T10S1/T10S2/T10S3/T10S4	AUS	Epson WorkForce Pro WF-C5890/WF-C5390 (N)	
AJE-T10Y1	T10Y1			
AJE-T10W1/T10W2/T10W3/T10W4	T10W1/T10W2/T10W3/T10W4	HK	Epson XP-2200/XP-4200	
AJE-T10S1/T10S2/T10S3/T10S4	T10S1/T10S2/T10S3/T10S4			
AJE-T10JBK/T10JC/T10JM/T10JY (HK)	T10JBK/T10JC/T10JM/T10JY	KOR	Epson XP-2200/XP-2205	
AJE-T10JBK/T10JC/T10JM/T10JY (KOR)	T10JBK/T10JC/T10JM/T10JY	TW	Epson XP-2200	
AJE-T10JBK/T10JC/T10JM/T10JY (U)	T10JBK/T10JC/T10JM/T10JY	JPN	Epson PX-S887/PX-M887F	
AJE-IP11KA/IP11CA/IP11MA/IP11YA	IP11KA/IP11CA/IP11MA/IP11YA			
AJE-IP11KB/IP11CB/IP11MB/IP11YB	IP11KB/IP11CB/IP11MB/IP11YB	EUR	Epson WorkForce Pro WF-C5890DWF/WF-C5390DWF	
AJE-T11E1	T11E1			
AJE-T11D1/T11D2/T11D3/T11D4	T11D1/T11D2/T11D3/T11D4	HK/CHN	Epson WorkForce Pro WF-C5890/WF-C5390 Epson WorkForce Pro WF-C5890a	
AJE-T11C1/T11C2/T11C3/T11C4	T11C1/T11C2/T11C3/T11C4			
AJE-T09S1/T09S2/T09S3/T09S4/T09U1	T09S1/T09S2/T09S3/T09S4/T09U1	LA	Epson-Pro WorkForce WF-C5310/WF-C5390/WF-C5810/WF-C5890	
AJE-T11H1	T11H1	JPN	Epson PX-M382F/PX-S382 Epson PX-M382F/PX-S382/PX-S383L Epson PX-S383L	
AJE-T11G1/T11G2/T11G3/T11G4	T11G1/T11G2/T11G3/T11G4			
AJE-T11F1/T11F2/T11F3/T11F4	T11F1/T11F2/T11F3/T11F4	NA	Epson WorkForce Pro WF-M5899/WF-M5399	
AJE-T11B1/T11A1/T11A2/T11A3/T11A4	T11B1/T11A1/T11A2/T11A3/T11A4			
AJE-IP12KA	IP12KA	EUR	Epson WorkForce Pro WF-M5899/WF-M5399	
AJE-IP12KB	IP12KB			
AJE-IP13KA	IP13KA	JPN	Epson WorkForce Pro WF-M4119DW/WF-M4619DWF	
AJE-T12G1	T12G1			
AJE-T12H1	T12H1	CHN	Epson WF-M5899a/M5399a	
AJE-T12J1	T12J1			
AJE-T12D1	T12D1	NA	Epson WorkForce Pro WF-M4119DW/WF-M4619DWF	
AJE-T12E1	T12E1			
AJE-T12F1	T12F1	JPN	EPSON EP-887AW/AB/AP	
AJE-T11J1	T11J1			
AJE-MEDBK/MEDC/MEDM/MEDY	MEDBK/MEDC/MEDM/MEDY	JPN	EPSON EP-717A/EP-817A	
AJE-T11V1	T11V1			
AJE-T11W1	T11W1	JPN	EPSON EP-887AW/AB/AP	
AJE-T11Y1	T11Y1			
AJE-T11J1	T11J1	JPN	EPSON EP-717A/EP-817A	
AJE-KNIBKL/KNICL/KNIML/KNIYL/KNILCL/KNILML	KNIBKL/KNICL/KNIML/KNIYL/KNILCL/KNILML			
AJE-KNIBK/KNIC/KNIM/KNIY/KNILC/KNILM	KNIBK/KNIC/KNIM/KNIY/KNILC/KNILM	JPN	EPSON EP-717A/EP-817A	
AJE-KAKBK/KAKC/KAKM/KAKY/KAKLC/KAKLM	KAKBK/KAKC/KAKM/KAKY/KAKLC/KAKLM			

for Epson VIII Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-T08N1/T08N2/T08N3/T08N4	T08N1/T08N2/T08N3/T08N4	EUR	Epson AM-C400/AM-C550	
AJE-T08Q1/T08Q2/T08Q3/T08Q4	T08Q1/T08Q2/T08Q3/T08Q4	EUR	Epson AM-C550	
AJE-T44U1/T44U2/T44U3/T44U4/T44U5/ T44U6/T44U7/T44U8/T44U9/T44UA/T44UB/T44UD	T44U1/T44U2/T44U3/T44U4/T44U5/T44U6/ T44U7/T44U8/T44U9/T44UA/T44UB/T44UD	KOR	Epson SC-P7540/SC-P9540	
AJE-T44J1/T44J2/T44J3/T44J4/T44J5/ T44J6/T44J7/T44J8/T44J9/T44JA/T44JB/T44JD	T44J1/T44J2/T44J3/T44J4/T44J5/T44J6/T44J7/T44J8/T44J9/T44JA/T44JB/T44JD	EUR	Epson SureColor SC-P7500/SureColor SC-P9500	
AJE-SJIC37PK/SJIC37PC/SJIC37PM/SJIC37PY/SJIC37PMK	SJIC37PK/SJIC37PC/SJIC37PM/SJIC37PY/SJIC37PMK	JPN	Epson CW-C6020A/C6020AG/C6020P/C6020PG/C6520A/C6520AG/C6520P/C6520PG	
AJE-T912XLBK/T912XLC/T912XLM/T912XLY	T912XLBK/T912XLC/T912XLM/T912XLY	NA	Epson WorkForce Pro WF-C8190/WF-C8690	
AJE-SC26BK70/SC26C70/SC26M70/SC26Y70/SC26GY70/SC26MB70	SC26BK70/SC26C70/SC26M70/SC26Y70/SC26GY70/SC26MB70	JPN	Epson SC-P6550D/SC-P6550DE/SC-P6550E/SC-P8550D/SC-P8550DM	
AJE-SC27BK70/SC27C70/SC27M70/SC27Y70/SC27R70/SC27MB70	SC27BK70/SC27C70/SC27M70/SC27Y70/SC27R70/SC27MB70		Epson SC-T3750D/SC-T3750DE/SC-T3750E/SC-T5750D/SC-T5750DM/SC-T7750D/SC-T7750DM	
AJE-SJIC38PBK/SJIC38PC/SJIC38PM/SJIC38PY	SJIC38PBK/SJIC38PC/SJIC38PM/SJIC38PY	HK/CHN	Epson CW-C6030/C6530	
AJE-SJIC38PBKR/SJIC38PCR/SJIC38PMR/SJIC38PYR	SJIC38PBKR/SJIC38PCR/SJIC38PMR/SJIC38PYR			
AJE-C9371	C9371	EUR/CHN	Epson AM-C4000a/AM-C5000a/AM-C6000a Epson WorkForce Enterprise AM-C4000/AM-C5000/AM-C6000	
AJE-SJIC45PBK/SJIC45PC/SJIC45PM/SJIC45PY/SJIC45PMK	SJIC45PBK/SJIC45PC/SJIC45PM/SJIC45PY/SJIC45PMK	KOR	Epson CW-C4040	
AJE-SC26MB	SC26MB	JPN	Epson SC-P6550D/SC-P6550DE/SC-P6550E/SC-P8550D/SC-P8550DM/SC-T3750D/SC-T3750DE/	
AJE-SJIC44PBK/SJIC44PC/SJIC44PM/SJIC44PY	SJIC44PBK/SJIC44PC/SJIC44PM/SJIC44PY	CHN	Epson CW-C4030	
AJE-T08D1/T08D2/T08D3/T08D4	T08D1/T08D2/T08D3/T08D4		Epson AM-C4000a	
AJE-T08C1/T08C2/T08C3/T08C4	T08C1/T08C2/T08C3/T08C4		Epson AM-C5000a/AM-C6000a	
AJE-T08H1/T08H2/T08H3/T08H4	T08H1/T08H2/T08H3/T08H4	EUR	Epson WorkForce Enterprise AM-C4000	
AJE-T08G1/T08G2/T08G3/T08G4	T08G1/T08G2/T08G3/T08G4		Epson WorkForce Enterprise AM-C5000/AM-C6000	
AJE-T47A1/T47A2/T47A3/T47A4/T47A5/T47A6/T47A7/T47A8/T47A9/T47AD	T47A1/T47A2/T47A3/T47A4/T47A5/T47A6/T47A7/T47A8/T47A9/T47AD		Epson SureColor SC-P900	
AJE-T46MBK/T46MC/T46MM/T46MY/T46MLC/T46MLM	T46MBK/T46MC/T46MM/T46MY/T46MLC/T46MLM	CHN	Epson SureLab D1080	
AJE-T04ABK/T04AC/T04AM/T04AY	T04ABK/T04AC/T04AM/T04AY	EUR	Epson WorkForce Pro WF-C8190/WF-C8190DTWC/WF-C8690D3TWFC/WF-C8690DWF/WF-C8190D3TWC/WF-C8190DW/WF-C8690DTWF/WF-C8190DTW/WF-C8690/WF-C8690DTWFC	
AJE-603BK/603C/603M/603Y	603BK/603C/603M/603Y		Epson Expression Home XP-2100,/XP-2105/XP-2150/XP-2155/XP-3100/XP-3105/XP-3150/XP-3155/XP-4100/XP-4105/XP-4150/XP-4155 Epson Workforce WF-2810DWF/WF-2820DWF/WF-2830DWF/WF-2840DWF/WF-2835DWF/WF-2845DWF/WF-2850DWF/WF-2870DWF	
AJE-603XLBK/603XLC/603XLM/603XLY	T03A1(603XLBK)/T03A2(603XLC)/T03A3(603XLM)/T03A4(603XLY)		Epson Expression Home XP-5100/XP-5105 Epson WorkForce WF-2860DWF/WF-2865DWF	
AJE-502BK/502C/502M/502Y	502BK/502C/502M/502Y		Epson WF-7830DTWF/7835DTWF/7840DTWF	
AJE-502XLBK/502XLC/502XLM/502XLY	T02W1(502XLBK)/T02W2(502XLC)/T02W3(502XLM)/T02W4(502XLY)		Epson WF-3820DWF/WF-3825DWF/WF-4820DWF/WF-4825DWF/WF-4830DTWF/ WF-7830DTWF/WF-7835DTWF/WF-7840DTWF	
AJE-405XXLBK/405XLC/405XLM/405XLY	405XXLBK/405XLC/405XLM/405XLY		Epson WF-4830DTWF/WF-4820DWF/WF-3820DWF/WF-7830DTWF/ WF-7835DTWF/WF-7840DTWF	
AJE-405BK/405C/405M/405Y	405BK/405C/405M/405Y		Epson Expression Home XP-5100 Epson WorkForce WF-2860	
AJE-405XLBK/405XLC/405XLM/405XLY	405XLBK/405XLC/405XLM/405XLY		Epson WF-7840/WF-7845/WF-7830/WF-7840/WF-7820/EC-C7000 Epson WF-3820/WF-3825/WF-4830/WF-4835/WF-7840/WF-7820/EC-C7000 Epson WF-3820/WF-4820/WF-4830/WF-4834	
AJE-NA202XLBK/NA202XLC/NA202XLM/NA202XLY	T202XL1(T02P1)/T202XL2(T02P2)/T202XL3(T02P3)/T202XL4(T02P4)	NA/AUS	Epson EW-052A/EW-452A	
AJE-812XLBK/812XLC/812XLM/812XLY	812XLBK/812XLC/812XLM/812XLY		Epson PX-S5010	
AJE-812XLBK/812XLC/812XLM/812XLY	812XLBK/812XLC/812XLM/812XLY		Epson PX-M730F	
AJE-822XLBK/822XLC/822XLM/822XLY	822XLBK/822XLC/822XLM/822XLY	JPN	Epson EW-M530F	
AJE-MUGBK/MUGC/MUGM/MUGY	MUGBK/MUGC/MUGM/MUGY		Epson Expression Home XP-2101/XP-4101 Epson WorkForce WF-2831/WF-2851	
AJE-IB06KA*2/IB06CA/IB06MA/IB06YA	IB06KA*2/IB06CA/IB06MA/IB06YA		Epson WorkForce WF-7841	
AJE-IB07KA/IB07CA/IB07MA/IB07YA	IB07KA/IB07CA/IB07MA/IB07YA		Epson WorkForce WF-4838	
AJE-IB07KB/IB07CB/IB07MB/IB07YB	IB07KB/IB07CB/IB07MB/IB07YB	CHN	Epson WorkForce WF-7848/WF-7318	
AJE-IB09KB/IB09CB/IB09MB/IB09YB	IB09KB/IB09CB/IB09MB/IB09YB		Epson WorkForce Pro WF-C878R Epson WorkForce Pro WF-C879R	
AJE-IB10KA/IB10CA/IB10MA/IB10YA	IB10KA/IB10CA/IB10MA/IB10YA	AUS		
AJE-04EBK/04EC/04EM/04EY	T04E1/T04E2/T04E3/T04E4	HK/KOR	Epson Expression Home XP-2101/XP-4101 Epson WorkForce WF-2831/WF-2851	
AJE-T05NBK/T05NC/T05NM/T05NY	T05NBK/T05NC/T05NM/T05NY	HK	Epson WorkForce WF-7841	
AJE-T05UBK/T05UC/T05UM/T05UY	T05U1/T05U2/T05U3/T05U4	CHN	Epson WorkForce WF-4838	
AJE-T05NBK/T05UC/T05UM/T05UY	T05NBK/T05UC/T05UM/T05UY		Epson WorkForce WF-7848/WF-7318	
AJE-T05ABK/T05AC/T05AM/T05AY	T05ABK/T05AC/T05AM/T05AY	AUS	Epson WorkForce Pro WF-C878R Epson WorkForce Pro WF-C879R	

AJE-03CBK/03CC/03CM/03CY	T03C1/T03C2/T03C3/T03C4	HK/KOR	Epson WorkForce WF-2861
AJE-03DBK/03CC/03CM/03CY	T03D1/T03C2/T03C3/T03C4		
AJE-206BK/206C/206M/206Y	T2061/T2062/T2063/T2064	LA	Epson Expression XP-2101
AJE-39XLBK/39XLC/39XLM/39XLY	T04L1(39XLBK)/T04L2(39XLC)/T04L3(39XLM)/T04L4(39XLY)	AUS	Epson Expression Home XP-2105/XP-4105
AJE-212XLBK/212XLC/212XLM/212XLY	T02X1(212XLBK)/T02X2(212XLC)/T02X3(212XLM)/T02X4(212XLY)	NA/AUS	Epson Expression Home XP-2100/XP-3100/XP-3105/XP-4100 Epson WorkForce WF-2810/WF-2830/WF-2850
AJE-T04CBK/T04CC/T04CM/T04CY	T04C1/T04C2/T04C3/T04C4	EUR	Epson WorkForce Pro WF-C8190/WF-C8690/WF-C8610 Epson WorkForce Pro WF-C8190/WF-C8690 Epson SureLab SL-D800
AJE-04BBK/04BC/04BM/04BY	T04B1/T04B2/T04B3/T04B4		
AJE-04ABK/04AC/04AM/04AY	T04A1/T04A2/T04A3/T04A4		
AJE-43UBK/43UC/43UM/43UY/43ULC/43ULM	T43U1/T43U2/T43U3/T43U4/T43U5/T43U6		
AJE-43WBK/43WC/43WM/43WY/43WLC/43WLM	T43W1/T43W2/T43W3/T43W4/T43W5/T43W6	CHN	Epson SureLab SL-D880
AJE-IB02KA/IB02CA/IB02MA/IB02YA	IB02KA/IB02CA/IB02MA/IB02YA	JPN	Epson PX-S7110 Epson PX-M7110F
AJE-IB02KB/IB02CB/IB02MB/IB02YB	IB02KB/IB02CB/IB02MB/IB02YB		
AJE-01BBK/01BC/01BM/01BY	T01B1/T01B2/T01B3/T01B4	CHN	Epson WF-C8190a/WF-C8690a
AJE-T46SY/T46SV	T46SY/T46SV	EUR	Epson SureColor SC-P700
AJE-T46H2/T46H3/T46H4/T46H8	T46H2/T46H3/T46H4/T46H8	AP	Epson SC-F6330
AJE-T924XLBK/T924XLC/T924XLM/T924XLY	T924XLBK/T924XLC/T924XLM/T924XLY	NA	Epson WorkForce Pro WF-C4810 Color MFP
AJE-SJIC36PBK/SJIC36PC/SJIC36PM/SJIC36PY	SJIC36PBK/SJIC36PC/SJIC36PM/SJIC36PY	EUR	Epson CW-C6000A
AJE-SC18BK70/SC18LGY70/SC18GR70/SC18GY70/SC18C70/SC18LC70/SC18V70/SC18VL70/SC18VLM70/SC18MB70/SC18Y70/SC18OR70/SC18VM70	SC18BK70/SC18LGY70/SC18GR70/SC18GY70/SC18C70/SC18LC70/SC18V70/SC18VL70/SC18VLM70/SC18MB70/SC18Y70/SC18OR70/SC18VM70	JPN	Epson SC-P7550/SC-P7550PS Epson P9550/SC-P9550PS
AJE-408LBK/408LC/408LM/408LY	408LBK/408LC/408LM/408LY	EUR	Epson WorkForce Pro WF-C4810DTWF Epson SC-F6300/F6360 Epson SC-F6380/F9480
AJE-408BK/408C/408M/408Y	408BK/408C/408M/408Y		
AJE-T46DHDK/T46DBK/T46DC/T46DM/T46DY	T46D8/T46D1/T46D2/T46D3/T46D4		
AJE-T46FBK/T46FC/T46FM/T46FY/T46FLC/T46FLM	T46F1/T46F2/T46F3/T46F4/T46F5/T46F6	CHN	
AJE-ICBK96/ICCG96/ICVM96/ICY96/ICLC96/ICVLM96/ICGY96/ICMB96/ICLG96/ICDBL96	ICBK96/ICCG96/ICVM96/ICY96/ICLC96/ICVLM96/ICGY96/ICMB96/ICLG96/ICDBL96	JPN	Epson SC-PX1VL Epson SC-PX1V
AJE-ICBK97/ICCG97/ICVM97/ICY97/ICLC97/ICVLM97/ICGY97/ICMB97/ICLG97/ICDBL97	ICBK97/ICCG97/ICVM97/ICY97/ICLC97/ICVLM97/ICGY97/ICMB97/ICLG97/ICDBL97		

for Epson VII Series Inkjet Cartridge

Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-SC14MB35/SC14C35/SC14M35/SC14Y35	SC14MB35/SC14C35/SC14M35/SC14Y35	JPN	Epson SC-T3050/SC-T3050MS/SC-T3250/SC-T3250MS/SC-T3255/SC-T32MFP/SC-T3MFP2/SC-T5050/SC-T5050MS/SC-T5250/SC-T5250D/SC-T5250MS/SC-T5255/SC-T5255D/SC-T52DMFP/SC-T52MFP2/SC-T5DMFP2/SC-T5MFP2/SC-T7050/SC-T7250/SC-T7250D/SC-T7255/SC-T7255D	
AJE-SC14MB70/SC14C70/SC14M70/SC14Y70	SC14MB70/SC14C70/SC14M70/SC14Y70	JPN	Epson SC-T3455/SC-T3455N/SC-T345MS1/SC-T345MS2/SC-T345MS3/SC-T5455/SC-T545MS1/SC-T545MS2/SC-T545MS3	
AJE-M04XXLBK	M04XXLBK	LA	Epson WorkForce Pro WF-M5799/WF-M5299	
AJE-KUIBK/LKUICL/KUIML/KUIYL/KUILCL/KUILML	KUIBK/LKUICL/KUIML/KUIYL/KUILCL/KUILML	JPN	Epson EP-879AW/AB/AR	
AJE-ICBK84/ICC84/ICM84/ICY84	ICBK84/ICC84/ICM84/ICY84		Epson PX-M780F/PX-M781F	
AJE-ICBK86/ICC86/ICM86/ICY86	ICBK86/ICC86/ICM86/ICY86		Epson PX-M680F	
AJE-SORBK/SORC/SORM/SORY/SORR/SORGY	SORBK/SORC/SORM/SORY/SORR/SORGY		Epson EP-50V	
AJE-KAMBK/KAMC/KAMM/KAMY/KAMLC/KAMLM	KAMBK/KAMC/KAMM/KAMY/KAMLC/KAMLM		Epson EP-881AW/AB/AR/AN	
AJE-KAMBK/LKAMCL/KAMML/KAMYL/KAMLCL/KAMLML	KAMBK/LKAMCL/KAMML/KAMYL/KAMLCL/KAMLML		Epson EP-882AW/AB/AR Epson EP-884AW/AB/AR	
AJE-34BK/34C/34M/34Y	T3461(34BK)/T3462(34C)/T3463(34M)/T3464 (34Y)	EUR	Epson WorkForce Pro WF-3725DWF/3720DWF Epson WorkForce Pro WF-4740DTWF/4720DW/4725DW	
AJE-34XLBK/34XLC/34XLM/34XLY	T3471(34XLBK)/T3472(34XLC)/T3473(34XLM)/T3474 (34XLY)			
AJE-35BK/35C/35M/35Y	T3581(35BK)/T3582(35C)/T3583(35M)/T3584 (35Y)			
AJE-35XLBK/35XLC/35XLM/35XLY	T359(35XLBK)1/T3592(35XLC)/T3593(35XLM)/T3594 (35XLY)			
AJE-202BK/202PBK/202C/202M/202Y	202BK(T02E1)/202PBK(T02F1)/202C(T02F2)/202M(T02F3)/202Y(T02F4)	EUR/HK	Epson Expression premium XP-6000/XP-6005/XP-6100/XP-6105	
AJE-202XLBK/202XPBK/202XLC/202XLM/202XLY	T02G1(202XLBK)/T02H1(202XPBK)/T02H2(202XLC)/T02H3(202XLM)/T02H4 (202XLY)			
AJE-378BK/378C/378M/378Y/378LC/378LM	378BK/378C/378M/378Y/378LC/378LM	EUR	Epson Expression Photo XP-8500/8505	
AJE-378XLBK/378XLC/378XLM/378XLY/378XLLC/378XLLM	T3791 (378XLBK)/T3792 (378XLC)/T3793 (378XLM)/T3794 (378XLY)/T3795 (378XLLC)/T3796 (378XLLM)			

AJE-378XLBK/378XLC/378XLM/378XLY/478XLR/478XLG Y	T3791 (378XLBK)/T3792 (378XLC)/T3793 (378XLM)/T3794 (378XLY)/T04F5(478XLR)/T04F6 (478XLG Y)		Epson Expression Photo HD XP-15000
AJE-407BK/407C/407M/407Y	407BK/407C/407M/407Y		Epson WF-4745DTWF
AJE-702XLBK/702XLC/702XLM/702XLY	T702XL1(T3451)/T702XL2(T3452)/T702XL3(T3453)/T702XL4(T3454)	NA/AUS	Epson WorkForce Pro WF-3720
AJE-802BK/802C/802M/802Y	802BK/802C/802M/802Y		Epson WorkForce Pro WF-4720/WF-4730/WF-4740/WF-4734 Epson WorkForce Pro EC-4020/EC-4030/EC-4040
AJE-802XLBK/802XLC/802XLM/802XLY	T802XL1(T3561)/T802XL2(T3562)/T802XL3(T3563)/T802XL4(T3564)		Epson Expression Photo XP-8500
AJE-312XLBK/312XLC/312XLM/312XLY/312XLLC/312XLLM	T312XL1(T1831)/T312XL2(T1832)/T312XL3(T1833)/T312XL4(T1834)/T312XL5 (T1835)/T312XL6 (T1836)		Epson Expression Photo HD XP-15000
AJE-312XLBK/312XLC/312XLM/312XLY/314XLG Y/314XLR	T312XL1(T1831)/T312XL2(T1832)/T312XL3(T1833)/T312XL4(T1834)/T314XL7(T01M 6)/T314XL8(T01M5)		Epson Expression premium XP-6000/XP-6100
AJE-302XLBK/302XPBK/302XLC/302XLM/302XLY	T302XL0(T01X1)/T302XL1(T01Y1)/T302XL2(T01Y2)/T302XL3(T01Y3)/T302XL4(T01Y4)		
AJE-349BK/349C/349M/349Y	T3491/T3492/T3493/T3494	HK	Epson WorkForce Pro WF-3721
AJE-01UBK/01UC/01UM/01UY/01UR/01UG Y	T01U1/T01U2/T01U3/T01U4/T01U5/T01U6	CHN	Epson Expression Photo HD XP-15010/15080
AJE-IP01KA/IP01CA/IP01MA/IP01YA	IP01KA/IP01CA/IP01MA/IP01YA	JPN	Epson PX-S884 Epson PX-M884F
AJE-IP01KB/IP01CB/IP01MB/IP01YB	IP01KB/IP01CB/IP01MB/IP01YB		Epson PX-M380F/PX-S380
AJE-IP03KA	IP03KA		Epson PX-M381FL/PX-S381L
AJE-IP03KB	IP03KB		Epson PX-M886FL
AJE-IP03KB	IP03KB		
AJE-IP04KA	IP04KA		
AJE-IP05KA/IP05CA/IP05MA/IP05YA	IP05KA/IP05CA/IP05MA/IP05YA	EUR	Epson WorkForce Pro WF-C5290/C5790 Epson WorkForce Pro WF-C5210/C5710 Epson WorkForce Pro WF-C5290/C5790 Epson Workforce Pro WF-C529RDTW Epson Workforce Pro WF-C579RDTW
AJE-944BK/944C/944M/944Y	T9441/T9442/T9443/T9444		Epson WorkForce Pro WF-M5299/M5799
AJE-T945BK/T945C/T945M/T945Y	T9451/T9452/T9453/T9454		
AJE-946BK/945C/945M/945Y	T9461/T9452/T9453/T9454		
AJE-01CBK/01CC/01CM/01CY	T01C1/T01C2/T01C3/T01C4		
AJE-01DBK/01DC/01DM/01DY	T01D1/T01D2/T01D3/T01D4		
AJE-964BK	T9641	NA	Epson WorkForce Pro WF-C5290/C5790 Epson WorkForce Pro WF-C5210/C5710 Epson WorkForce Pro WF-C5290/C5790
AJE-965BK	T9651		
AJE-966BK	T9661		
AJE-902XLBK/902XLC/902XLM/902XLY	T902XL1/T902XL2/T902XL3/T902XL4		
AJE-902XXLBK/902XLC/902XLM/902XLY	T902XXL1/T902XL2/T902XL3/T902XL4		
AJE-948BK/948C/948M/948Y	T9481/T9482/T9483/T9484	KOR/HK/ TW	Epson WorkForce Pro WF-C5790 Epson WorkForce Pro WF-C5290
AJE-T949BK/T949C/T949M/T949Y	T9491/T9492/T9493/T9494		
AJE-T950BK/T949C/T949M/T949Y	T9501/T9492/T9493/T9494	CHN	Epson WorkForce Pro WF-C5790a Epson WorkForce Pro WF-C5290a
AJE-948BK/948C/948M/948Y	T9481/T9482/T9483/T9484		
AJE-T949BK/T949C/T949M/T949Y	T9491/T9492/T9493/T9494	KOR/HK	
AJE-T950BK/T949C/T949M/T949Y	T9501/T9492/T9493/T9494		
AJE-968BK	T9681	CHN	Epson WF-M5299/M5799
AJE-969BK	T9691		
AJE-970BK	T9701	CHN	Epson WF-M5299a/M5799a
AJE-968BK	T9681		
AJE-969BK	T9691	AUS	Epson WF-M5299/M5799
AJE-970BK	T9701		Epson WorkForce Pro WF-C5790 Epson WorkForce Pro WF-C5290
AJE-T957	T957		Epson Workforce Pro WF-C529R Epson Workforce Pro WF-C579R
AJE-T958	T958		
AJE-936BK/936C/936M/936Y	T9361/T9362/T9363/T9364		
AJE-937BK/937C/937M/937Y	T9371/T9372/T9373/T9374		
AJE-938BK/937C/937M/937Y	T9381/T9372/T9373/T9374	AP	Epson PictureMate PM-520
AJE-AU01CBK/AU01CC/AU01CM/AU01CY	T01C1/T01C2/T01C3/T01C4		Epson PictureMate PM-525
AJE-AU01DBK/AU01DC/AU01DM/AU01DY	T01D1/T01D2/T01D3/T01D4	CHN	Epson SureColor T3180/T5180 Epson SureColor T3480/T5480
AJE-T372	T372		Epson SureColor T3100/T5100
AJE-T376	T376	EUR	Epson SureColor T3400/T5400
AJE-40HBK/40HC/40HM/40HY	T40H1/T40H2/T40H3/T40H4		
AJE-41KBK/41KC/41KM/41KY	T41K5/T41K2/T41K3/T41K4		
AJE-40DBK/40DC/40DM/40DY	T40D1/T40D2/T40D3/T40D4		
AJE-41FBK/41FC/41FM/41FY	T41F5/T41F2/T41F3/T41F4		



AJE-SC13MBL/SC13CL/SC13ML/SC13YL	SC13MBL/SC13CL/SC13ML/SC13YL	JPN	Epson SureColor T3150/T5150	
AJE-R04XBK/R04LBK/R04LC/R04LM/R04LY	R04XBK(T9421)/R04LBK(T9411)/R04LC(T9412)/R04LM(T9413)/R04LY(T9414)	LA	Epson WorkForce Pro WF-C5210/WF-C5290/WF-C5290/WF-C5710/WF-C5790	
for Epson VI Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-T8000/T8001/T8002/T8003/T8004/T8005/T8006/T8007/T8008/T8009	T8000/T8001/T8002/T8003/T8004/T8005/T8006/T8007/T8008/T8009	NA	Epson SureColor P10000/P20000	
AJE-T320	T320	NA	Epson PictureMate PM-400	
AJE-T8581/T8582/T8583/T8584	T8581/T8582/T8583/T8584	WW(ex.JPN)	Epson WF-C20590	
AJE-T04Q1	T04Q1	CHN	Epson WF-M20590	
AJE-T02Y1/T02Y2/T02Y3/T02Y4	T02Y1/T02Y2/T02Y3/T02Y4	AUS	Epson WorkForce Enterprise WF-C21000	
AJE-SC8LGY70/SC8BK70/SC8C70/SC8VM70/SC8Y70/SC8LC70/SC8VLM70/SC8DGY70/SC8MB70/SC8GY70	SC8LGY70/SC8BK70/SC8C70/SC8VM70/SC8Y70/SC8LC70/SC8VLM70/SC8DGY70/SC8MB70/SC8GY70	JPN	Epson SC-P10050/P1005PS/P20050X/P2005PS	
AJE-SC10M70M/SC10Y70M/SC10LC70M/SC10LM70M/SC10GY70M/SC10OR70M/SC10R70M/SC10BK70M/SC10C70M/SC10CLL	SC10M70M/SC10Y70M/SC10LC70M/SC10LM70M/SC10GY70M/SC10OR70M/SC10R70M/SC10BK70M/SC10C70M/SC10CLL		Epson SC-S40650/S60650/S80650/S80650R	
AJE-T364BK/T364C/T364M/T364Y	T3641/T3642/T3643/T3644	KOR	Epson Expression Home XP-245/442	
AJE-T288XL1/T288XL2/T288XL3/T288XL4	T288XL1/T288XL2/T288XL3/T288XL4	NA/AUS	Epson Expression Home XP-240/XP-330/XP-340/XP-430/XP-434/XP-440/XP-446	
AJE-T410XL0/T410XL1/T410XL2/T410XL3/T410XL4	T410XL0/T410XL1/T410XL2/T410XL3/T410XL4	NA	Epson Expression Premium XP-530/XP-630/XP-540/XP-640/XP-900/XP-830/XP-7100	
AJE-T2971/T2962/T2963/T2964	T2971/T2962/T2963/T2964	LA	Epson XP-231/431	
AJE-T410XL0A/T410XL1A/T410XL2A/T410XL3A/T410XL4A	T3391/T3401/T3402/T3403/T3404	AUS	Epson Expression Premium XP-530/XP-630/XP-540/XP-640/XP-900	
AJE-T2991A/T2992A/T2993A/T2994A	T2991/T2992/T2993/T2994		Epson Expression Home XP-235/ XP-432	
AJE-T2991/T2992/T2993/T2994	T2991/T2992/T2993/T2994	EUR	Epson Expression Home XP-235/XP-245/XP-247/XP-332/XP-335/XP-342/XP-345/XP-432/XP-435/XP-442/XP-445	
AJE-T3331/T3341/T3342/T3343/T3344	T3331/T3341/T3342/T3343/T3344		Epson Expression Premium XP-530/XP-630/XP-830/XP-635/XP-540/XP-640/XP-645/XP-900/XP-7100	
AJE-T3351/T3361/T3362/T3363/T3364	T3351/T3361/T3362/T3363/T3364			
AJE-RDHBKL/RDHBK/RDHC/RDHM/RDHY	RDHBKL/RDHBK/RDHC/RDHM/RDHY	JPN	Epson PX-048A/049A	
AJE-YTHBK/YTHC/YTHM/YTHY/YTHR/YTHGY	YTHBK/YTHC/YTHM/YTHY/YTHR/YTHGY		Epson EP-10VA/30VA	
AJE-T2981/T2982/T2983/T2984	T2981/T2982/T2983/T2984	EUR	Epson XP-235/XP-245/XP-247/XP-255/XP-257/XP-332/XP-335/XP-342/XP-345/XP-352/XP-355/XP-432/XP-435/XP-442/XP-445/XP-452/XP-455	
AJE-T8021/T8022/T8023/T8024/T8025/T8026/T8027/T8028/ T8029/T8020	T8021/T8022/T8023/T8024T8025/T8026/T8027/T8028/T8029/T8020	CHN	Epson SureColor P10080/P20080	
AJE-T8061/T8062/T8063/T8064/T8065/T8066/T8067/T8068/T8069	T8061/T8062/T8063/T8064/T8065/T8066/T8067/T8068/T8069		Epson SureColor P6080	
AJE-T8041/T8042/T8043/T8044/T8045/T8046/T8047/T8048/T8049	T8041/T8042/T8043/T8044/T8045/T8046/T8047/T8048/T8049	NA	Epson SureColor P6000	
AJE-SC9BK70/SC9C70/SC9GR70/SC9GY70/SC9LM70/SC9MB70/SC9OR70/SC9VLM70/SC9VM70/SC9Y70/SC9LGY70	SC9BK70/SC9C70/SC9GR70/SC9GY70/SC9LM70/SC9MB70/SC9OR70/SC9VLM70/SC9VM70/SC9Y70/SC9LGY70	JPN	Epson SureColor P6050	
AJE-T289/T290	T289/T290	CHN	Epson WorkForce WF-100/WF110	
for Epson V Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-SATBK/SATC/SATM/SATY/SATLC/SATLM	SATBK/SATC/SATM/SATY/SATLC/SATLM	JPN	Epson EP-712A/EP-812A	
AJE-ITHBK/ITHC/ITHM/ITHY/ITHLC/ITHLM	ITHBK/ITHC/ITHM/ITHY/ITHLC/ITHLM		Coming soon !	
AJE-ICBK73L	ICBK73L		Epson EP-709A/EP-710A/EP-810AW/EP-810AB	
AJE-ICBK80L/ICC80L/ICM80L/ICY80L/ICLC80L/ICLM80L	ICBK80L/ICC80L/ICM80L/ICY80L/ICLC80L/ICLM80L		Epson PX-BK150	
AJE-ICBK80/ICC80/ICM80/ICY80/ICLC80/ICLM80	ICBK80/ICC80/ICM80/ICY80/ICLC80/ICLM80		Epson EP-707A/EP-777A/EP-807AB/EP-807AR/EP-807AW/EP-907F/EP-977A3/EP-978A3/ EP-808AW/EP-808AB/EP-808AR/EP-979A3/EP-982A3	
AJE-ICBK82/ICCL82	ICBK82/ICCL82		Epson PX-S05W/PX-S05B/PX-S06W/PX-S06B	
AJE-ICCL81	ICCL81		Epson PF-71	
AJE-ICBK78/ICC78/ICM78/ICY78	ICBK78/ICC78/ICM78/ICY78			
AJE-ICBK77/ICC78/ICM78/ICY78	ICBK77/ICC78/ICM78/ICY78		Epson PX-M650/PX-M650A	
AJE-T220XL1/T220XL2/T220XL3/T220XL4	T220XL1/T220XL2/T220XL3/T220XL4	NA	Epson WorkForce WF-2630/WF-2650/WF-2660/WF-2750/WF-2760 Epson Expression Home XP-420/XP-424/XP-320	
AJE-T2941/T2942/T2943/T2944	T2941/T2942/T2943/T2944	AU	Epson WorkForce WF-2630/WF-2650/WF-2660 Epson Expression Home XP-420/XP-424/XP-320	
AJE-T266/AJE-T267	T266/T267	EUR	Epson WorkForce WF-100W	
for Epson IV Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-SJIC26PK/SJIC26PC/SJIC26PM/SJIC26PY	SJIC26PK/SJIC26PC/SJIC26PM/SJIC26PY	EUR	Epson ColorWorks C7500	
AJE-T7101/T7102/T7103/T7104/T7105/T7106	T7101/T7102/T7103/T7104/T7105/T7106	EUR	Epson SureLab D3000	

AJE-T7611/T7612/T7613/T7614/T7615/T7616/T7617/T7618/T7619	T7611/T7612/T7613/T7614/T7615/T7616/T7617/T7618/T7619	CHN	EPSON SC-P608
AJE-SC23MB	SC23MB	JPN	Epson SC-F150
AJE-T8651	T8651	EUR	Epson WorkForce Pro WF-M5690/WF-M5190
AJE-ICBK95L	ICBK95L	JPN	Epson PX-M350F/PX-S350
AJE-ICBK79/ICC79/ICVM79/ICY79/ICLC79/ICGY79/ICLG79/ICMB79/ICVLM79	ICBK79/ICC79/ICVM79/ICY79/ICLC79/ICGY79/ICLG79/ICMB79/ICVLM79		Epson SC-PX5V2
AJE-ICBK88/IC88/ICM88/ICY88/ICBL88/ICGL88/ICMB88/ICR88/ICOR88	ICBK88/IC88/ICM88/ICY88/ICBL88/ICGL88/ICMB88/ICR88/ICOR88		EpsonSC-PX7VII
AJE-ICBK89/ICC89/ICVM89/ICY89/ICGY89/ICLC89/ICLG89/ICMB89/ICVLM89	ICBK89/ICC89/ICVM89/ICY89/ICGY89/ICLC89/ICLG89/ICMB89/ICVLM89		Epson SC-PX3V
AJE-T7601/T7602/T7603/T7604/T7605/T7606/T7607/T7608/T7609	T7601/T7602/T7603/T7604/T7605/T7606/T7607/T7608/T7609	EUR	Epson SureColor SC-P600
AJE-T3240/T3241/T3242/T3243/T3244/T3247/T3248/T3249	T3240/T3241/T3242/T3243/T3244/T3247/T3248/T3249	NA/EUR	Epson SureColor P400
AJE-T9731/T9732/T9733/T9734	T9731/T9732/T9733/T9734	CHN	Epson WF-C869Ra
AJE-T9741/T9742/T9743/T9744	T9741/T9742/T9743/T9744	EUR	Epson WorkForce Pro WF-R5190/WF-R5690
AJE-T8781/T8782/T8783/T8784	T8781/T8782/T8783/T8784		Epson WorkForce Pro WF-6590D2TWFC/6590DTWC/6590DW/6090D2TWFC/6090DTWC/6090DW
AJE-T9071/9072/T9073/T9074	T9071/T9072/T9073/T9074		Epson Expression Home XP-30/XP-102/XP-202/XP-205/XP-302/XP-305/XP-402/XP-405/XP-215/XP-312/XP-415
AJE-T9081/9082/T9083/T9084	T9081/T9082/T9083/T9084		
AJE-T1801/T1802/T1803/T1804	T1801/T1802/T1803/T1804	Russia	Epson WorkForce WF-100W
AJE-T1811/T1812/T1813/T1814	T1811/T1812/T1813/T1814		Epson Expression Home XP-200/XP-300/XP-400/XP-310/XP-410/XP-510
AJE-T215BK/AJE-T215CL	T2151/T2153		Epson WorkForce WF-2520/WF-2530/WF-2540
AJE-T2001/T2002/T2003/T2004	T2001/T2002/T2003/T2004		Epson Expression Home XP-103/XP-203/XP-207/XP-313/XP-413
AJE-T200XL1/T200XL2/T200XL3/T200XL4	T200XL1/T200XL2/T200XL3/T200XL4	NA	Epson Expression Home XP-102/XP-202 (HBK)
AJE-T1701/T1702/T1703/T1704	T1701/T1702/T1703/T1704	EUR	Epson Expression Home XP-102/XP-202 (HBK)
AJE-T1711/T1712/T1713/T1714	T1711/T1712/T1713/T1714		Epson Expression Home XP-102/XP-202/XP-302/XP-402 (HBK)
AJE-T1621/T1622/T1623/T1624	T1621/T1622/T1623/T1624		Epson Expression Home XP-302/XP-402 (HBK)
AJE-T1631/T1632/T1633/T1634	T1631/T1632/T1633/T1634		Epson Expression Home XP-204/XP-211/XP-214/XP-401
AJE-T1901/T1902/T1903/T1904	T1901/T1902/T1903/T1904	AP	Epson PX-535F/PX-045A/PX-405A/PX-435A
AJE-T1911/T1902/T1903/T1904	T1911/T1902/T1903/T1904		Epson PX-S5040/PX-M5040F/PX-M5041F
AJE-T1931/T1932/T1933/T1934	T1931/T1932/T1933/T1934		Epson PX-M741F/PX-M740F/PX-S740
AJE-T1981/T1932/T1933/T1934	T1981/T1932/T1933/T1935		Epson WorkForce WF-M1030/M1560
AJE-1661/1662/1663/1664	T1661/T1662/T1663/T1664	EUR	Epson WorkForce WF-7110 DTW/WF-7610 DWF/WF-7620 DTWF/WF-3620/WF-3640DTWF/WF-7715DWF/WF-7710DWF/WF-7210DTW
AJE-1671/1662/1663/1664	T1671/T1662/T1663/T1664		Epson WorkForce WF-3620/WF-3640/WF-7610/WF-7620/WF-7710/WF-7720/WF-7210 (NA)
AJE-1761/1762/1763/1764	T1761/T1762/T1763/T1764		EpsonWorkForceWF-7610EpsonWorkForceWF-7620
AJE-1771/1772/1773/1774	T1771/T1772/T1773/T1774		Epson WorkForce WF-M1561
AJE-1781/1772/1773/1774	T1781/T1772/T1773/T1774	LA	Epson WF-7621/WF-7111/WF-3641 (CHN)
AJE-T1971/T1962/T1963/T1964	T1971/T1962/T1963/T1964	JPN	Epson Pro WF-8090/8590/8010/8510
AJE-ICBK69/ICC69/ICM69/ICY69	ICBK69/ICC69/ICM69/ICY69		Epson Expression Premium XP-600/XP-605/XP-700/XP-800/XP-610/XP-615/XP-710/XP-810
AJE-ICBK69L/ICC69/ICM69/ICY69	ICBK69L/ICC69/ICM69/ICY69		
AJE-ICBK74/ICC74/ICM74/ICY74	ICBK74/ICC74/ICM74/ICY74		Epson Expression Photo XP-750/XP-850/XP-950/XP-860/XP-55/XP-760/XP-960
AJE-ICBK76/ICC76/ICM76/ICY76	ICBK76/ICC76/ICM76/ICY76	NA	
AJE-ICBK75/ICC75/ICM75/ICY75	ICBK75/ICC75/ICM75/ICY75		
AJE-T2231/T223XL1	T2231/T223XL1		
AJE-T2701/T2702/T2703/T2704	T2701/T2702/T2703/T2704		
AJE-T2711/T2712/T2713/T2714	T2711/T2712/T2713/T2714	EUR	
AJE-T2791/T2712/T2713/T2714	T2791/T2712/T2713/T2714	NA/AU	
AJE-T2521/T2522/T2523/T2524	T2521/T2522/T2523/T2524		
AJE-T252XL1/T252XL2/T252XL3/T252XL4	T252XL1/T252XL2/T252XL3/T252XL4		
AJE-T254XL1	T254XL1		
AJE-T2511	T2511	AUS	
AJE-T1881/T1882/T1883/T1884	T1881/T1882/T1883/T1884	HK	
AJE-T7551/T7552/T7553/T7554	T7551/T7552/T7553/T7554	AP	
AJE-T2601/T2611/T2612/T2613/T2614	T2601/T2611/T2612/T2613/T2614	EUR	
AJE-T2621/T2631/T2632/T2633/T2634	T2621/T2631/T2632/T2633/T2634		
AJE-T2421/T2422/T2423/T2424/T2425/T2426	T2421/T2422/T2423/T2424/T2425/T2426		
AJE-T2431/T2432/T2433/T2434/T2435/T2436	T2431/T2432/T2433/T2434/T2435/T2436		



AJE-T2771/T2772/T2773/T2774/T2775/T2776	T2771/T2772/T2773/T2774/T2775/T2776	NA	Epson Expression Premium XP-850/XP-950/XP-860/XP-960	
AJE-T277XL1/T277XL2/T277XL3/T277XL4/T277XL5/T277XL6	T277XL1/T277XL2/T277XL3/T277XL4/T277XL5/T277XL6			
AJE-T2730/T2731/T2732/T2733/T2734	T2730/T2731/T2732/T2733/T2734		Epson Expression Premium XP-600/XP-800/XP-610/XP-810	
AJE-T273XL0/T273XL1/T273XL2/T273XL3/T273XL4	T273XL0/T273XL1/T273XL2/T273XL3/T273XL4	AP	Epson Expression Premium XP-701 (CHN/HBK)	
AJE-T2551/T2561/T2562/T2563/T2564	T2551/T2561/T2562/T2563/T2564	LA	Epson Expression Premium XP-702/802	
AJE-ICBK70/ICC70/ICM70/ICY70/ICLC70/ICLM70	ICBK70/ICC70/ICM70/ICY70/ICLC70/ICLM70	JPN	Epson EP-905F/EP-775AW/EP-805AW/EP-706A/EP-776A	
AJE-ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70L/ICLM70L	ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70L/ICLM70L			
AJE-ICBK93L/ICC93L/ICM93L/ICY93L	ICBK93L/ICC93L/ICM93L/ICY93L		Epson PX-M7050F/PX-M7050FP/PX-M7050FT	
AJE-ICBK93M/ICC93M/ICM93M/ICY93M	ICBK93M/ICC93M/ICM93M/ICY93M		Epson PX-S7050/PX-S7050PS	
AJE-T6941/T6942/T6943/T6944/T6945	T6941/T6942/T6943/T6944/T6945	NA/EUR	Epson SureColor T3000/T5000/T7000	
AJE-T6931/T6932/T6933/T6934/T6935	T6931/T6932/T6933/T6934/T6935		Epson SureColor T3200/T5200/T7200	
			Epson SureColor T3270/T5270/T7270	
AJE-T7081/T7072/T7073/T7074/T7075	T7081/T7072/T7073/T7074/T7075	CHN	Epson SureColor T3080/T3280/T5280/T7280	
AJE-SC1BK70/SC1C70/SC1M70/SC1Y70/SC1MB70	SC1BK70/SC1C70/SC1M70/SC1Y70/SC1MB70	JPN	Epson SureColor T3050/T3250/T5050/T5250/T7050/T7250	
AJE-T7411/T7412/T7413/T7414	T7411/T7412/T7413/T7414	NA/EUR	Epson SureColor F6000/F6070/F7000/F7100/F7070/F7170/F7200	
AJE-T741X/T7412/T7413/T7414	T741X/T7412/T7413/T7414		Epson SureColor F6000/F6200/F7000/F7100/F7200/F9200/F9300/F9370	
AJE-T7421/T7422/T7423/T7424	T7421/T7422/T7423/T7424			
AJE-T742X/T7422/T7423/T7424	T742X/T7422/T7423/T7424	CHN	Epson SureColor F6080/F7180/F7080	
AJE-T7251/T7252/T7253/T7254/T725A	T7251/T7252/T7253/T7254/T725A		Epson SureColor F9380	
AJE-T7261/T7262/T7263/T7264/T726A	T7261/T7262/T7263/T7264/T726A	NA/EUR	Epson SureColor F2000	
AJE-T6871/T6872/T6873/T6874	T6871/T6872/T6873/T6874	CHN	Epson SureColor F2080	
AJE-T6881/T6882/T6883/T6884	T6881/T6882/T6883/T6884	EUR	Epson SureColor S30600/S50600	
AJE-T6891/T6892/T6893/T6894	T6891/T6892/T6893/T6894		Epson SureColor S30610/S50610	
AJE-T8931/T8932/T8933/T8934/T8935/T8936/T8937/T8938/T8939	T8931/T8932/T8933/T8934/T8935/T8936/T8937/T8938/T8939		NA	Epson SureColor S30670/S50670
AJE-T6193	T6193	CHN	Epson SureColor S40680/S60680/S80680	
AJE-T8391/T8392/T8393/T8394	T8391/T8392/T8393/T8394	/	Epson T3000	
AJE-T7921/T7922/T7923/T7924	T7921/T7922/T7923/T7924	EUR	Epson WorkForce Pro WF-R8590	
AJE-788XXLBK/788XXLC/788XXLM/788XXLY	788XXLBK/788XXLC/788XXLM/788XXLY	TW	Epson WF-5191/5621	
AJE-T786XL1/T786XL2/T786XL3/T786XL4	T786XL1/T786XL2/T786XL3/T786XL4	NA	Epson WorkForce Pro WF-5110/5190/5690/5620	
AJE-ICBK92M/ICC92M/ICM92M/ICY92M	ICBK92M/ICC92M/ICM92M/ICY92M		Epson WorkForce Pro WF-5620/WF-5690/WF-5110/WF-5190 (US)	
AJE-ICBK92L/ICC92L/ICM92L/ICY92L	ICBK92L/ICC92L/ICM92L/ICY92L			
AJE-T7891/T7892/T7893/T7894	T7891/T7892/T7893/T7894	JPN	Epson PX-M840/PX-S840	
AJE-T7901/T7902/T7903/T7904	T7901/T7902/T7903/T7904			
AJE-T7911/T7912/T7913/T7914	T7911/T7912/T7913/T7914			
AJE-T8501/T8502/T8503/T8504/T8505/T8506/T8507/T8508/T8509	T8501/T8502/T8503/T8504/T8505/T8506/T8507/T8508/T8509	EUR	Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/WF-5190DW	
			Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/WF-5190DW	
			Epson WorkForce Pro WF-4640/WF-4630 (EUR)	
AJE-T6997	T6997	/	Epson SureColor P800	
			Epson SureColor P6000/P6080	
for Epson IV Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-KAMBKLR/KAMCLR/KAMMLR/KAMYLRL/KAMLCLR/KAMLMLR	KAMBKLR/KAMCLR/KAMMLR/KAMYLRL/KAMLCLR/KAMLMLR	JPN	Epson 881AW/AB/AR/AN/Epson 882AW/AB/AR	
AJE-T1811R/T1812R/T1813R/T1814R	T1811/T1812/T1813/T1814	EUR	Epson Expression Home XP-30/XP-102/XP-202/XP-205/XP-302/XP-305/XP-402/XP-405	
AJE-T1881R/T1882R/T1883R/T1884R	T1881/T1882/T1883/T1884	AP	Epson WF-7621/WF-7111/WF-3641	
AJE-T2511R	T251BK		Epson WorkForce WF-M1561	
AJE-T252XL1R/T252XL2R/T252XL3R/T252XL4R	T252XL1/T252XL2/T252XL3/T252XL4		Epson WorkForce WF-3620/WF-3640/WF-7610/WF-7620	
AJE-T200XL1R/T200XL2R/T200XL3R/T200XL4R	T200XL1/T200XL2/T200XL3/T200XL4	NA/AU	Epson Expression Home XP-200/XP-300/XP-400	
AJE-T1711R/T1712R/T1713R/T1714R	T1711/T1712/T1713/T1714	NA	Epson WorkForce WF-2520/WF-2530/WF-2540	
AJE-T1621R/T1622R/T1623R/T1624R	T1621/T1622/T1623/T1624	AP	Epson Expression Home XP-103/XP-203/XP-207	
AJE-T1631R/T1632R/T1633R/T1634R	T1631/T1632/T1633/T1634			
AJE-ICBK69LR/ICC69R/ICM69R/ICY69R	ICBK69L/ICC69/ICM69/ICY69		Epson WorkForce WF-2010W/WF-2510WF/WF-2520NF/WF-2530WF/WF-2540WF	
AJE-ICBK74R/ICC74R/ICM74R/ICY74R	ICBK74/ICC74/ICM74/ICY74	JPN	Epson PX-535F/PX-045A/PX-405A/PX-435A	
AJE-ICBK75R/ICC75R/ICM75R/ICY75R	ICBK75/ICC75/ICM75/ICY75		Epson PX-M741F/PX-M740F/PX-S740/PX-S5040/PX-M5040F/PX-M5041F	
AJE-ICBK76R/ICC76R/ICM76R/ICY76R	ICBK76/ICC76/ICM76/ICY76		Epson PX-M741F/PX-M740F	
AJE-ICBK80LR/ICC80LR/ICM80LR/ICY80LR/ICLC80LR/ICLM80LR	ICBK80LR/ICC80LR/ICM80LR/ICY80LR/ICLC80LR/ICLM80LR		Epson PX-S5040/PX-M5040F/PX-M5041F	
AJE-ITHBKRL/ITHCR/ITHMR/ITHYR/ITHLCR/ITHLMR	ITHBKRL/ITHCR/ITHMR/ITHYR/ITHLCR/ITHLMR		Epson-707A/Epson-777A/Epson-807AB/Epson-807AR/Epson-807AW/Epson-907F/Epson-	
			Epson 709A/Epson 710A/Epson 810AW/Epson 810AB	

AJE-SATBKR/SATCR/SATMR/SATYR/SATLCR /SATLMR	SATBKR/SATCR/SATMR/SATYR/SATLCR /SATLMR		Epson 712A/Epson 812A	
AJE-T1811R	T1811/T1812/T1813/T1814	EUR	Epson Expression Home XP-30/XP-102/XP-202/XP-205/XP-302/XP-305/XP-402/XP-405	
AJE-T200XL1R	T200XL1/T200XL2/T200XL3/T200XL4	NA	Epson Expression Home XP-200/XP-300/XP-400 Epson WorkForce WF-2520/WF-2530/WF-2540	
AJE-ICBK69LR	ICBK69L/ICC69/ICM69/ICY69	JPN	Epson PX-535F/PX-045A/PX-405A/PX-435A	
AJE-T2621R/T2631R/T2632R/T2633R/T2634R	T2621/T2631/T2632/T2633/T2634	EUR	Epson Expression Premium XP-600/XP-605/XP-700/XP-800	
AJE-T2431R/T2432R/T2433R/T2434R/T2435R/T2436R	T2431/T2432/T2433/T2434/T2435/T2436		Epson Expression Photo XP-750/XP-850/XP-960	
AJE-T2771R/T2772R/T2773R/T2774R/T2775R/T2776R	T2771/T2772/T2773/T2774/T2775/T2776	NA	Epson Expression Premium XP-850	
AJE-T2730R/T2731R/T2732R/T2733R/T2734R			Epson Expression Premium XP-600/XP-800	
AJE-T2690R/T2691R/T2692R/T2693R/T2694R	T2690/T2691/T2692/T2693/T2694	LA	Epson Expression Premium XP-702/XP-802	
AJE-ICBK70LR/ICC70LR/ICM70LR/ICY70LR/ICLC70LR/ICLM70LR	ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70L/ICLM70L	JPN	Epson EP-905F/EP-775AW	
AJE-ICBK92LR/ICC92LR/ICM92LR/ICY92LR	ICBK92L/ICC92L/ICM92L/ICY92L		Epson PX-M840/PX-S840	
AJE-T7891R/T7892R/T7893R/T7894R	T7891/T7892/T7893/T7894	EUR	Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/WF-5190DW	
AJE-T7901R/T7902R/T7903R/T7904R	T7901/T7902/T7903/T7904		Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/ WF-5190DW/WF-4640/WF-4630	
AJE-T7911R/T7912R/T7913R/T7914R	T7911/T7912/T7913/T7914	NA/EUR	Epson SureColor SC-P600	
AJE-T7601R/T7602R/T7603R/T7604R/T7605R/ T7606R/T7607R/T7608R/T7609 R	T7601/T7602/T7603/T7604/T7605/T7606/ T7607/T7608/T7609		Epson SureColor P400	
AJE-T3240R/T3241R//T3242R/T3243R/T3244R/T3247R/T3248R/T3249R	T3240/T3241//T3242/T3243/T3244/T3247/T3248/T3249	EUR	Epson WorkForce Pro WF-8010DW/WF-8090DTC/8590DWF/WF-8590D3TWFC/WF-8090D3TWC/WF-8090DW/WF-8590DTWF/WF-8090DTW/WF-8510DWF/WF-8590DTWFC	
AJE-T7561/T7562//T7563/T7564	T7561/T7562//T7563/T7564	(NA/LA)	Epson WorkForce Pro WF-6090/WF-6590/WF-8090/WF-8590	
AJE-T748XXL1/T748XXL2//T748XXL3/T748XXL4	T748XXL1/T748XXL2//T748XXL3/T748XXL4			
for Epson New 7-pin Series Inkjet Cartridge (III)				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-T1241/T1242/T1243/T1244	T1241/T1242/T1243/T1244	NA	Epson Stylus NX125/NX420/NX430/NX330/NX230 Epson Workforce 320/323/325/435	
AJE-T1251/T1252/T1253/T1254	T1251/T1252/T1253/T1254		Epson Stylus NX125/NX625/NX420/NX230 Epson Workforce 320/323/325/520	
AJE-T1261/T1262/T1263/T1264	T1261/T1262/T1263/T1264		Epson WorkForce 630/635/60/840/435/545/645/845 Epson Stylus NX430/NX330 Epson WorkForce WF-3520/3540	
AJE-T1271/T1272/T1273/T1274	T1271/T1272/T1273/T1274		Epson Stylus NX625 Epson Workforce 630/635/60/840/545/645/845 Epson WorkForce WF-3520/3540	
AJE-T1261/T1261/T1262/T1263/T1264	T1261/T1261/T1262/T1263/T1264		Epson Workforce 520	
AJE-T1281/T1282/T1283/T1284	T1281/T1282/T1283/T1284	EUR	Epson Stylus S22/SX125/SX420W/SX425W/SX235W/SX130/ SX435W/SX230/SX440W Epson Stylus Office BX305F/BX305FW	
AJE-T1291/T1292/T1293/T1294	T1291/T1292/T1293/T1294		Epson Stylus SX420W/SX425W/SX525WD/SX620FW/ SX445/SX235W/SX435W/SX230/SX440W/SX535WD Epson Stylus Office BX305F/BX305FW/BX320FW/BX525WD/BX625FWD/ B42WD/BX925FWD/BX925FW/BX535WD/BX635FWD/BX935FWD Epson WorkForce WF-3540DTWF	
AJE-T1301/T1302/T1303/T1304	T1301/T1302/T1303/T1304		Epson Stylus SX525WD/SX620FW/SX445/SX535W Epson Stylus Office BX525WD/BX625FWD/BX925FWD/B42WD/ BX925FW/BX535WD/BX635FWD/BX935FWD Epson WorkForce WF-3540DTWF	
AJE-T1321/T1322/T1323/T1324	T1321/T1322/T1323/T1324	NA	Epson Stylus N11 Epson NX125 (AU)	
AJE-T1331/T1332/T1333/T1334	T1331/T1332/T1333/T1334	NA/ASIA	Epson Stylus N11/NX420/T12/T22/TX120/NX125/TX129/ TX420W/TX235/TX430W/NX230/TX130 Epson Workforce 320/435 (AU/AP)	
AJE-T1381/T1382/1383/T1384	T1381/T1382/T1383/T1384		Epson Stylus NX420/TX420W/TX235/TX430W/NX230 Epson Workforce 320/630/633/435 (AU/AP)	
AJE-T1401/T1402/T1403/T1404	T1401/T1402/T1403/T1404	NA	Epson Workforce 630/633 Epson Stylus Office TX620FWD Epson Stylus TX560WD (AU)	

AJE-T1411/T1412/T1413/T1414	T1411/T1412/T1413/T1414	AP	Epson ME 32/33/320/330/35/350/340 Epson ME Office 620F/560W/570W/960FWD/900WD/535/85ND Epson WF-7018		
AJE-T1431/T1432/T1433/T1434	T1431/T1432/T1433/T1434		Epson ME Office 960FWD/900WD/940FW/85ND Epson WF-7018		
AJE-T1731/T1732/T1733/T1734	T1731/T1732/T1733/T1734		Epson ME 35/350		
AJE-T1421/T1412/T1413/T1414	T1421/T1412/T1413/T1414		Epson ME Office 620F/560W		
AJE-T1371/T1371	T1371/T1371		Epson BK100/BK200		
AJE-T1321/T1332/T1333/T1334	T1321/T1332/T1333/T1334		LA		Epson Stylus T22/TX120 (SA)
AJE-T1351/T1332/T1333/T1334	T1351/T1332/T1333/T1334	Epson Stylus T25/TX125/TX135 (SA)			
AJE-T1381/T1332/T1333/T1334	T1381/T1332/T1333/T1334	Epson Stylus TX420W/TX320F/TX235W (SA)			
AJE-T1381/T1381/T1402/T1403/T1404	T1381/T1381/T1402/T1403/T1404	Epson Stylus Office TX525FW (SA)			
AJE-T1361/T1361	T1361/T1361	Epson WorkForce BK101 (SA)			
AJE-ICBK67/ICBK67	ICBK67/ICBK67	JPN	Epson PX-BK100		
AJE-ICBK62/ICC62/ICM62/ICY62	ICBK62/ICC62/ICM62/ICY62		Epson PX-430A/PX-403A/PX-404A/PX-434A/PX-675F		
AJE-ICBK61/ICC62/ICM62/ICY62	ICBK61/ICC62/ICM62/ICY62		Epson PX-503A/603F/203/PX-675F		
AJE-ICBK61/ICC65/ICM65/ICY65	ICBK61/ICC65/ICM65/ICY65		Epson PX-673F/1600F/1200/1700F		
AJE-T1590/T1591/T1592/T1593/T1594/T1597/T1598/T1599	T1590/T1591/T1592/T1593/T1594/T1597/T1598/T1599		NA		Epson Stylus Photo R2000 (8 colors)
AJE-T1571/T1572/T1573/T1574/T1575/T1576/T1577/T1578/T1579	T1571/T1572/T1573/T1574/T1575/T1576/T1577/T1578/T1579	Epson Stylus Photo R3000 (9 colors)			
AJE-ICBK64/ICMB64/ICC64/ICVM64/ICY64/ICLC64/ICVLM64/ICGY64/ICLG64	ICBK64/ICMB64/ICC64/ICVM64/ICY64/ICLC64/ICVLM64/ICGY64/ICLG64	JPN	Epson Stylus Photo PX-5V (9 colors)		
AJE-T7441	T7441	AP	Epson WorkForce Pro WP-M4015dn		
AJE-T6761/T6762/T6763/T6764	T676XL1/T676XL2/T676XL3/T676XL4	/	WorkForce Pro (WP-Series) WP-4520/4530/4533/4540/4590/4010/4020/4023/4090 (NA)		
AJE-T6771/T6772/T6773/T6774	T6771/T6772/T6773/T6774	CHN	Epson WorkForce Pro WP-4511/WP-4531/WP-4521		
AJE-T6781/T6782/T6783/T6784	T6781/T6782/T6783/T6784		Epson WorkForce Pro WP-4011/WP-4511/WP-4521		
AJE-T7011/T7012/T7013/T7014	T7011/T7012/T7013/T7014	EUR	Epson WorkForce Pro WP-4025/WP-4015/WP-4525/WP-4545/WP-4595		
AJE-T7021/T7022/T7023/T7024	T7021/T7022/T7023/T7024		Epson WorkForce Pro WP-4590/4023		
AJE-T7031/T7032/T7033/T7034	T7031/T7032/T7033/T7034				
AJE-T7111/T7112/T7113/T7114	T711XXL120/T711XXL220/T711XXL320/T711XXL420	JPN	Epson PX-B750F/B700		
AJE-ICBK90M/ICC90M/ICM90M/ICY90M	ICBK90M/ICC90M/ICM90M/ICY90M				
AJE-ICBK90L/ICC90L/ICM90L/ICY90L	ICBK90L/ICC90L/ICM90L/ICY90L				
AJE-T6551/T6552/T6553/T6554/T6555/T6556/T6557/T6558/T6559/T655A/T655B	T6551/T6552/T6553/T6554/T6555/T6556/T6557/T6558/T6559/T655A/T655B	/	Epson Stylus Pro 4910		
AJE-T6531/T6532/T6533/T6534/T6535/T6536/T6537/T6538/T6539/T653A/T653B	T6531/T6532/T6533/T6534/T6535/T6536/T6537/T6538/T6539/T653A/T653B		Epson Stylus Pro 4900		
AJE-T9131/T9132/T9133/T9134/T9135/T9136/T9137/T9138/T9139/T913A/T913B/T913D	T9131/T9132/T9133/T9134/T9135/T9136/T9137/T9138/T9139/T913A/T913B/T913D	NA/EUR	Epson SureColor P5000		
AJE-T9151/T9152/T9153/T9154/T9155/T9156/T9157/T9158/T9159/T915A/T915B/T915D	T9151/T9152/T9153/T9154/T9155/T9156/T9157/T9158/T9159/T915A/T915B/T915D	CHN	Epson SureColor P5080		
AJE-T6190	T6190	/	Epson Stylus Pro 4900/4910		
AJE-T5820	T5820		Epson SureLab D700 Epson SureColor P800 Epson SC-PX3V Epson SureLab D800		
AJE-T6710/T6711	T6710/T6711		WW		
AJE-T6712	T6712	WW	Epson WorkForce Pro WF-6090/WF-6590/WF-8090//WF-8010/WF-8510/WF-8590/WF-R8590		
AJE-SJMB3500	SJMB3500	JPN	TM-C3500		
for Epson 9-pin Series Inkjet Cartridge (II)					
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo	
AJE-T6361/T6362//T6363/T6364/T6365/T6366/T6367/T6368/T6369/T636A//T636B	T6361/T6362//T6363/T6364/T6365/T6366/T6367/T6368/T6369/T636A/T636B	/	Epson Stylus Pro 7700/7900(EUR)		

AJE-0731N/0732N/0733N/0734N	T0731N/T0732N/T0733N/T0734N	/	Epson Stylus T10/T11/T20/T21/T40W/T13/TX220/T20E/TX213 Epson Stylus TX100/TX101/TX200/TX209/TX110/TX210/TX300F/TX121 Epson Stylus TX400/TX409/TX550W/TX610/TX600FW/TX410 Epson Stylus C79/CX8300/CX5500
AJE-0731HN/0732N/0733N/0734N	T0731HN/T0732N/T0733N/T0734N	/	Epson Stylus T40W/TX550W/TX410/TX200/TX400 Epson Stylus TX610/TX600FW/C110/C7300/CX8300/ C9300F/TX200/TX210/TX220/TX300F/TX510FN/ TX400/TX550W/T30/T1100
AJE-0851N/0852N/0853N/0854N/0855N/0856N	T0851N/T0852N/T0853N/T0854N/T0855N/T0856N	/	Epson Stylus T60
AJE-0901N/0732N/0733N/0734N	T0901N/T0732N/T0733N/T0734N	/	Epson Stylus T20/TX100
AJE-0911N/0912N/0913N/0914N	T0911N/T0912N/T0913N/T0914N	/	Epson Stylus TX101/T21/TX110/TX210/TX111/TX610/TX121/C91
AJE-0921N/0922N/0923N/0924N	T0921N/T0922N/T0923N/T0924N	/	Epson Stylus T26//T27/TX117/TX119/TX106/TX109/CX4300/C91
AJE-0981/0982/0983/0984/0985/0986	T0981/T0982/T0983/T0984/T0985/T0986	/	Epson Artisan 600/700/800/710/810/725/835/837/730
AJE-0981/0992/0993/0994/0995/0996	T0981/T0992/T0993/T0994/T0995/T0996	/	
AJE-0811N/0812N/0813N/0814N/0815N/0816N	T0811N/T0812N/T0813N/T0814N/T0815N/T0816N	/	Epson Stylus Photo TX700/TX800/T50/TX710W/TX650/TX810FW/TX820FWD Epson Stylus RX615/R270/R290;Epson Artisan 1430/837
AJE-0821N/0822N/0823N/0824N/0825N/0826N	T0821N/T0822N/T0823N/T0824N/T0825N/T0826N	/	Epson Stylus Photo TX700/TX800/TX710W/TX650/TX810FW/TX820FWD Epson Stylus Photo RX615/R270/R290 Epson Stylus Photo T50/T59 Epson Artisan 837
AJE-1171/0732N/0733N/0734N	T1171/T0732N/T0733N/T0734N	/	Epson Stylus T23/T24/TX105/TX115
AJE-1031/1032/1033/1034	T1031/T1032/T1033/T1034	/	Epson Stylus T40W/TX600FW/TX550W/TX610
AJE-0961/0962/0963/0964/0965/0966/0967/0968/0969	T0961/T0962/T0963/T0964/T0965/T0966/T0967/T0968/T0969	/	Epson Stylus Photo R2880
AJE-0731HN/0731HN/0732N/0733N/0734N	T0731HN/T0731HN/T0732N/T0733N/T0734N	/	Epson Stylus T30
AJE-1151/1151/0732N/0733N/0734N	T1151/T1151/T0732N/T0733N/T 0734N	/	Epson Stylus T33
AJE-1151/1151/1032/1033/1034	T1151/T1151/T1032/T1033/T1034	/	Epson Stylus TX515FN
AJE-0971/0682/0683/0684	T0971/T0682/T0683/T0684	/	Epson WorkForce 40/500/600/610/615 Epson WorkForce NX510/515
AJE-1001/1002/1003/1004	T1001/T1002/T1003/T1004	/	Epson Stylus SX600FW/SX510W
AJE-1231/1232/1233/1234	T1231/T1232/T1233/T1234	/	Epson Stylus ME OFFICE 80W/700FW
AJE-1191/1191/1092/1093/1094	T1191/T1191/T1092/T1093/T1094	/	Epson ME OFFICE 70/1100
AJE-1191/1191/1232/1233/1234	T1191/T1191/T1232/T1233/T1234	/	Epson ME OFFICE 1100
AJE-1091/1091/1092/1093/1094	T1091/T1091/T1092/T1093/T1094	/	
AJE-1091/1092/1093/1094	T1091/T1092/T1093/T1094	/	Epson ME 30/ME360/ME300/ Epson ME OFFICE 70 Epson ME OFFICE 360/80W/700FW/600F/510/520
AJE-0691/0692/0693/0694	T0691/T0692/T0693/T0694	/	Epson Stylus CX7400/CX7000F/CX6000/CX5000 Epson Stylus CX8400/CX9400FAX/CX7450/CX9475FAX Epson Stylus NX100/NX115/NX200/NX215/NX400/NX300/ NX415/NX105/NX110/NX305/NX510/NX515 Epson Workforce 30/500/600/610/615/40
AJE-0691/0691/0692/0693/0694	T0691/T0691/T0692/T0693/T0694	/	Epson Stylus WorkForce 30/310/315/1100
AJE-0681/0681/0692/0693/0694	T0681/T0681/T0692/T0693/T0694	/	Epson Stylus C120
AJE-0681/0682/0683/0684	T0681/T0682/T0683/T0684	/	Epson WorkForce 40/500/600/610/615 Epson NX510/515/CX5000/CX6000/CX7000F/CX8400/CX9400/CX9475



AJE-0711/0712/0713/0714	T0711/T0712/T0713/T0714	/	Epson Stylus D78/D92/DX7000F/DX5000/ DX4050/4000/4400/4450/DX5050/DX6000 Epson Stylus DX6050/DX7400/DX7450/DX8400/DX8450/DX9400/DX9400F Epson Stylus S20/S21 Epson Stylus SX100/SX110/SX200/SX209/SX210/SX400/SX510W Epson Stylus SX410/SX610FW/SX600FW/SX205/SX215/SX105/SX405 Epson Stylus BX310FN/BX300F/BX3450F/BX600FW/BX610FW/B40W	
AJE-0711H/0712/0713/0714	T0711H/T0712/T0713/T0714	/	Epson Stylus SX410/SX510W	
AJE-0731/0732/0733/0734	T0731/T0732/T0733/T0734	/	Epson Stylus C79/C90/C92 Epson Stylus CX3900/CX4900/CX4905/CX5600/CX5900F/CX6900F Epson Stylus CX7310/8300/CX7300 Epson Stylus CX5500/CX5501/CX5505/CX5510	
AJE-0731H	T0731H	/	Epson CX3900/ CX3905/CX4900/CX4905/CX5500/CX5501/CX5505/CX5510/CX5600 T0731N)/CX5900/CX6900F/CX7300/CX7310/CX8300/ CX9300/ CX9300F/C79/C90/C92/C110/T10/T11/T13/T13X/T20/T20E/ T22E/T21/T30/T33/T40W/TX100/TX101/TX102/TX103/TX11	
AJE-0881/0882/0883/0884	T0881/T0882/T0883/T0884	/	Epson Stylus CX4400/CX4450/CX7400/CX7450/N11 Epson Stylus NX200/NX400/NX100/NX115/NX105/NX110/ NX215/NX300/NX305/NX415/NX510	
AJE-0891/0892/0893/0894	T0891/T0892/T0893/T0894	/	Epson Stylus S20/S21 Epson Stylus SX100/SX105/SX115/SX110/SX210/SX215/SX218/SX415 Epson Stylus SX200/SX205/SX400/SX405/SX410/SX510W	
AJE-0911/0912/0913/0914	T0911/T0912/T0913/T0914	/	Epson Stylus C90/CX5500/CX5501/CX5510/CX5505	
AJE-0901/0732/0733/0734	T0901/T0732/T0733/T0734	/	Epson Stylus C92/C90/CX5600/T20/T21/TX110	
AJE-0921/0922/0923/0924	T0921/T0922/T0923/T0924	/	Epson Stylus C91/CX4300	
AJE-0771/0772/0773/0774/0775/0776	T0771/T0772/T0773/T0774/T0775/T0776	/	Epson Stylus Photo R260/R380/R280 Epson Stylus Photo RX580/RX680/RX595 Epson Artisan 50	
AJE-0781/0782/0783/0784/0785/0786	T0781/T0782/T0783/T0784/T0785/T0786	/	Epson Stylus Photo R260/R380/R280 Epson Stylus Photo RX580/RX680/RX595 Epson Artisan 50	
AJE-0791/0792/0793/0794/0795/0796	T0791/T0792/T0793/T0794/T0795/T0796	/	Epson Stylus Photo 1400/PX700W/PX800FW/P50/PX830FWD Epson Artisan 1430	
AJE-0801/0802/0803/0804/0805/0806	T0801/T0802/T0803/T0804/T0805/T0806	/	Epson Stylus Photo R265/R360/R285 Epson Stylus Photo RX585/RX685/RX560 Epson Stylus Photo P50/PX820FWD/PX830FWD Epson Stylus PX700W/PX710W/PX800FW/PX810/PX650/ PX50/PX660/PX720WD/PX730WD	
AJE-0811/0812/0813/0814/0815/0816	T0811/T0812/T0813/T0814/T0815/T0816	/	Epson Stylus Photo R390/RX590/R270/RX690/RX610/RX615/R290/R295 Epson Stylus photo 1410	
AJE-0821/0822/0823/0824/0825/0826	T0821/T0822/T0823/T0824/T0825/T0826	/	Epson Stylus R390/R270/R290/R295 Epson Stylus RX590/RX615/RX610/RX690	
AJE-0851/0852/0853/0854/0855/0856	T0851/T0852/T0853/T0854/T0855/T0856	/	Epson Stylus Photo 1390	
AJE-0870/0871/0872/0873/0874/0877/0878/0879	T0870/T0871/T0872/T0873/T0874/T0877/T0878/T0879	/	Epson Stylus Photo R1900	
AJE-5971/5972/5973/5974/5975/5976/597A/597B/5978	T5971/T5972/T5973/T5974/T5975/T5976/T597A/T597B/T5978	/	Epson Stylus Pro 7910/9910/7710/9710	
for Epson Large Format Application				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-6071/6072/6073/6074/6075/6076/6077/6079	T6071/T6072/T6073/T6074/T6075/T6076/T6077/T6079	/	Epson Stylus Pro 4880 ColorBurst Epson Stylus Pro 4880 Portrait Edition	
AJE-6041/6042/6043/6044/6045/6046/6047/6049/6128	T6041/T6042/T6043/T6044/T6045/T6046/T6047/T6049/T6128	/	Epson Stylus PRO 9880C/7880C	
AJE-6051/6052/6053/6054/6055/6056/6057/6059	T6051/T6052/T6053/T6054/T6055/T6056/T6057/T6059	/	Epson Stylus Pro 4880 ColorBurst Epson Stylus Pro 4880 Portrait Edition (USA)	
AJE-499/500/501/502/503/504	T499/T500/T501/T502/T503/T504	/	Epson Stylus Pro 10000/10600 (PHOTOGRA)	
AJE-511/512/513/514/515/516	T511/T512/T513/T514/T515/T516	/	Epson Stylus Pro 10000CF/10600 (ARCHIVAL)	
AJE-5431/5432/5433/5434/5435/5436/5437	T5431/T5432/T5433/T5434/T5435/5436/T5437	/	Epson Stylus Pro 4000/7600/9600 (ULTRACHROME)	
AJE-5438	T5438	/	Epson Stylus Pro 4000/4400/4800/7600/9600 (ULTRACHROME)	

AJE-5441/5442/5443/5444/5445/5446/5447	T5441/T5442/T5443/T5444/T5445/T5446/T5447	/	Epson Stylus Pro 4000/9600 (ULTRACHROME)	
AJE-5448	T5448	/	Epson Stylus Pro 4000/4400/4800/9600 (ULTRACHROME)	
AJE-5451/5452/5453/5454/5455/5456	T5451/T5452/T5453/T5454/5455/5456	/	Epson Stylus Pro 7600/9600 (ULTRACHROME)	
AJE-5491/5492/5493/5494/5495/5496/5497/5498	T5491/T5492/T5493/T5494/5495/5496/5497/5498	/	Epson Stylus Pro 10600	
AJE-5621/5622/5623/5624/5625/5626/5627/5629	T5621/T5622/T5623/T5624/5625/5626/5627/5629	/	Epson Stylus Pro 7800/9800	
AJE-5631/5632/5633/5634/5635/5636/5637/5639	T5631/T5632/T5633/T5634/5635/5636/5637/5639	/	Epson Stylus Pro 7800/9800	
AJE-5641/5642/5643/5644/5645/5646/5647/5649	T5641/T5642/T5643/5644/5645/5646/5647/5649	/	Epson Stylus Pro 4800	
AJE-5651/5652/5653/5654/5655/5656/5657/5659	T5651/T5652/T5653/T5654/5655/5656/5657/5659	/	Epson Stylus Pro 4800	
AJE-5662/5663/5664/5668/5678	T5662/T5663/5664/5668/5678	/	Epson Stylus Pro 7400/7800/9400/9800	
AJE-5672/5673/5674	T5672/T5673/5674	/	Epson Stylus Pro 7400/9400	
AJE-T103BK/T102C/T102M/T102Y SAMPLE!	T103BK/T102C/T102M/T102Y	/	Epson Noritsu d502 duplex	
AJE-5801/5802/5803/5804/5805/5806/5807/5808/5809	T5801/T5802/5803/5804/5805/5806/5807/5808/5809	/	Epson Stylus Pro 3800/3805	
AJE-5811/5812/5813/5814/5815/5816/5817/5818/5819	T5811/T5812/5813/5814/5815/5816/5817/5818/5819	/	Epson Stylus Pro 3800C	
AJE-5891/5892/5893/5894/5895/5896/5897/5898/5899	T5891/T5892/5893/5894/5895/5896/5897/5898/5899	/	Epson Stylus Pro 3850	
for Epson 7-pin Series Inkjet Cartridge (A/B)				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE- C8901	C8901	/	Epson Stylus Pro 4000/4450/4800/4880/7600/7880/7890/ 7900/9600/9880/9890/9900/11880/WT7900 Epson SureLab SL-D3000/D3000 Epson SureColor SC-P6000/PX-20000/PX-7000/PX-7500/PX-7500N/PX-7550/PX-9000/ PX-9500/PX-9500N/PX-9550/PX-H10000/PX-H7000/PX-H8000/PX-H9000/PX-W8000/ SL-D30SS/SL-D30SSC/SL-D30WS/SL-D30WSCPX-20000/PX-7000/PX-7500/PX-7500N/PX-7550/ PX-9000/PX-9500/PX-9500N/PX-9550/PX-H10000/PX-H7000/PX-H8000/PX-H9000/PX-W8000/ SL-D30SS/SL-D30SSC/SL-D30WS/SL-D30WSC	
AJE-007	T007/T008/T009/T017/T018	/	Epson Stylus Photo 780/785/785EPX/790/870/875/890/895/900/915 Epson Stylus Photo 1270/1280/1290/1290S Epson Stylus Photo 825/777/777i Epson Stylus COLOR 680/685 Epson 1000 ICS	
AJE-015/016	T015/T016	/	Epson Stylus Photo 2000SP	
AJE-C100 SAMPLE!	C100	/	Epson TM-C100	
AJE-026/027	T026/T027/T028/T029	/	Epson Stylus Photo 810/820/830/830U Epson Stylus Photo 925/935 Epson Stylus Photo C60/C61/CX3100	
AJE-0321/0322/0323/0324	T0321/T0322/T0323/T0324	/	Epson Stylus C80/C80WN/C80N	
AJE-0331/0331/0332/0333/0334/0335/0336	T0331/T0331/T0332/T0333/T0334/T0335/T0336	/	Epson Stylus Photo 950/960	
AJE-0341/0342/0343/0344/0345/0346/0347/0348	T0341/T0342/T0343/T0344/T0345/T0346/T0347/T0348	/	Epson Stylus Photo 2100/2200	
AJE-036/037	T036/T037	/	Epson Stylus C42/C44/C46	
AJE-038/039	T038/T039	/	Epson Stylus C41/C43/C43U/C45 Epson Stylus CX1500/CX1500v	
AJE-040/041	T040/T041	/	Epson Stylus CX3200/C62	
AJE-0321/0422/0423/0424	T0321/T0422/T0423/T0424	/	Epson Stylus CX5200/CX5400 Epson Stylus C82/C82N/C82WN	
AJE-0431/0442/0443/0444	T0431/T0442/T0443/T0444	/	Epson Stylus C84/C84N/C84WN Epson Stylus CX6400/CX6600	
AJE-0441/0442/0443/0444	T0441/T0442/T0443/T0444	/	Epson Stylus C64/C66/C84/C84N/C84WN/C86 Epson Stylus CX3600/CX3650 Epson Stylus CX4600/CX6400/CX6600	
AJE-0441/0452/0453/0454	T0441/T0452/T0453/T0454	/	Epson Stylus C64/C66/C84/C86 Epson Stylus CX6600/CX3600/CX3650	
AJE-0461/0472/0473/0474	T0461/T0472/T0473/T0474	/	Epson Stylus C63/C65/C83/C85 Epson Stylus CX3500/CX4500/CX6300/CX6500	
AJE-0481/0482/0483/0484/0485/0486	T0481/T0482/T0483/T0484/T0485/T0486	/	Epson Stylus Photo R200/R220/R300/R300M/R320/R340 Epson Stylus Photo RX500/RX600/RX620	

AJE-0491/0492/0493/0494/0495/0496	T0491/T0492/T0493/T0494/0495/T0496	/	Epson Stylus Photo R210/R230/R310/R350 Epson Stylus Photo RX510/RX630	
AJE-0540/0541/0542/0543/0544/0547/0548/0549	T0540/T0541/T0542/T0543/0544/T0547/T0548/T0549	/	Epson Stylus Photo R800/R1800	
AJE-0551/0552/0553/0554	T0551/T0552/T0553/T0554	/	Epson Stylus Photo R240/RX420/RX425/RX520	
AJE-5591/5592/5593/5594/5595/5596	T5591/T54592/T5593/T5594/T5595/T5596	/	Epson Stylus Photo RX700	
AJE-0561/0562/0563/0564	T0561/T0562/T0563/T0564	/	Epson Stylus Photo R250/RX430/RX530	
AJE-057/058	T057/T058	/	Epson ME 1/ME 100/ME1+	
AJE-0557	T0557	/	Epson PictureMate 500	
AJE-0573	T0573	/	Epson PictureMate 100 Epson PictureMate 100 Mobile Phone Edition	
AJE-0591/0592/0593/0594/0595/0596/0597/0598/0599	T0591/T0592/T0593/T0594/T0595/T0596/T0597/T0598/T0599	/	Epson Stylus Photo R2400	
AJE-0601/0602/0603/0604	T0601/T0602/T0603/T0604	/	Epson Stylus C88 Epson Stylus CX3800/CX3810/CX4200/CX4800/CX5800F/CX7800	
AJE-0611H/0611/0612/0613/0614	T0611H/T0611/T0612/T0613/T0614	/	Epson Stylus D88/D68 series Epson Stylus DX3800/DX3850 Epson Stylus DX4800/DX4850	
AJE-0631/0632/0633/0634	T0631/T0632/T0633/T0634	/	Epson Stylus C67/C87 Epson Stylus CX3700/CX4100/CX4700	
AJE-066/067	T066/T067	/	Epson Stylus C48	
AJE-0841/0842/8043/0844	T0841/T0842/T0843/T0844	/	Epson Stylus Photo 20	
AJE-0751/0752/0753/0754	T0751/T0752/T0753/T0754	/	Epson Stylus C59/CX2900/CX2905	
AJE-0761/0762/0763/0764	T0761/T0762/T0763/T0764	/	Epson ME200/ME2/C58	
AJE-5846	T5846	/	Epson PictureMate Flash-PM280 Epson PictureMate pal-PM 200 Epson PictureMate Snap-PM 240/290/225	
AJE-5852	T5852	/	Epson Picture Mate PM210/250/270/235/215/245	
AJE-EPM5BKL/EPM5CL/EPM5ML/EPM5YL SAMPLE!	EPM5BKL/EPM5CL/EPM5ML/EPM5Y	/	Epson EMP 5000 (JP)	
for Epson 7-pin Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-0321R	T0321/T0322/T0323/T0324	/	Epson Stylus C70/C80/C80N/C80WN/C82/C82N/C82WN Epson Stylus CX5200/CX5300/CX5400	
AJE-0331R	T0331/T0331/T0332/T0333/T0334/T0335/T0336	/	Epson Stylus Photo 950/960	
AJE-036R	T036/T037	/	Epson Stylus C42/C44/C46	
AJE-038R	T038/T039	/	Epson Stylus C41/C43/C43U/C45 Epson Stylus CX1500/CX1500v	
AJE-040R	T040/T041	/	Epson Stylus CX3200/C62	
AJE-0441R	T0441/T0442/T0443/T0444	/	Epson Stylus C64/C66/C84/C84N/C84WN/C86 Epson Stylus CX3600/CX3650/CX4600/CX6400/CX6600	
AJE-0461R	T0461/T0472/T0473/T0474	/	Epson Stylus C63/C65/C83/C85 Epson Stylus CX6300/CX6500/CX3500/CX4500	
AJE-0481R	T0481/T0482/T0483/T0484/T0485/T0486	/	Epson Stylus Photo R200/R220/R300/R300M/R320/R340 Epson Stylus Photo RX500/RX600/RX620	
AJE-0491R	T0491/T0492/T0493/T0494/T0495/T0496	/	Epson Stylus Photo R210/R230/R310/R350 Epson Stylus Photo RX510/RX630	
AJE-0551R	T0551/T0552/T0553/T0554	/	Epson Stylus Photo R240/RX420/RX425/RX520	
AJE-5591R	T5591/T5592/T5593/T5594/T5595/T5596	/	Epson Stylus Photo RX700	
AJE-0561R	T0561/T0562/T0563/T0564	/	Epson Stylus Photo R250/RX430/RX530	
AJE-057R	T057/T058	/	Epson ME 1 Epson ME 100 Epson ME1+	
AJE-0601R	T0601/T0602/T0603/T0604	/	Epson Stylus C88/CX3800/CX3810/CX4200/CX4800/CX5800F/CX7800	
AJE-0611R	T0611H/T0611/T0612/T0613/T0614	/	Epson Stylus D88/D68 series	
AJE-0631R	T0631/T0632/T0633/T0634	/	Epson Stylus C67/C87	
AJE-066R	T066/T067	/	Epson Stylus C48	
AJE-0841R	T0841/T0842/T0843/T0844	/	Epson Stylus Photo 20	
AJE-0741R	T0741/T0742/T0743/T0744	/	Epson CX4080	
AJE-0751R	T0751/T0752/T0753/T0754	/	Epson Stylus C59/CX2900/CX2905	
AJE-0761R	T0761/T0762/T0763/T0764	/	Epson ME2/ME20	

for Epson 9-pin Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-0731NR	T0731N/T0732N/T0733N/T0734N	/	Epson Stylus T10/T11/T20/T21/T40W/T13/TX220/T20E/TX213 Epson Stylus TX100/TX101/TX200/TX110/TX209/TX210/TX300F/TX121 Epson Stylus TX400/TX409/TX550W/TX610/TX600FW/TX410 Epson Stylus C79/CX8300/CX5500	
AJE-0811NR	T0811N/T0812N/T0813N/T0814N/T0815N/T0816N	/	Epson Stylus Photo TX700/TX800/T50/TX710W/TX650/TX810FW/T59/TX820FWD	
AJE-0821NR	T0821N/T0822N/T0823N/T0824N/T0825N/T0826N	/	Epson Stylus Photo RX615/R270/R290	
AJE-0911NR	T0911N/T0912N/T0913N/T0914N	/	Epson Stylus TX101/T21/TX110/TX210/C91/TX111/TX610/TX121	
AJE-0851NR	T0851N/T0852N/T0853N/T0854N/T0855N/T0856N	/	Epson Stylus T60	
AJE-0921NR	T0921N/T0922N/T0923N/T0924N	/	Epson Stylus T26/TX106/TX109/T27/TX117/TX119 Epson Stylus CX4300/C91	
AJE-0981R	T0981/T0982/T0983/T0984/T0985/T0986	/	Epson Artisan 600/700/800/710/810/837	
AJE-0982R	T0981/T0982/T0983/T0984/T0985/T0986	/		
AJE-1171R	T1171/T0732N/T0733N/T0734N	/	Epson Stylus T23/TX105/T24/TX115	
AJE-1151R	T1151/T1151/T0732N/T0733N/T0734N	/	Epson Stylus T33	
AJE-1033R	T1151/T1151/T1032/T1033/T1034	/	Epson Stylus T1110/TX515FN	
AJE-1031R	T1031/T1032/T1033/T1034	/	Epson Stylus T40W/TX600FW/TX550W/TX610	
AJE-0731HNR	T0731HN/T0731HN/T1032/T1033/T1034	/	Epson Stylus T1100/TX510FN	
AJE-1032R	T0731HN/T0731HN/T1032/T1033/T1034	/		
AJE-1091R	T1091/T1092/T1093/T1094	/	Epson ME30/ME360/ME300 Epson ME OFFICE 70 Epson ME OFFICE 360/80W/700FW/600F/510	
AJE-1191R	T1191/T1191/T1092/T1093/T1094	/	Epson ME OFFICE 70/1100	
AJE-0681R	T0681/T0682/T0683/T0684	/	Epson WorkForce 40/500/600/610/615 Epson WorkForce NX510/515/CX5000/CX6000/CX7000F/CX8400/CX9400/CX9475	
AJE-0691R	T0691/T0692/T0693/T0694	/	Epson Stylus CX7400/CX7000F/CX6000/CX5000/CX8400	
AJE-0711R	T0711/T0712/T0713/T0714	/	Epson Stylus D78/D92/DX7000F/DX5000/DX4050/4000/4400/4450	
AJE-0711HR	T0711H/T0712/T0713/T0714	/	Epson Stylus D120	
AJE-0731R	T0731/T0732/T0733/T0734	/	Epson Stylus C79/C90/C92	
AJE-0881R	T0881/T0882/T0883/T0884	/	Epson Stylus CX4400/CX4450/CX7400/CX7450/N11	
AJE-0891R	T0891/T0892/T0893/T0894	/	Epson Stylus S20/SX510W/SX410	
AJE-0911R	T0911/T0912/T0913/T0914	/	Epson Stylus CX5500/CX5501/CX5510/CX5505/C90	
AJE-0921R	T0921/T0922/T0923/T0924	/	Epson Stylus CX4300/C91	
AJE-0771R	T0771/T0772/T0773/T0774/T0775/T0776	/	Epson Stylus Photo R260/R380/R280 Epson Stylus Photo RX580/RX680/RX595 Epson Stylus Photo Artisan50	
AJE-0781R	T0781/T0782/T0783/T0784/T0785/T0786	/	Epson Stylus Photo 1400/PX700W/PX800FW/P50	
AJE-0791R	T0791/T0792/T0793/T0794/T0795/T0796	/		
AJE-0801R	T0801/T0802/T0803/T0804/T0805/T0806	/	Epson Stylus Photo R265/R360/R285 Epson Stylus Photo RX585/RX685 Epson Stylus Photo P50 Epson Stylus PX700W/PX710W/PX800FW/PX810/PX650/PX50	
AJE-0811R	T0811/T0812/T0813/T0814/T0815/T0816	/	Epson Stylus Photo R270/R390/RX590/R295/ RX690/RX610/RX615/R290	
AJE-0821R	T0821/T0822/T0823/T0824/T0825/T0826	/	Epson Stylus photo 1410	
AJE-0851R	T0851/T0852/T0853/T0854/T0855/T0856	/	Epson Stylus Photo 1390	
AJE-0871R	T0870/T0871/T0872/T0873/T0874/T0877/T0878/T0879	/	Epson Stylus Photo R1900	
AJE-0878R		/		
AJE-0961R	T0961/T0962/T0963/T0964/T0965/T0966/T0967/T0968/T0969	/	Epson Stylus Photo R2880	
AJE-0967R		/		
for Epson New 7-pin Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-T1361R	T1361/T1361	/	Epson Workforce BK101	
AJE-T1371R	T1371/T1371	/	Epson BK100/BK200	
AJE-ICBK67R	ICBK67/ICBK67	/	Epson PX-BK100	
AJE-T1241R	T1241/T1242/T1243/T1244	/	Epson Stylus NX125/NX420/NX430/NX330/NX230 Epson Workforce 325/320/323	

AJE-T1251R	T1251/T1252/T1253/T1254	/	Epson Stylus NX125/NX625/NX420/NX230 Epson Workforce 520/320/323/325	
AJE-T1261R	T1261/T1262/T1263/T1264	/	Epson Workforce 520/630/635/60/840/545/645/845 Epson Stylus NX430/NX330 Epson WorkForce WF-3520/3540	
AJE-T1271R	T1271/T1272/T1273/T1274	/	Epson Stylus NX625 Epson Workforce 630/635/60/840/545/648/845 Epson WorkForce WF-3520/3540	
AJE-T1281R	T1281/T1282/T1283/T1284	/	Epson Stylus S22/SX125/SX420W/SX425W/SX235W/SX130/SX435W Epson Stylus Office BX305F/BX305FW	
AJE-T1291R	T1291/T1292/T1293/T1294	/	Epson Stylus SX420W/SX425W/SX525WD/SX620FW/SX445/SX235W/SX435W Epson Stylus Office BX305F/BX305FW/BX525WD/BX625FWD/ B42WD/BX925FWD/BX925FW/BX535WD/BX635FWD	
AJE-T1301R	T1301/T1302/T1303/T1304	/	Epson Stylus SX525WD/SX620FW/SX445 Epson Stylus Office BX525WD/BX625FWD/BX925FWD/B42WD/ BX925FW/BX535WD/BX635FWD	
AJE-T1321R	T1321/T1322/T1323/T1324	/	Epson Stylus NX125/N11	
AJE-T1331R	T1331/T1332/T1333/T1334	/	Epson Stylus N11/NX420/NX125/T12/T22/TX120/TX129/ TX420W/TX235/TX235W/NX230/TX130 Epson Workforce 320/435	
AJE-T1351R	T1351/T1332/T1333/T1334	/	Epson Stylus T25/TX125/TX135	
AJE-T1381R	T1381/T1382/T1383/T1384	/	Epson WorkForce 320/630/633/435 Epson Stylus NX420/TX420W/TX235/NX230	
AJE-T1401R	T1401/T1402/T1403/T1404	/	Epson WorkForce 630/633 Epson Stylus Office TX620FWD Epson Stylus TX560WD	
AJE-T1411R	T1411/T1412/T1413/T1414	/	Epson ME 32/33/320/330/35/350 Epson ME Office 560W/620F/960FWD/900WD/535	
AJE-T1731R	T1731/T1732/T1733/T1734	/	Epson ME 35/350	
AJE-T1412R	T1431/T1412/T1413/T1414	/	Epson ME OFFICE 85ND	
AJE-T1431R	T1431/T1432/T1433/T1434	/	Epson ME Office 960FWD/900WD/940FW	
AJE-ICBK61R	ICBK61/ICC62/ICM62/ICY62	/	Epson PX-503A/PX203/603F/PX-675F	
AJE-ICBK62R	ICBK62/ICC62/ICM62/ICY62	/	Epson PX-430A/PX-403A/PX-404A/PX-434A/PX-675F	
AJE-ICC65R	ICBK61/ICC65/ICM65/ICY65	/	EpsonPX-673F/1600F/1200/1700F	
AJE-T1321LR	T1321/T1332/T1333/T1334	/	Epson Stylus TX120/T22	
AJE-T1381LR	T1381/T1332/T1333/T1334	/	Epson Stylus TX420W/TX320F/TX235W	
AJE-T1291NR	T1291/T1291/T1292/T1293/T1294	/	Epson Stylus Office BX320FW	
AJE-T1251NR	T1251/T1251/T1252/T1253/T1254	/	Epson Workforce 520	
AJE-T1381NR	T1381/T1381/T1402/T1403/T1404	/	Epson Stylus Office TX525FW	
AJE-T159AR	T1592/T1590/T1591/T1599	/	Epson Stylus Photo R2000(8 colors)	
AJE-T159BR	T1597/T1598/T1593/T1594	/		
for Epson Japan Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJE-ICBK50/ICC50/ICM50/ICY50/ICLC50/ICLM50	ICBK50/ICC50/ICM50/ICY50/ICLC50/ICLM50	/	Epson PM-G850/PM-G4500/PM-T960 Epson PM-A940/A920/PM-A840S/D870/PM-A840/A820 Epson PM-G860/EP-301/302/EP-774A Epson EP-4004 Epson EP-901F/901A/902A/903A/903F/904F/904A/803AW/705A Epson EP-801A/802A/803A/803AW/702A/703A/804A/804AW/804AR/704A	
AJE-ICBK51/ICC51/ICM51/ICY51/ICLC51/ICLM51	ICBK51/ICC51/ICM51/ICY51/ICLC51/ICLM51	/	Epson EP-703A/704A/705A/774A/803A/803AW/804A/ 804AR/804AW/903A/903F/904A/904F	
AJE-ICBK53/ICC53/ICM53/ICY53/ICMB53/ICR53/ICOR53/ICGL53	ICBK53/ICC53/ICM53/ICY53/ICMB53/ICR53/ICOR53/ICGL53	/	Epson PX-G5300	
AJE-ICBK53/ICMB53/ICC55/ICVM55/ICY55/ICLC55/ ICVLM55/ICGY55/ICLGY55	ICBK53/ICMB53/ICC55/ICVM55/ICY55/ICLC55/ ICVLM55/ICGY55/ICLGY55	/	Epson PX-5600	

AJE-ICBK46/ICC46/ICM46/ICY46	ICBK46/ICC46/ICM46/ICY46	/	Epson PX-A720/A740;FA700;A620/A640 Epson PX-V780;PX-401A/402A;PX-501A;PX-101	
AJE-ICBK56/ICC46/ICM46/ICY46	ICBK56/ICC46/ICM46/ICY46	/	Epson PX-201/502A/601F/602F	
AJE-ICBK59/ICBK59/ICC59/ICM59/ICY59	ICBK59/ICBK59/ICC59/ICM59/ICY59	/	Epson PX-1001	
AJE-ICBK50R	ICBK50/ICC50/ICM50/ICY50/ICLC50/ICLM50	/	Epson PM-G850/D870/PM-G4500/PM-T690/T960 Epson PM-A940/A840/A920/PM-G860/EP-901F Epson PM-A840S/A820/EP-774A/EP-4004 Epson EP-301/302/702A/703A/802A/803A/ 803AW/804A/804AW/804AR/803AW Epson EP-801A/901A/902A/903A/903F/904F/904A/704A	
AJE-ICBK53R	ICBK53/ICC53/ICM53/ICY53/ICMB53/	/	Epson PX-G5300	
AJE-ICMB53R	ICR53/ICOR53/ICGL53	/		
AJE-ICBK46R	ICBK46/ICC46/ICM46/ICY46	/	Epson PX-A720/A740 Epson FA700 Epson A620/A640 Epson PX-401A/402A/501A Epson PX-101/V780	
AJE-ICBK59R	ICBK59/ICBK59/ICC59/ICM59/ICY59	/	Epson PX-1001	
AJE-IC2CL05	IC1BK05/IC5CL05	/	Epson PM-720C/PM-780C/PM-780CS/PM-780CV/PM-790PT Epson PM-800DC/PM-820C/PM-820DC/PM-880C/PM-800C	
AJE-IC5L06	IC5CL06	/	Epson PM-3300C/PM-3500C/PM-3700C Epson PM-870C/PM-890C	
AJE-IC2CL12	IC1BK12/IC3CL12	/	Epson CC-500L/CC-550L	
AJE-IC2CL13	IC1BK13/IC5CL13	/	Epson PM-730C/PM-740C/PM-740DU Epson PM-830C/PM-840C/PM-850PT/PM-860PT	
AJE-IC2CL28	ICBK28/ICCL28	/	Epson CL-760	
AJE-IC2CL29	ICBK29/ICCL29	/	Epson CC-570L	
AJE-IC7CL21	ICBK21/ICC21/ICM21/ICY21/ICLC21/IC LM21/ICDY21	/	Epson PM-930C/PM-940C/PM-950C Epson PM-970C/PM-980C	
AJE-IC4CL22	ICBK22/ICC22/ICM22/ICY22	/	Epson PX-V700/CC-660PX/CC-600PX	
AJE-IC8CL23	ICBK23/ICC23/ICM23/ICY23/ICLC23/ ICLM23/ICGY23/ICMB23	/	Epson PM-4000PX	
AJE-IC4CL31	ICBK31/ICC31/ICM31/ICY31	/	Epson PX-V500/PX-V600/PX-A550	
AJE-IC6CL32	ICBK32/ICC32/ICM32/ICY32/ICLC32/ICLM32	/	Epson PM-A850/A870/A890;PM-D750/D800/D770 Epson PM-G700/G720/G730;PM-G800/G820	
AJE-IC8CL33	ICGL33/ICBK33/ICC33/ICM33/ICY33/ICR33/ICMB33/ICBL33	/	Epson PX-G900/G920/G930/G5000/G5100	
AJE-ICCL34	ICCL34	/	Epson E-100/200;E-100P	
AJE-IC6CL35	ICBK35/ICC35/ICM35/ICY35/ICLC35/ICLM35	/	Epson PM-D1000;PM-A900/A950;BKX-PG1/PG2	
AJE-IC3CL42	ICC42/ICM42/ICY42	/	Epson PX-A650;PX-V630	
AJE-IC6CL47	ICBK47/ICC47/ICM47/ICY47/ICLC47/ICLM47	/	Epson PM-A970;PM-T990	
AJE-IC4CL70	ICBK70/ICC70/ICM70/ICY70	/	Epson GP-710	
AJE-ICCL45	ICCL45	/	Epson PictureMate E-300/300L/330/330S/340/500/520/530/ 600/700/720/800/810	
for Canon VII Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI280XXLPGBK	PGI-280XXLPGBK	NA	Canon PIXMA TR7520 (five colors) Canon PIXMA TR8520 (five colors) Canon PIXMA TS6120 (five colors) Canon PIXMA TS8120 (six colors) Canon PIXMA TS9120 (six colors) Canon PIXMA TS6220 (five colors) Canon PIXMA TS8220 (six colors) Canon PIXMA TS9521C (five colors) Canon PIXMA TS9520 (five colors) Canon PIXMA TS702 (five colors) Canon PIXMA TS9220 (five colors)	
AJC-CLI281XXLBK	CLI-281XXLBK			
AJC-CLI281XXLC	CLI-281XXLC			
AJC-CLI281XXLM	CLI-281XXLM			
AJC-CLI281XXLY	CLI-281XXLY			

AJC-CLI281XXLPB	CLI-281XXLPB		Canon PIXMA TS8320 (six colors) Canon PIXMA TS6320 (five colors)
AJC-BCI380XLPGBK	BCI-380XLPGBK	JPN	Canon PIXUS TS8130 (six colors) Canon PIXUS TS6130 (five colors) Canon PIXUS TR8530 (five colors) Canon PIXUS TR7530 (five colors) Canon PIXUS TS8230 (six colors) Canon PIXUS TS6230 (five colors) Canon PIXUS TR9530 (five colors) Canon PIXUS TR703 (five colors) Canon PIXUS TS8330 (six colors) Canon PIXUS TS7330 (five colors) Canon PIXUS TS6330 (five colors) Canon PIXUS TR703a (five colors) Canon PIXUS TR8630a (five colors)
AJC-BCI381BK	BCI-381BK		
AJC-BCI381C	BCI-381C		
AJC-BCI381M	BCI-381M		
AJC-BCI381Y	BCI-381Y		
AJC-BCI381GY	BCI-381GY		
AJC-BCI381XLBK	BCI-381XLBK		
AJC-BCI381XLC	BCI-381XLC		
AJC-BCI381XLM	BCI-381XLM		
AJC-BCI381XLY	BCI-381XLY		
AJC-BCI381XLY	BCI-381XLY		
AJC-BCI381XLY	BCI-381XLY		
AJC-N10XLPGBK	XKI-N10XLPGBK	JPN	Canon PIXUS XBK50 (six colors) Canon PIXUS XBK60 (six colors) Canon PIXUS XBK70 (six colors) Canon PIXUS XBK80 (six colors) Canon PIXUS XBK90 (six colors)
AJC-N11XLBK	XKI-N11XLBK		
AJC-N11XLC	XKI-N11XLC		
AJC-N11XLM	XKI-N11XLM		
AJC-N11XLY	XKI-N11XLY		
AJC-N11XLPB	XKI-N11XLPB		
AJC-XKIN20PGBK	XKI-N20PGBK	JPN	Canon PIXUS XBK100 (five colors) Canon PIXUS XBK500 (six colors) Canon PIXUS XBK110 (five colors)
AJC-XKIN21BK	XKI-N21BK		
AJC-XKIN21C	XKI-N21C		
AJC-XKIN21M	XKI-N21M		
AJC-XKIN21Y	XKI-N21Y		
AJC-BCI301C	BCI-301C		
AJC-BCI301M	BCI-301M	JPN	Canon PIXUS TS7530 (five colors)
AJC-BCI301Y	BCI-301Y		
AJC-BCI301BK	BCI-301BK		
AJC-BCI300PGBK	BCI-300PGBK		
AJC-BCI331XLC	BCI-331XLC		
AJC-BCI331XLM	BCI-331XLM		
AJC-BCI331XLY	BCI-331XLY	JPN	Canon PIXUS TS8530 (six colors) Canon PIXUS TS8630 (six colors)
AJC-BCI331XLBK	BCI-331XLBK		
AJC-BCI331XLY	BCI-331XLY		
AJC-BCI331XLBK	BCI-331XLBK		
AJC-BCI331XLY	BCI-331XLY		
AJC-BCI330XLPGBK	BCI-330XLPGBK		
AJC-BCI331C	BCI-331C		
AJC-BCI331M	BCI-331M		
AJC-BCI331Y	BCI-331Y		
AJC-BCI331BK	BCI-331BK		
AJC-BCI331GY	BCI-331GY		
AJC-BCI330PGBK	BCI-330PGBK		
AJC-PGI480XXLPGBK	PGI-480XXLPGBK	MEA	Canon PIXMA TS6140 (five colors) Canon PIXMA TS8140 (six colors) Canon PIXMA TS9140 (six colors) Canon PIXMA TR7540 (five colors) Canon PIXMA TR8540 (five colors) Canon PIXMA TS704 (five colors) Canon PIXMA TS8340 (six colors) Canon PIXMA TS6340 (five colors)
AJC-CLI481XXLBK	CLI-481XXLBK		
AJC-CLI481XXLC	CLI-481XXLC		
AJC-CLI481XXLM	CLI-481XXLM		
AJC-CLI481XXLY	CLI-481XXLY		
AJC-CLI481XXLPB	CLI-481XXLPB		



AJC-PGI580XXLPGBK	PGI-580XXLPGBK	EUR	Canon PIXMA TR7550 (five colors) Canon PIXMA TR8550 (five colors) Canon PIXMA TS6150 (five colors) Canon PIXMA TS6151 (five colors) Canon PIXMA TS8150 (six colors) Canon PIXMA TS8151 (six colors) Canon PIXMA TS8152 (six colors) Canon PIXMA TS9150 (six colors) Canon PIXMA TS9155 (six colors) Canon PIXMA TS6250 (five colors) Canon PIXMA TS8250/8251/8252 (six colors) Canon PIXMA TS9550/TS9551C (five colors) Canon PIXMA TS705 (five colors) Canon PIXMA TS8350 (six colors) Canon PIXMA TS6350 (five colors)
AJC-CLI581XXLBK	CLI-581XXLBK		
AJC-CLI581XXLC	CLI-581XXLC		
AJC-CLI581XXLM	CLI-581XXLM		
AJC-CLI581XXLY	CLI-581XXLY		
AJC-CLI581XXLPB	CLI-581XXLPB		
AJC-PGI530PGBK	PGI-530PGBK	EUR	Canon PIXMA TS8750 (six colors) Canon PIXMA TS8751 (six colors)
AJC-CLI531BK	CLI-531BK		
AJC-CLI531C	CLI-531C		
AJC-CLI531M	CLI-531M		
AJC-CLI531Y	CLI-531Y		
AJC-CLI531GY	CLI-531GY		
AJC-PGI680XXLPGBK	PGI-680XXLPGBK	AU	Canon PIXMA TR7560 (five colors) Canon PIXMA TR8560 (five colors) Canon PIXMA TS6160 (five colors) Canon PIXMA TS8160 (six colors) Canon PIXMA TS9160 (six colors) Canon PIXMA TS706 (five colors) Canon PIXMA TS6260 (five colors) Canon PIXMA TS8260 (six colors)
AJC-CLI681XXLBK	CLI-681XXLBK		
AJC-CLI681XXLC	CLI-681XXLC		
AJC-CLI681XXLM	CLI-681XXLM		
AJC-CLI681XXLY	CLI-681XXLY		
AJC-CLI681XXLPB	CLI-681XXLPB		
AJC-PGI780XXLPGBK	PGI-780XXLPGBK	AP	Canon PIXMA TR8570 (five colors) Canon PIXMA TS9170 (six colors) Canon PIXMA TS8170 (six colors) Canon PIXMA TS707 (five colors) Canon PIXMA TS8370 (six colors) Canon PIXMA TS6370 (five colors)
AJC-CLI781XXLBK	CLI-781XXLBK		
AJC-CLI781XLC	CLI-781XLC		
AJC-CLI781XLM	CLI-781XLM		
AJC-CLI781XLY	CLI-781XLY		
AJC-CLI781XXLPB	CLI-781XXLPB		
AJC-PGI880XXLPGBK	PGI-880XXLPGBK	CHN	Canon PIXMA TS9180 (six colors) Canon PIXMA TS8180 (six colors) Canon PIXMA TS6180 (five colors) Canon PIXMA TR8580 (five colors) Canon PIXMA TS8280 (six colors) Canon PIXMA TS6280 (five colors)
AJC-CLI881XXLBK	CLI-881XXLBK		
AJC-CLI881XLC	CLI-881XLC		
AJC-CLI881XLM	CLI-881XLM		
AJC-CLI881XLY	CLI-881XLY		
AJC-CLI881XXLPB	CLI-881XXLPB		
AJC-PGI980XXLPGBK	PGI-980XXLPGBK	KOR	Canon PIXMA TS8190 (six colors) Canon PIXMA TS8195 (six colors)
AJC-CLI981XXLBK	CLI-981XXLBK		
AJC-CLI981XLC	CLI-981XLC		
AJC-CLI981XLM	CLI-981XLM		
AJC-CLI981XLY	CLI-981XLY		
AJC-CLI981XXLPB	CLI-981XXLPB		



for Canon VI Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI170PGBK	PGI-170PGBK	LA	Canon PIXMA MG7710 (six colors including GY) Canon PIXMA MG6810 (five colors) Canon PIXMA MG5710 (five colors)	
AJC-CLI171BK	CLI-171BK			
AJC-CLI171C	CLI-171C			
AJC-CLI171M	CLI-171M			
AJC-CLI171Y	CLI-171Y			
AJC-CLI171GY	CLI-171GY			
AJC-PGI170PGBKXL	PGI-170PGBKXL			
AJC-CLI171BKXL	CLI-171BKXL			
AJC-CLI171CXL	CLI-171CXL			
AJC-CLI171MXL	CLI-171MXL			
AJC-CLI171YXL	CLI-171YXL			
AJC-CLI171GYXL	CLI-171GYXL			
AJC-PGI270PGBK	PGI-270PGBK	NA	Canon PIXMA MG5720 (five colors) Canon PIXMA MG5721 (five colors) Canon PIXMA MG5722 (five colors) Canon PIXMA MG6820 (five colors) Canon PIXMA MG6821 (five colors) Canon PIXMA MG6822 (five colors) Canon PIXMA MG7720 (six colors including GY) Canon PIXMA TS9020/TS8020 (six colors including GY) Canon PIXMA TS6020/TS5020 (five colors)	
AJC-CLI271BK	CLI-271BK			
AJC-CLI271C	CLI-271C			
AJC-CLI271M	CLI-271M			
AJC-CLI271Y	CLI-271Y			
AJC-CLI271GY	CLI-271GY			
AJC-PGI270PGBKXL	PGI-270PGBKXL			
AJC-CLI271BKXL	CLI-271BKXL			
AJC-CLI271CXL	CLI-271CXL			
AJC-CLI271MXL	CLI-271MXL			
AJC-CLI271YXL	CLI-271YXL			
AJC-CLI271GYXL	CLI-271GYXL			
AJC-BCI370PGBK	BCI-370PGBK	JPN	Canon PIXUS MG7730 (six colors including GY) Canon PIXUS MG6930 (six colors including GY) Canon PIXUS MG5730 (five colors) Canon PIXUS TS9030/TS8030 (six colors including GY) Canon PIXUS TS6030/TS5030 (five colors)	
AJC-BCI371BK	BCI-371BK			
AJC-BCI371C	BCI-371C			
AJC-BCI371M	BCI-371M			
AJC-BCI371Y	BCI-371Y			
AJC-BCI371GY	BCI-371GY			
AJC-BCI370PGBKXL	BCI-370PGBKXL			
AJC-BCI371BKXL	BCI-371BKXL			
AJC-BCI371CXL	BCI-371CXL			
AJC-BCI371MXL	BCI-371MXL			
AJC-BCI371YXL	BCI-371YXL			
AJC-BCI371GYXL	BCI-371GYXL			
AJC-PGI470PGBK	PGI-470PGBK	MEA	Canon PIXMA MG7740 (six colors including GY) Canon PIXMA MG6840 (five colors) Canon PIXMA MG5740 (five colors)	
AJC-CLI471BK	CLI-471BK			
AJC-CLI471C	CLI-471C			
AJC-CLI471M	CLI-471M			
AJC-CLI471Y	CLI-471Y			
AJC-CLI471GY	CLI-471GY			
AJC-PGI470PGBKXL	PGI-470PGBKXL			
AJC-CLI471BKXL	CLI-471BKXL			
AJC-CLI471CXL	CLI-471CXL			
AJC-CLI471MXL	CLI-471MXL			
AJC-CLI471YXL	CLI-471YXL			
AJC-CLI471GYXL	CLI-471GYXL			

AJC-PGI570PGBK	PGI-570PGBK	EUR	Canon PIXMA MG5750 (five colors) Canon PIXMA MG5751 (five colors) Canon PIXMA MG5752 (five colors) Canon PIXMA MG5753 (five colors) Canon PIXMA MG6850 (five colors) Canon PIXMA MG6851 (five colors) Canon PIXMA MG6852 (five colors) Canon PIXMA MG6853 (five colors) Canon PIXMA MG7750 (six colors including GY) Canon PIXMA MG7751 (six colors including GY) Canon PIXMA MG7752 (six colors including GY) Canon PIXMA MG7753 (six colors including GY) Canon PIXMA TS9050/9055/8050/8051/8052/8053(six colors including GY) Canon PIXMA TS6050/6051/6052/5050/5051/5052/5053 (five colors)
AJC-CLI571BK	CLI-571BK		
AJC-CLI571C	CLI-571C		
AJC-CLI571M	CLI-571M		
AJC-CLI571Y	CLI-571Y		
AJC-CLI571GY	CLI-571GY		
AJC-PGI570PGBKXL	PGI-570PGBKXL		
AJC-CLI571BKXL	CLI-571BKXL		
AJC-CLI571CXL	CLI-571CXL		
AJC-CLI571MXL	CLI-571MXL		
AJC-CLI571YXL	CLI-571YXL		
AJC-CLI571GYXL	CLI-571GYXL		
AJC-PGI670PGBK	PGI-670PGBK	AUS	Canon PIXMA MG7760 (six colors including GY) Canon PIXMA MG7765 (six colors including GY) Canon PIXMA MG7766 (six colors including GY) Canon PIXMA MG6860 (five colors) Canon PIXMA MG5760 (five colors) Canon PIXMA MG6865 (five colors) Canon PIXMA MG5765 (five colors) Canon PIXMA TS6060/TS5060 (five colors)
AJC-CLI671BK	CLI-671BK		
AJC-CLI671C	CLI-671C		
AJC-CLI671M	CLI-671M		
AJC-CLI671Y	CLI-671Y		
AJC-CLI671GY	CLI-671GY		
AJC-PGI670PGBKXL	PGI-670PGBKXL		
AJC-CLI671BKXL	CLI-671BKXL		
AJC-CLI671CXL	CLI-671CXL		
AJC-CLI671MXL	CLI-671MXL		
AJC-CLI671YXL	CLI-671YXL		
AJC-CLI671GYXL	CLI-671GYXL		
AJC-PGI770PGBK	PGI-770PGBK	AP	Canon PIXMA MG7770 (six colors including GY) Canon PIXMA MG6870 (five colors) Canon PIXMA MG5770 (five colors)
AJC-CLI771BK	CLI-771BK		
AJC-CLI771C	CLI-771C		
AJC-CLI771M	CLI-771M		
AJC-CLI771Y	CLI-771Y		
AJC-CLI771GY	CLI-771GY		
AJC-PGI770PGBKXL	PGI-770PGBKXL		
AJC-CLI771BKXL	CLI-771BKXL		
AJC-CLI771CXL	CLI-771CXL		
AJC-CLI771MXL	CLI-771MXL		
AJC-CLI771YXL	CLI-771YXL		
AJC-CLI771GYXL	CLI-771GYXL		
AJC-PGI870PGBK	PGI-870PGBK	CHN	Canon PIXMA MG7780 (six colors including GY) Canon PIXMA MG6880 (five colors) Canon PIXMA MG5780 (five colors) Canon PIXMA TS9080/TS8080 (six colors including GY) Canon PIXMA TS6080/TS5080 (five colors)
AJC-CLI871BK	CLI-871BK		
AJC-CLI871C	CLI-871C		
AJC-CLI871M	CLI-871M		
AJC-CLI871Y	CLI-871Y		
AJC-CLI871GY	CLI-871GY		
AJC-PGI870PGBKXL	PGI-870PGBKXL		
AJC-CLI871BKXL	CLI-871BKXL		
AJC-CLI871CXL	CLI-871CXL		
AJC-CLI871MXL	CLI-871MXL		
AJC-CLI871YXL	CLI-871YXL		
AJC-CLI871GYXL	CLI-871GYXL		



AJC-PGI970PGBK	PGI-970PGBK	KOR	Canon PIXMA MG7790 (six colors including GY) Canon PIXMA MG5795 (five colors) Canon PIXMA MG5790 (five colors) Canon PIXMA TS5090 (five colors)	
AJC-CLI971BK	CLI-971BK			
AJC-CLI971C	CLI-971C			
AJC-CLI971M	CLI-971M			
AJC-CLI971Y	CLI-971Y			
AJC-CLI971GY	CLI-971GY			
AJC-PGI970PGBKXL	PGI-970PGBKXL			
AJC-CLI971BKXL	CLI-971BKXL			
AJC-CLI971CXL	CLI-971CXL			
AJC-CLI971MXL	CLI-971MXL			
AJC-CLI971YXL	CLI-971YXL			
AJC-CLI971GYXL	CLI-971GYXL			
AJC-PFI1000BL	PFI1000BL	WW	Canon imagePROGRAF PRO-1000	
AJC-PFI1000C	PFI1000C			
AJC-PFI1000CO	PFI1000CO			
AJC-PFI1000GY	PFI1000GY			
AJC-PFI1000M	PFI1000M			
AJC-PFI1000MBK	PFI1000MBK			
AJC-PFI1000PBK	PFI1000PBK			
AJC-PFI1000PC	PFI1000PC			
AJC-PFI1000PGY	PFI1000PGY			
AJC-PFI1000PM	PFI1000PM			
AJC-PFI1000R	PFI1000R			
AJC-PFI1000Y	PFI1000Y			
AJC-PFI57B	PFI57B	CHN	Canon imagePROGRAF PRO-520/PRO-540/PRO-540S/PRO-560s	
AJC-PFI57C	PFI57C			
AJC-PFI57CO	PFI57CO			
AJC-PFI57GY	PFI57GY			
AJC-PFI57M	PFI57M			
AJC-PFI57MBK	PFI57MBK			
AJC-PFI57PBK	PFI57PBK			
AJC-PFI57PC	PFI57PC			
AJC-PFI57PGY	PFI57PGY			
AJC-PFI57PM	PFI57PM			
AJC-PFI57R	PFI57R			
AJC-PFI57Y	PFI57Y			
for Canon VI Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI170PGBKXLR	PGI-170PGBKXL	LA	Canon PIXMA MG7710 (six colors including GY) Canon PIXMA MG6810 (five colors) Canon PIXMA MG5710 (five colors)	
AJC-CLI171BKXLR	CLI-171BKXL			
AJC-CLI171CXLR	CLI-171CXL			
AJC-CLI171MXLR	CLI-171MXL			
AJC-CLI171YXLR	CLI-171YXL			
AJC-CLI171GYXLR	CLI-171GYXL			
AJC-PGI270PGBKXLR	PGI-270PGBKXL	NA	Canon PIXMA MG5720 (five colors) Canon PIXMA MG5721 (five colors) Canon PIXMA MG5722 (five colors) Canon PIXMA MG6820 (five colors) Canon PIXMA MG6821 (five colors) Canon PIXMA MG6822 (five colors) Canon PIXMA MG7720 (six colors including GY) Canon PIXMA TS9020/TS8020 (six colors including GY) Canon PIXMA TS6020/TS5020 (five colors)	
AJC-CLI271BKXLR	CLI-271BKXL			
AJC-CLI271CXLR	CLI-271CXL			
AJC-CLI271MXLR	CLI-271MXL			
AJC-CLI271YXLR	CLI-271YXL			
AJC-CLI271GYXLR	CLI-271GYXL			

AJC-BCI370PGBKXLR	BCI-370PGBKXL	JPN	Canon PIXUS MG7730 (six colors including GY) Canon PIXUS MG6930 (six colors including GY) Canon PIXUS MG5730 (five colors) Canon PIXUS TS9030/TS8030 (six colors including GY) Canon PIXUS TS6030/TS5030 (five colors)
AJC-BCI371BKXLR	BCI-371BKXL		
AJC-BCI371CXLR	BCI-371CXL		
AJC-BCI371MXLR	BCI-371MXL		
AJC-BCI371YXLR	BCI-371YXL		
AJC-BCI371GYXLR	BCI-371GYXL		
AJC-PGI470PGBKXLR	PGI-470PGBKXL	MEA	Canon PIXMA MG7740 (six colors including GY) Canon PIXMA MG6840 (five colors) Canon PIXMA MG5740 (five colors)
AJC-CLI471BKXLR	CLI-471BKXL		
AJC-CLI471CXLR	CLI-471CXL		
AJC-CLI471MXLR	CLI-471MXL		
AJC-CLI471YXLR	CLI-471YXL		
AJC-CLI471GYXLR	CLI-471GYXL		
AJC-PGI570PGBKXLR	PGI-570PGBKXL	EUR	Canon PIXMA MG5750 (five colors) Canon PIXMA MG5751 (five colors) Canon PIXMA MG5752 (five colors) Canon PIXMA MG5753 (five colors) Canon PIXMA MG6850 (five colors) Canon PIXMA MG6851 (five colors) Canon PIXMA MG6852 (five colors) Canon PIXMA MG6853 (five colors) Canon PIXMA MG7750 (six colors including GY) Canon PIXMA MG7751 (six colors including GY) Canon PIXMA MG7752 (six colors including GY) Canon PIXMA MG7753 (six colors including GY) Canon PIXMA TS9050/9055/8050/8051/8052/8053 (six colors including GY) Canon PIXMA TS6050/6051/6052/5050/5051/5052/5053 (five colors)
AJC-CLI571BKXLR	CLI-571BKXL		
AJC-CLI571CXLR	CLI-571CXL		
AJC-CLI571MXLR	CLI-571MXL		
AJC-CLI571YXLR	CLI-571YXL		
AJC-CLI571GYXLR	CLI-571GYXL		
AJC-PGI670PGBKXLR	PGI-670PGBKXL		
AJC-CLI671BKXLR	CLI-671BKXL		
AJC-CLI671CXLR	CLI-671CXL	AUS	Canon PIXMA MG7760 (six colors including GY) Canon PIXMA MG7765 (six colors including GY) Canon PIXMA MG7766 (six colors including GY) Canon PIXMA MG6860 (five colors) Canon PIXMA MG5760 (five colors) Canon PIXMA MG6865 (five colors) Canon PIXMA MG5765 (five colors) Canon PIXMA TS6060/TS5060 (five colors)
AJC-CLI671MXLR	CLI-671MXL		
AJC-CLI671YXLR	CLI-671YXL		
AJC-CLI671GYXLR	CLI-671GYXL		
AJC-PGI770PGBKXLR	PGI-770PGBKXL		
AJC-CLI771BKXLR	CLI-771BKXL		
AJC-CLI771CXLR	CLI-771CXL	AP	Canon PIXMA MG7770 (six colors including GY) Canon PIXMA MG6870 (five colors) Canon PIXMA MG5770 (five colors)
AJC-CLI771MXLR	CLI-771MXL		
AJC-CLI771YXLR	CLI-771YXL		
AJC-CLI771GYXLR	CLI-771GYXL		
AJC-PGI870PGBKXLR	PGI-870PGBKXL		
AJC-CLI871BKXLR	CLI-871BKXL		
AJC-CLI871CXLR	CLI-871CXL	CHN	Canon PIXMA MG7780 (six colors including GY) Canon PIXMA MG6880 (five colors) Canon PIXMA MG5780 (five colors) Canon PIXMA TS9080/TS8080 (six colors including GY) Canon PIXMA TS6080/TS5080 (five colors)
AJC-CLI871MXLR	CLI-871MXL		
AJC-CLI871YXLR	CLI-871YXL		
AJC-CLI871GYXLR	CLI-871GYXL		
AJC-PGI970PGBKXLR	PGI-970PGBKXL		
AJC-CLI971BKXLR	CLI-971BKXL		
AJC-CLI971CXLR	CLI-971CXL	KOR	Canon PIXMA MG7790 (six colors including GY) Canon PIXMA MG5795 (five colors) Canon PIXMA MG5790 (five colors) Canon PIXMA TS5090 (five colors)
AJC-CLI971MXLR	CLI-971MXL		
AJC-CLI971YXLR	CLI-971YXL		
AJC-CLI971GYXLR	CLI-971GYXL		





AJC-PFI1000BLR	PFI1000BL	WW	Canon imagePROGRAF PRO-1000	
AJC-PFI1000CR	PFI1000C			
AJC-PFI1000COR	PFI1000CO			
AJC-PFI1000GYR	PFI1000GY			
AJC-PFI1000MR	PFI1000M			
AJC-PFI1000MBKR	PFI1000MBK			
AJC-PFI1000PBKR	PFI1000PBK			
AJC-PFI1000PCR	PFI1000PC			
AJC-PFI1000PGYR	PFI1000PGY			
AJC-PFI1000PMR	PFI1000PM			
AJC-PFI1000RR	PFI1000R			
AJC-PFI1000YR	PFI1000Y			
For Canon V Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI2100BK	PGI2100BK	LA	Canon MAXIFY MB5310/Ib4010 (LA)	
AJC-PGI2100C	PGI2100C			
AJC-PGI2100M	PGI2100M			
AJC-PGI2100Y	PGI2100Y			
AJC-PGI2100BKXL	PGI2100BKXL			
AJC-PGI2100CXL	PGI2100CXL			
AJC-PGI2100MXL	PGI2100MXL			
AJC-PGI2100YXL	PGI2100YXL			
AJC-PGI1100BK	PGI1100BK		Canon MAXIFY MB2010 (LA)	
AJC-PGI1100C	PGI1100C			
AJC-PGI1100M	PGI1100M			
AJC-PGI1100Y	PGI1100Y			
AJC-PGI1100BKXL	PGI1100BKXL			
AJC-PGI1100CXL	PGI1100CXL			
AJC-PGI1100MXL	PGI1100MXL			
AJC-PGI1100YXL	PGI1100YXL			
AJC-PGI1200BK	PGI1200BK	NA	Canon MAXIFY MB2020/MB2320 /MB2120/MB2720 (USA)	
AJC-PGI1200C	PGI1200C			
AJC-PGI1200M	PGI1200M			
AJC-PGI1200Y	PGI1200Y			
AJC-PGI1200BKXL	PGI1200BKXL			
AJC-PGI1200CXL	PGI1200CXL			
AJC-PGI1200MXL	PGI1200MXL			
AJC-PGI1200YXL	PGI1200YXL			
AJC-PGI2200BK	PGI2200BK		Canon MAXIFY MB5020/MB5320/iB4020/MB5120/MB5420/iB4120 (USA)	
AJC-PGI2200C	PGI2200C			
AJC-PGI2200M	PGI2200M			
AJC-PGI2200Y	PGI2200Y			
AJC-PGI2200BKXL	PGI2200BKXL			
AJC-PGI2200CXL	PGI2200CXL			
AJC-PGI2200MXL	PGI2200MXL			
AJC-PGI2200YXL	PGI2200YXL			
AJC-PGI1300BKXL	PGI1300BKXL	JPN	Canon MAXIFY MB2330/MB2030/MB2130/MB2730 (JA)	
AJC-PGI1300CXL	PGI1300CXL			
AJC-PGI1300MXL	PGI1300MXL			
AJC-PGI1300YXL	PGI1300YXL			
AJC-PGI1300BK	PGI1300BK			
AJC-PGI1300C	PGI1300C			
AJC-PGI1300M	PGI1300M			
AJC-PGI1300Y	PGI1300Y			

AJC-PGI2300BKXL	PGI2300BKXL
AJC-PGI2300CXL	PGI2300CXL
AJC-PGI2300MXL	PGI2300MXL
AJC-PGI2300YXL	PGI2300YXL
AJC-PGI2300BK	PGI2300BK
AJC-PGI2300C	PGI2300C
AJC-PGI2300M	PGI2300M
AJC-PGI2300Y	PGI2300Y
AJC-PGI1400BKXL	PGI1400BKXL
AJC-PGI1400CXL	PGI1400CXL
AJC-PGI1400MXL	PGI1400MXL
AJC-PGI1400YXL	PGI1400YXL
AJC-PGI2400BKXL	PGI2400BKXL
AJC-PGI2400CXL	PGI2400CXL
AJC-PGI2400MXL	PGI2400MXL
AJC-PGI2400YXL	PGI2400YXL
AJC-PGI1500BKXL	PGI1500BKXL
AJC-PGI1500CXL	PGI1500CXL
AJC-PGI1500MXL	PGI1500MXL
AJC-PGI1500YXL	PGI1500YXL
AJC-PGI2500BKXL	PGI2500BKXL
AJC-PGI2500CXL	PGI2500CXL
AJC-PGI2500MXL	PGI2500MXL
AJC-PGI2500YXL	PGI2500YXL
AJC-PGI1600BK	PGI1600BK
AJC-PGI1600C	PGI1600C
AJC-PGI1600M	PGI1600M
AJC-PGI1600Y	PGI1600Y
AJC-PGI1600BKXL	PGI1600BKXL
AJC-PGI1600CXL	PGI1600CXL
AJC-PGI1600MXL	PGI1600MXL
AJC-PGI1600YXL	PGI1600YXL
AJC-PGI2600BK	PGI2600BK
AJC-PGI2600C	PGI2600C
AJC-PGI2600M	PGI2600M
AJC-PGI2600Y	PGI2600Y
AJC-PGI2600BKXL	PGI2600BKXL
AJC-PGI2600CXL	PGI2600CXL
AJC-PGI2600MXL	PGI2600MXL
AJC-PGI2600YXL	PGI2600YXL
AJC-PGI2700BK	PGI-2700BK
AJC-PGI2700C	PGI-2700C
AJC-PGI2700M	PGI-2700M
AJC-PGI2700Y	PGI-2700Y
AJC-PGI2700BKXL	PGI-2700XLBK
AJC-PGI2700CXL	PGI-2700XLC
AJC-PGI2700MXL	PGI-2700XLM
AJC-PGI2700YXL	PGI-2700XLY
AJC-PGI2800BK	PGI-2800BK
AJC-PGI2800C	PGI-2800C
AJC-PGI2800M	PGI-2800M
AJC-PGI2800Y	PGI-2800Y
AJC-PGI2800BKXL	PGI-2800XLBK
AJC-PGI2800CXL	PGI-2800XLC
AJC-PGI2800MXL	PGI-2800XLM
AJC-PGI2800YXL	PGI-2800XLY

JF14

MEA

EUR

AUS

AP

CHN

Canon MAXIFY MB5030/MB5330/iB4030/MB5130/MB5430/iB4130(JA)
Canon MAXIFY MB2340/MB2040/MB2140/MB2740 (ME)
Canon MAXIFY iB4040/MB5040/MB5340/MB5140/MB5440/iB4140 (ME)
Canon MAXIFY MB2050/MB2350/MB2150/MB2750 (EUR)
Canon MAXIFY iB4050/MB5050/MB5350/MB5150/MB5450/iB4150 (EUR)
Canon MAXIFY iB4060/MB2060/MB2360 (AU)
Canon MAXIFY MB5060/MB5360 (AU)
Canon MAXIFY MB5370 (AP) Canon MAXIFY MB5070 Canon MAXIFY iB4070/MB5170/MB5470/iB4170
Canon MAXIFY MB5080 (CHN) Canon MAXIFY iB4080/MB5180/MB5480/iB4180



AJC-PGI1900BKXL COMING SOON!	PGI-1900XLBK	KOR	Canon MB2090 Canon MB2390 (BKOR)	
AJC-PGI1900CXL COMING SOON!	PGI-1900XLC			
AJC-PGI1900MXL COMING SOON!	PGI-1900XLM			
AJC-PGI1900YXL COMING SOON!	PGI-1900XLY			
AJC-PGI1900BK	PGI-1900BK			
AJC-PGI1900C	PGI-1900C			
AJC-PGI1900M	PGI-1900M			
AJC-PGI1900Y	PGI-1900Y			
AJC-PGI2900BK	PGI-2900BK		Canon MAXIFY iB4090/MB5090/MB5390 (BKOR)	
AJC-PGI2900C	PGI-2900C			
AJC-PGI2900M	PGI-2900M			
AJC-PGI2900Y	PGI-2900Y			
AJC-PGI2900BKXL	PGI2900BKXL			
AJC-PGI2900CXL	PGI2900CXL			
AJC-PGI2900MXL	PGI2900MXL			
AJC-PGI2900YXL	PGI2900YXL			
For Canon V Series CISS Chips				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI1100BKR	PGI1100BK	LA	Canon MAXIFY MB2010 (LA)	
AJC-PGI1100CR	PGI1100C			
AJC-PGI1100MR	PGI1100M			
AJC-PGI1100YR	PGI1100Y			
AJC-PGI1100BKXL	PGI1100BKXL			
AJC-PGI1100CXL	PGI1100CXL			
AJC-PGI1100MXL	PGI1100MXL			
AJC-PGI1100YXL	PGI1100YXL			
AJC-PGI2100BKR	PGI2100BK		Canon MAXIFY MB5310/iB4010 (LA)	
AJC-PGI2100CR	PGI2100C			
AJC-PGI2100MR	PGI2100M			
AJC-PGI2100YR	PGI2100Y			
AJC-PGI2100BKXL	PGI2100BKXL			
AJC-PGI2100CXL	PGI2100CXL			
AJC-PGI2100MXL	PGI2100MXL			
AJC-PGI2100YXL	PGI2100YXL			
AJC-PGI1200BKR	PGI1200BKR	NA	Canon MAXIFY MB2020/MB2320/MB2120/MB2720 (USA)	
AJC-PGI1200CR	PGI1200CR			
AJC-PGI1200MR	PGI1200MR			
AJC-PGI1200YR	PGI1200YR			
AJC-PGI1200BKXL	PGI1200BKXL			
AJC-PGI1200CXL	PGI1200CXL			
AJC-PGI1200MXL	PGI1200MXL			
AJC-PGI1200YXL	PGI1200YXL			
AJC-PGI2200BKR	PGI2200BKR		Canon MAXIFY MB5020/MB5320/iB4020/MB5120/MB5420/iB4120 (USA)	
AJC-PGI2200CR	PGI2200CR			
AJC-PGI2200MR	PGI2200MR			
AJC-PGI2200YR	PGI2200YR			
AJC-PGI2200BKXL	PGI2200BKXL			
AJC-PGI2200CXL	PGI2200CXL			
AJC-PGI2200MXL	PGI2200MXL			
AJC-PGI2200YXL	PGI2200YXL			

AJC-PG1300BKXLR	PGI1300BKXLR	JPN	Canon MAXIFY MB2330/MB2030/MB2130/MB2730 (JA)
AJC-PG1300CXLR	PGI1300CXLR		
AJC-PG1300MXLR	PGI1300MXLR		
AJC-PG1300YXLR	PGI1300YXLR		
AJC-PG1300BKR	PGI1300BKR		
AJC-PG1300CR	PGI1300CR		
AJC-PG1300MR	PGI1300MR		
AJC-PG1300YR	PGI1300YR		
AJC-PG12300BKXLR	PGI2300BKXLR		
AJC-PG12300CXLR	PGI2300CXLR		
AJC-PG12300MXLR	PGI2300MXLR		
AJC-PG12300YXLR	PGI2300YXLR		
AJC-PG12300BKR	PGI2300BKR		
AJC-PG12300CR	PGI2300CR		
AJC-PG12300MR	PGI2300MR		
AJC-PG12300YR	PGI2300YR		
AJC-PG1400BKXLR SAMPLE!	PGI1400BKXLR	MEA	Canon MAXIFY MB2340/MB2040/MB2140/MB2740 (ME)
AJC-PG1400CXLR SAMPLE!	PGI1400CXLR		
AJC-PG1400MXLR SAMPLE!	PGI1400MXLR		
AJC-PG1400YXLR SAMPLE!	PGI1400YXLR		
AJC-PG12400BKXLR SAMPLE!	PGI2400BKXLR		Canon MAXIFY iB4040/MB5040/MB5340/MB5140/MB5440/iB4140 (ME)
AJC-PG12400CXLR SAMPLE!	PGI2400CXLR		
AJC-PG12400MXLR SAMPLE!	PGI2400MXLR		
AJC-PG12400YXLR SAMPLE!	PGI2400YXLR		
AJC-PG1500BKXLR	PGI1500BKXLR	EUR	Canon MAXIFY MB2050/MB2350/MB2150/MB2750 (EU)
AJC-PG1500CXLR	PGI1500CXLR		
AJC-PG1500MXLR	PGI1500MXLR		
AJC-PG1500YXLR	PGI1500YXLR		
AJC-PG12500BKXLR	PGI2500BKXLR		
AJC-PG12500CXLR	PGI2500CXLR		
AJC-PG12500MXLR	PGI2500MXLR	AUS	Canon MAXIFY iB4050/MB5050/MB5350/MB5150/MB5450/iB4150 (EU)
AJC-PG12500YXLR	PGI2500YXLR		
AJC-PG1600BKXLR SAMPLE!	PGI1600BKXLR	AP	Canon MAXIFY MB5370 (AP) Canon MAXIFY MB5070 Canon MAXIFY iB4070/MB5170/MB5470/iB4170
AJC-PG1600CXLR SAMPLE!	PGI1600CXLR		
AJC-PG1600MXLR SAMPLE!	PGI1600MXLR		
AJC-PG1600YXLR SAMPLE!	PGI1600YXLR		
AJC-PG12700BKR SAMPLE!	PGI2700BKR	CHN	Canon MAXIFY MB5080 (CHN) Canon MAXIFY iB4080/MB5180/MB5480/iB4180
AJC-PG12700CR SAMPLE!	PGI2700CR		
AJC-PG12700MR SAMPLE!	PGI2700MR		
AJC-PG12700YR SAMPLE!	PGI2700YR		
AJC-PG12700BKXLR SAMPLE!	PGI2700BKXLR		
AJC-PG12700CXLR SAMPLE!	PGI2700CXLR		
AJC-PG12700MXLR SAMPLE!	PGI2700MXLR		
AJC-PG12700YXLR SAMPLE!	PGI2700YXLR		
AJC-PG12800BKR SAMPLE!	PGI2800BKR		
AJC-PG12800CR SAMPLE!	PGI2800CR		
AJC-PG12800MR SAMPLE!	PGI2800MR		
AJC-PG12800YR SAMPLE!	PGI2800YR		
AJC-PG12800BKXLR SAMPLE!	PGI2800BKXLR		
AJC-PG12800CXLR SAMPLE!	PGI2800CXLR		
AJC-PG12800MXLR SAMPLE!	PGI2800MXLR		
AJC-PG12800YXLR SAMPLE!	PGI2800YXLR		



AJC-PGI1900BKR SAMPLE!	PGI1900BKR	KOR	Canon MB2090 Canon MB2390 (BKOR)		
AJC-PGI1900CR SAMPLE!	PGI1900CR				
AJC-PGI1900MR SAMPLE!	PGI1900MR				
AJC-PGI1900YR SAMPLE!	PGI1900YR				
AJC-PGI1900BKXLR SAMPLE!	PGI1900BKXLR				
AJC-PGI1900CXLR SAMPLE!	PGI1900CXLR				
AJC-PGI1900MXLR SAMPLE!	PGI1900MXLR				
AJC-PGI1900YXLR SAMPLE!	PGI1900YXLR				
AJC-PGI2900BKR SAMPLE!	PGI2900BKR		Canon MAXIFY iB4090/MB5090/MB5390 (BKOR)		
AJC-PGI2900CR SAMPLE!	PGI2900CR				
AJC-PGI2900MR SAMPLE!	PGI2900MR				
AJC-PGI2900YR SAMPLE!	PGI2900YR				
AJC-PGI2900BKXLR	PGI2900BKXLR				
AJC-PGI2900CXLR	PGI2900CXLR				
AJC-PGI2900MXLR	PGI2900MXLR				
AJC-PGI2900YXLR	PGI2900YXLR				
For Canon V Series Universal Chips					
Product Code	OEM Product Code	Region	For Use in Printers		Chip Photo
AJC-PGI1U00BK	PGI1X00BK	WW	Canon MAXIFY MB20X0/MB23X0/MB21X0/MB27X0		
AJC-PGI1U00C	PGI1X00C				
AJC-PGI1U00M	PGI1X00M				
AJC-PGI1U00Y	PGI1X00Y				
AJC-PGI1U00BKXL	PGI1X00BKXL				
AJC-PGI1U00CXL	PGI1X00CXL				
AJC-PGI1U00MXL	PGI1X00MXL		Canon MAXIFY MB50X0/MB53X0/MB51X0/MB54X0/IB41X0		
AJC-PGI1U00YXL	PGI1X00YXL				
AJC-PGI2U00BK	PGI2X00BK				
AJC-PGI2U00C	PGI2X00C				
AJC-PGI2U00M	PGI2X00M				
AJC-PGI2U00Y	PGI2X00Y				
AJC-PGI2U00BKXL	PGI2X00BKXL		Canon MAXIFY MB20X0/MB23X0/MB21X0/MB27X0		
AJC-PGI2U00CXL	PGI2X00CXL				
AJC-PGI2U00MXL	PGI2X00MXL				
AJC-PGI2U00YXL	PGI2X00YXL				
AJC-PGI1U00BKXLR	PGI1X00BKXLR		Canon MAXIFY MB50X0/MB53X0/MB51X0/MB54X0/IB41X0		
AJC-PGI1U00CXLR	PGI1X00CXLR				
AJC-PGI1U00MXLR	PGI1X00MXLR				
AJC-PGI1U00YXLR	PGI1X00YXLR				
AJC-PGI2U00BKXLR	PGI2X00BKXLR				
AJC-PGI2U00CXLR	PGI2X00CXLR				
AJC-PGI2U00MXLR	PGI2X00MXLR				
AJC-PGI2U00YXLR	PGI2X00YXLR				

For Canon IV Series Universal Chips				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGIU50PGBK	PGIX50PGBK	WW	Canon PIXMA IP72X0 Canon PIXMA MG54X0 Canon MG64X0/MG55X0/MG56X0/IX68X0 Canon PIXMA MX72X (Applied to PGBBKXXL) Canon PIXMA MX92X (Applied to PGBBKXXL) Canon PIXMA MG63X0/MG71X0 (six color, GY can only applied to this model)	
AJC-CLIU51BK	CLIX51BK			
AJC-CLIU51C	CLIX51C			
AJC-CLIU51M	CLIX51M			
AJC-CLIU51Y	CLIX51Y			
AJC-CLIU51GY	CLIX51GY			
AJC-PGIU50PGBKXL	PGIX50PGBKXL			
AJC-CLIU51BKXL	CLIX51BKXL			
AJC-CLIU51CXL	CLIX51CXL			
AJC-CLIU51MXL	CLIX51MXL			
AJC-CLIU51YXL	CLIX51YXL			
AJC-CLIU51GYXL	CLIX51GYXL			
AJC-PGIU55PGBKXXL	PGIX55PGBKXXL			
AJC-PGIU50PGBKXLR	PGIX50PGBKXLR			
AJC-CLIU51BKXLR	CLIX51BKXLR			
AJC-CLIU51CXLR	CLIX51CXLR			
AJC-CLIU51MXLR	CLIX51MXLR			
AJC-CLIU51YXLR	CLIX51YXLR			
AJC-CLIU51GYXLR	CLIX51GYXLR			
AJC-PGIU55PGBKXXLR	PGIX55PGBKXXLR			
for Canon IV Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI150PGBKXL	PGI-150PGBK XL	LA	Canon PIXMA IP7210 Canon PIXMA MG5410 Canon PIXMA MX921	
AJC-CLI151BKXL	CLI-151BK XL			
AJC-CLI151CXL	CLI-151C XL			
AJC-CLI151MXL	CLI-151M XL			
AJC-CLI151YXL	CLI-151Y XL			
AJC-CLI151GYXL	CLI-151GY XL		Canon PIXMA MG6310	
AJC-PGI250PGBK	PGI-250PGBK	NA	Canon PIXMA ip7220/8720 Canon PIXMA MG5420 Canon PIXMA MX922 Canon PIXMA MX722 Canon PIXMA IX6820 Canon MG5520/MG5620/MG6420/MG6620	
AJC-CLI251BK	CLI-251BK			
AJC-CLI251C	CLI-251C			
AJC-CLI251M	CLI-251M			
AJC-CLI251Y	CLI-251Y			
AJC-CLI251GY	CLI-251GY		Canon PIXMA MG6320/MG7520	
AJC-PGI250PGBKXL	PGI-250PGBK XL		Canon PIXMA ip7220/8720 Canon PIXMA MG5420 Canon PIXMA MX922 Canon PIXMA MX722 Canon PIXMA IX6820 Canon MG5520/MG5620/MG6420/MG6620	
AJC-CLI251BKXL	CLI-251BK XL			
AJC-CLI251CXL	CLI-251C XL			
AJC-CLI251MXL	CLI-251M XL			
AJC-CLI251YXL	CLI-251Y XL			
AJC-CLI251GYXL	CLI-251GY XL		Canon PIXMA MG6320/MG7520	
AJC-PGI255PGBKXXL	PGI-255PGBK XXL		Canon PIXMA MX922	
AJC-BCI350PGBKXL	BCI-350PGBK XL	JPN	Canon PIXUS ip7230/ip8730 Canon PIXUS MG5430/MG5630 Canon PIXUS MX923 Canon PIXUS MX723 Canon PIXUS MG5530/IX6830	
AJC-BCI351BKXL	BCI-351BK XL			
AJC-BCI351CXL	BCI-351C XL			
AJC-BCI351MXL	BCI-351M XL			
AJC-BCI351YXL	BCI-351Y XL			
AJC-BCI351GYXL	BCI-351GY XL		Canon PIXUS MG7530F/MG7530/MG7130/MG6730/MG6530/MG6330/IP8730	
AJC-BCI355PGBKXXL	BCI-355PGBK XXL		Canon PIXMA MX723/MX923	

AJC-PGI450PGBK	PGI-450PGBK	MEA	Canon PIXMA ip7240 Canon PIXMA MG5440		
AJC-CLI451BK	CLI-451BK				
AJC-CLI451C	CLI-451C				
AJC-CLI451M	CLI-451M				
AJC-CLI451Y	CLI-451Y				
AJC-CLI451GY	CLI-451GY				
AJC-PGI450PGBKXL	PGI-450PGBK XL				
AJC-CLI451BKXL	CLI-451BK XL				
AJC-CLI451CXL	CLI-451C XL				
AJC-CLI451MXL	CLI-451M XL				
AJC-CLI451YXL	CLI-451Y XL				
AJC-CLI451GYXL	CLI-451GY XL		Canon PIXMA MG6340 /MG7140		
AJC-PGI550PGBK	PGI-550PGBK	EUR	Canon PIXMA ip7250 /iP8750 Canon PIXMA MG5450 Canon PIXMA MX725 Canon PIXMA MX925 Canon PIXMA MG6450/MG5550/IX6850/MG5650		
AJC-CLI551BK	CLI-551BK			Canon PIXMA MG6350/MG7150	
AJC-CLI551C	CLI-551C			Canon PIXMA ip7250/iP8750 Canon PIXMA MG5450 Canon PIXMA MX725 Canon PIXMA MX925 Canon PIXMA MG6450/MG5550/IX6850/MG5650	
AJC-CLI551M	CLI-551M			Canon PIXMA MG6350/MG7150	
AJC-CLI551Y	CLI-551Y			Canon PIXMA MX725/MX925	
AJC-CLI551GY	CLI-551GY				
AJC-PGI550PGBKXL	PGI-550PGBK XL				
AJC-CLI551BKXL	CLI-551BK XL				
AJC-CLI551CXL	CLI-551C XL				
AJC-CLI551MXL	CLI-551M XL				
AJC-CLI551YXL	CLI-551Y XL				
AJC-CLI551GYXL	CLI-551GY XL				
AJC-PGI555PGBKXXL	PGI-555PGBK XXL	AUS	Canon PIXMA iP7260 Canon PIXMA MG5460 Canon PIXMA MX726 Canon PIXMA MX926 Canon PIXMA IX6860/IP8760/MG5560		
AJC-PGI650PGBKXL	PGI-650PGBK XL			Canon PIXMA MG6360	
AJC-CLI651BKXL	CLI-651BK XL			Canon PIXMA MX926	
AJC-CLI651CXL	CLI-651C XL				
AJC-CLI651MXL	CLI-651M XL				
AJC-CLI651YXL	CLI-651Y XL				
AJC-CLI651GYXL	CLI-651GY XL				
AJC-PGI655PGBKXXL	PGI-655PGBK XXL	AP	Canon PIXMA ip7270 Canon PIXMA MG5470 Canon PIXMA MX727 Canon PIXMA MX927 Canon PIXMA MG6470/MG5570/IX6770/MG6670 Canon PIXMA MG7570/IX6870		
AJC-PGI750PGBKXL	PGI-750PGBK XL			Canon PIXMA MG6370/MG7570	
AJC-CLI751BKXL	CLI-751BK XL			Canon PIXMA MX727/MX927	
AJC-CLI751CXL	CLI-751C XL				
AJC-CLI751MXL	CLI-751M XL				
AJC-CLI751YXL	CLI-751Y XL				
AJC-CLI751GYXL	CLI-751GY XL				
AJC-PGI755PGBKXXL	PGI-755PGBK XXL	CHN	Canon PIXMA ip7280 Canon PIXMA MG5480 Canon PIXMA IX6880/MG5680/MG6680/MG6480/MG5580/ix6780		
AJC-PGI850PGBKXL	PGI-850PGBK XL			Canon PIXMA MG6380/MG7180/MG7580	
AJC-CLI851BKXL	CLI-851BK XL			Canon PIXMA MX728/MX928	
AJC-CLI851CXL	CLI-851C XL				
AJC-CLI851MXL	CLI-851M XL				
AJC-CLI851YXL	CLI-851Y XL				
AJC-CLI851GYXL	CLI-851GY XL				
AJC-PGI855PGBKXXL	PGI-855PGBK XXL				
for Canon III Series Inkjet Cartridge					
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo	
AJC-PGI125PGBK	PGI125PGBK	LA	Canon PIXMA MG6110/5210 Canon PIXMA IP4810 Canon PIXMA IX6510		
AJC-CLI126BK	CLI126BK				
AJC-CLI126C	CLI126C				
AJC-CLI126M	CLI126M				
AJC-CLI126Y	CLI126Y				
AJC-CLI126GY	CLI126GY				
			Canon PIXMA MG6110		

AJC-PGI225PGBK	PGI225PGBK	NA	Canon PIXMA MG8120/6120/5220/5120/5210/5320 Canon PIXMA IP4820/4810/4920 Canon PIXMA IX6520 Canon PIXMA MX882
AJC-CLI226BK	CLI226BK		
AJC-CLI226C	CLI226C		
AJC-CLI226M	CLI226M		
AJC-CLI226Y	CLI226Y		
AJC-CLI226GY	CLI226GY		Canon PIXMA MG8120/6120
AJC-BCI325PGBK	BCI325PGBK	JPN	Canon PIXUS MG8130/6130/5230/5130/MG6230/MG8230/MG5330 Canon PIXUS IP4830/IP4930 Canon PIXUS IX6530 Canon PIXUS MX883/MX893
AJC-BCI326BK	BCI326BK		
AJC-BCI326C	BCI326C		
AJC-BCI326M	BCI326M		
AJC-BCI326Y	BCI326Y		
AJC-BCI326GY	BCI326GY		Canon PIXUS MG8130/6130/MG8230/MG6230
AJC-PGI425PGBK	PGI425PGBK	MEA	Canon PIXMA MG8140/6140/5240 Canon PIXMA IP4840 Canon PIXMA IX6540 Canon PIXMA MX884
AJC-CLI426BK	CLI426BK		
AJC-CLI426C	CLI426C		
AJC-CLI426M	CLI426M		
AJC-CLI426Y	CLI426Y		
AJC-CLI426GY	CLI426GY		Canon PIXMA MG8140/6140
AJC-PGI525PGBK	PGI525PGBK	EUR	Canon PIXMA MG8150/6150/5250/MG8250 Canon PIXMA IP4850 Canon PIXMA IX6550 Canon PIXMA MX885/MX895/MX715
AJC-CLI526BK	CLI526BK		
AJC-CLI526C	CLI526C		
AJC-CLI526M	CLI526M		
AJC-CLI526Y	CLI526Y		
AJC-CLI526GY	CLI526GY		Canon PIXMA MG8150/6150/MG8250
AJC-PGI725PGBK	PGI725PGBK	AP	Canon PIXMA MG8170/MG6170/MG5270/MG5370 Canon PIXMA IP4870/IP4970 Canon PIXMA IX6560 Canon PIXMA MX886
AJC-CLI726BK	CLI726BK		
AJC-CLI726C	CLI726C		
AJC-CLI726M	CLI726M		
AJC-CLI726Y	CLI726Y		
AJC-CLI726GY	CLI726GY		Canon PIXMA MG8170/6170
AJC-PGI825PGBK	PGI825PGBK	CHN	Canon PIXMA MG8180/6180/5280 Canon PIXMA IP4880/4980 Canon PIXMA IX6580 Canon PIXMA MX888
AJC-CLI826BK	CLI826BK		
AJC-CLI826C	CLI826C		
AJC-CLI826M	CLI826M		
AJC-CLI826Y	CLI826Y		
AJC-CLI826GY	CLI826GY		Canon PIXMA MG8180/6180
AJC-PGI29PBK	PGI-29PBK	WW (ex. JPN)	Canon PIXMA Pro-1
AJC-PGI29MBK	PGI-29MBK		
AJC-PGI29DGY	PGI-29DGY		
AJC-PGI29GY	PGI-29GY		
AJC-PGI29LGY	PGI-29LGY		
AJC-PGI29C	PGI-29C		Canon PIXMA Pro-1
AJC-PGI29PC	PGI-29PC		
AJC-PGI29M	PGI-29M		
AJC-PGI29PM	PGI-29PM		
AJC-PGI29Y	PGI-29Y		
AJC-PGI29R	PGI-29R		
AJC-PGI29CO	PGI-29CO		



for Canon II Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-CLI221BK	CLI-221BK	NA	Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (USA) Canon PIXMA MX860/MX870	
AJC-CLI221C	CLI-221C			
AJC-CLI221M	CLI-221M			
AJC-CLI221Y	CLI-221Y			
AJC-PGI220BK	PGI-220BK			
AJC-CLI221GY	CLI-221GY		Canon PIXMA MP980 (USA)	

AJC-BCI321BK	BCI-321BK	JPN	Canon PIXUS iP3600/iP4600 (JP) Canon PIXUS MP540/MP620/MP630/MP980/MX860/MX870
AJC-BCI321C	BCI-321C		
AJC-BCI321M	BCI-321M		
AJC-BCI321Y	BCI-321Y		
AJC-BCI320PGBK	BCI-320PGBK		
AJC-BCI321GY	BCI-321GY		
AJC-CLI521BK	CLI-521BK	EUR	Canon PIXUS MP980 (JP)
AJC-CLI521C	CLI-521C		
AJC-CLI521M	CLI-521M		
AJC-CLI521Y	CLI-521Y		
AJC-PGI520BK	PGI-520BK		
AJC-CLI521GY	CLI-521GY		
AJC-CLI821BK	CLI-821BK	CHN	Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (EUR) Canon PIXMA MX860/MX870
AJC-CLI821C	CLI-821C		
AJC-CLI821M	CLI-821M		
AJC-CLI821Y	CLI-821Y		
AJC-PGI820BK	PGI-820BK		
AJC-CLI821GY	CLI-821GY		
AJC-CLI42BK	CLI-42BK	WW (ex. JPN)	Canon PIXMA MP980 (EUR)
AJC-CLI42C	CLI-42C		
AJC-CLI42M	CLI-42M		
AJC-CLI42Y	CLI-42Y		
AJC-CLI42GY	CLI-42GY		
AJC-CLI42LGY	CLI-42LGY		
AJC-CLI42PC	CLI-42PC	JPN	Canon PIXMA MP988 (CHN)
AJC-CLI42PM	CLI-42PM		
AJC-BCI43BK SAMPLE!	BCI-43BK		
AJC-BCI43C SAMPLE!	BCI-43C		
AJC-BCI43M SAMPLE!	BCI-43M		
AJC-BCI43Y SAMPLE!	BCI-43Y		
AJC-BCI43PC SAMPLE!	BCI-43PC	JPN	Canon PIXMA iP3680/iP4680 Canon PIXMA MP545/MP628/MP988 (CHN) Canon PIXMA MX638/MX868/MX876
AJC-BCI43PM SAMPLE!	BCI-43PM		
AJC-BCI43GY SAMPLE!	BCI-43GY		
AJC-BCI43LGY SAMPLE!	BCI-43LGY		
AJC-PGI72PBK	PGI-72PBK		
AJC-PGI72MBK	PGI-72MBK	WW (ex. JPN)	Canon PRO-100
AJC-PGI72C	PGI-72C		
AJC-PGI72M	PGI-72M		
AJC-PGI72Y	PGI-72Y		
AJC-PGI72PC	PGI-72PC		
AJC-PGI72R	PGI-72R		
AJC-PGI72PM	PGI-72PM	JPN	Canon PRO-10
AJC-PGI72GY	PGI-72GY		
AJC-PGI72CO	PGI-72CO		
AJC-PGI73MBK SAMPLE!	PGI-73MBK		
AJC-PGI73PBK SAMPLE!	PGI-73PBK		
AJC-PGI73C SAMPLE!	PGI-73C	JPN	Canon PIXUS PRO 100S Canon PIXUS PRO 100
AJC-PGI73M SAMPLE!	PGI-73M		
AJC-PGI73Y SAMPLE!	PGI-73Y		
AJC-PGI73PC SAMPLE!	PGI-73PC		
AJC-PGI73PM SAMPLE!	PGI-73PM		
AJC-PGI73CO SAMPLE!	PGI-73CO		
AJC-PGI73R SAMPLE!	PGI-73R	JPN	Canon PIXUS PRO 10S Canon PIXUS PRO 10
AJC-PGI73GY SAMPLE!	PGI-73GY		



for Canon I Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI5BK	PGI-5BK	WW (ex.JPN)	Canon PIXMA IP3300/IP4200/IP4300/IP4500 Canon PIXMA IX4000/IX5000 Canon PIXMA MP970	
AJC-CLI8BK	CLI-8BK		Canon PIXMA IP4200/IP4500/IP4300/IP5300 Canon PIXMA Pro9000	
AJC-CLI8C	CLI-8C			
AJC-CLI8M	CLI-8M			
AJC-CLI8Y	CLI-8Y			
AJC-CLI8PC	CLI-8PC			
AJC-CLI8PM	CLI-8PM			
AJC-CLI8R	CLI-8R			
AJC-CLI8G	CLI-8G			
AJC-BCI9BK	BCI-9PGBK	JPN	Canon PIXUS IP3300/IP4200/IP4300 Canon PIXUS MP950/MP960/MP970	
AJC-BCI7BK	BCI-7eBK		Canon PIXUS MP950/MP960/MP970/MP900 Canon PIXUS PRO9000 Canon PIXUS ip8600/ip9910	
AJC-BCI7C	BCI-7eC			
AJC-BCI7M	BCI-7eM			
AJC-BCI7Y	BCI-7eY			
AJC-BCI7PC	BCI-7ePC			
AJC-BCI7PM	BCI-7ePM			
AJC-BCI7R	BCI-7eR		Canon PIXUS ip8100/ip8600/ip9910 Canon PIXUS Pro9000	
AJC-BCI7G	BCI-7eG		Canon PIXUS ip8600/ip9910 Canon PIXUS Pro9000	
AJC-PGI7BK	PGI-7BK		WW (ex.JPN)	
AJC-PGI9PBK	PGI-9PBK	Canon PIXMA iX7000/MX7600 Canon PIXMA Pro9500		
AJC-PGI9C	PGI-9C			
AJC-PGI9M	PGI-9M	Canon PIXMA Pro9500		
AJC-PGI9Y	PGI-9Y			
AJC-PGI9R	PGI-9R			
AJC-PGI9MBK	PGI-9MBK			
AJC-PGI9G	PGI-9G			
AJC-PGI9PM	PGI-9PM			
AJC-PGI9PC	PGI-9PC			
AJC-PGI9GY	PGI-9GY			
AJC-BCI19BK	BCI-19BK	JPN	Canon PIXUS ip100	
AJC-BCI19C	BCI-19COLOR		Canon PIXUS Mini260 Canon PIXUS ip100	
AJC-PGI35	PGI-35	WW (ex.JPN)	Canon PIXUS ip100	
AJC-CLI36C	CLI-36C		Canon PIXUS Mini260 Canon PIXUS ip100	
AJC-PGI1BK	PGI-1BK	JPN	Canon PIXUS iX7000/MX7600	
AJC-PGI2PBK	PGI-2PBK		Canon PIXUS iX7000/MX7600 Canon PIXUS Pro9500/Pro9500 Mark II	
AJC-PGI2C	PGI-2C			
AJC-PGI2M	PGI-2M			
AJC-PGI2Y	PGI-2Y		Canon PIXUS Pro9500/Pro9500 Mark II	
AJC-PGI2GY	PGI-2GY			
AJC-PGI2G	PGI-2G			
AJC-PGI2R	PGI-2R			
AJC-PGI2PC	PGI-2PC			
AJC-PGI2PM	PGI-2PM			
AJC-PGI2MBK	PGI-2MBK			

for Canon IV Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI150PGBKXLR	PGI-150PGBK XL	LA	Canon PIXMA IP7210 Canon PIXMA MG5410 Canon PIXMA MX921 Canon PIXMA MX721	
AJC-CLI151BKXLR	CLI-151BK XL			
AJC-CLI151CXLR	CLI-151C XL			
AJC-CLI151MXLR	CLI-151M XL			
AJC-CLI151YXLR	CLI-151Y XL			
AJC-CLI151GYXLR	CLI-151GY XL			
AJC-PGI250PGBKXLR	PGI-250PGBK XL	NA	Canon PIXMA ip7220 Canon PIXMA MG5420 Canon PIXMA MX922 Canon PIXMA MX722 Canon MG5520/MG5620/MG6420/MG6620	
AJC-CLI251BKXLR	CLI-251BK XL			
AJC-CLI251CXLR	CLI-251C XL			
AJC-CLI251MXLR	CLI-251M XL			
AJC-CLI251YXLR	CLI-251Y XL			
AJC-CLI251GYXLR	CLI-251GY XL			
AJC-PGI255PGBKXXLR	PGI-255PGBK XXL	JPN	Canon PIXUS ip7230/ip8730 Canon PIXUS MG5430/MG5630 Canon PIXUS MX923 Canon PIXUS MX723 Canon PIXUS MG5530/IX6830	
AJC-BCI350PGBKXLR	BCI-350PGBK XL			
AJC-BCI351BKXLR	BCI-351BK XL			
AJC-BCI351CXLR	BCI-351C XL			
AJC-BCI351MXLR	BCI-351M XL			
AJC-BCI351YXLR	BCI-351Y XL			
AJC-BCI351GYXLR	BCI-351GY XL	MEA	Canon PIXUS MG7530F/MG7530/MG7130/MG6730/MG6530/MG6330/iP8730	
AJC-BCI355PGBKXXLR	BCI-355PGBK XXL			
AJC-PGI450PGBKXLR	PGI-450PGBK XL			
AJC-CLI451BKXLR	CLI-451BK XL			
AJC-CLI451CXLR	CLI-451C XL			
AJC-CLI451MXLR	CLI-451M XL			
AJC-CLI451YXLR	CLI-451Y XL	EUR	Canon PIXMA ip7240 Canon PIXMA MG5440 Canon PIXMA MX724 Canon PIXMA MX924	
AJC-CLI451GYXLR	CLI-451GY XL			
AJC-PGI550PGBKXLR	PGI-550PGBK XL			
AJC-CLI551BKXLR	CLI-551BK XL			
AJC-CLI551CXLR	CLI-551C XL			
AJC-CLI551MXLR	CLI-551M XL			
AJC-CLI551YXLR	CLI-551Y XL	AUS	Canon PIXMA ip7260 Canon PIXMA MG5460 Canon PIXMA MX726 Canon PIXMA MX926 Canon IX6860/IP8760/MG5560	
AJC-CLI551GYXLR	CLI-551GY XL			
AJC-PGI555PGBKXXLR	PGI-555PGBK XXL			
AJC-PGI650PGBKXLR	PGI-650PGBK XL			
AJC-CLI651BKXLR	CLI-651BK XL			
AJC-CLI651CXLR	CLI-651C XL			
AJC-CLI651MXLR	CLI-651M XL	AP	Canon PIXMA MX926 Canon IX6860/IP8760/MG5560	
AJC-CLI651YXLR	CLI-651Y XL			
AJC-CLI651GYXLR	CLI-651GY XL			
AJC-PGI655PGBKXXLR	PGI-655PGBK XXL			
AJC-PGI750PGBKXLR	PGI-750PGBK XL			
AJC-CLI751BKXLR	CLI-751BK XL			
AJC-CLI751CXLR	CLI-751C XL	CHN	Canon PIXMA MX927 Canon MG6470/MG5570/IX6770/MG6670 Canon MG7570/IX6870	
AJC-CLI751MXLR	CLI-751M XL			
AJC-CLI751YXLR	CLI-751Y XL			
AJC-CLI751GYXLR	CLI-751GY XL			
AJC-PGI755PGBKXXLR	PGI-755PGBK XXL			
AJC-PGI850PGBKXLR	PGI-850PGBK XL			
AJC-CLI851BKXLR	CLI-851BK XL	CHN	Canon PIXMA ip7280 Canon PIXMA MG5480 Canon PIXMA MX728 Canon PIXMA MX928 Canon IX6880/MG5680/MG6680/MG6480/MG5580/ix6780	
AJC-CLI851CXLR	CLI-851C XL			
AJC-CLI851MXLR	CLI-851M XL			
AJC-CLI851YXLR	CLI-851Y XL			
AJC-CLI851GYXLR	CLI-851GY XL			
AJC-PGI855PGBKXXLR	PGI-855PGBK XXL			

for Canon III Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-PGI125PGBKR	PGI-125BK	LA	Canon PIXMA IP4810/MG5210/MG6110 Canon PIXMA IX6510	
AJC-CLI126BKR	CLI-126BK			
AJC-CLI126CR	CLI-126C			
AJC-CLI126MR	CLI-126M			
AJC-CLI126YR	CLI-126Y			
AJC-CLI126GYR	CLI-126GY			
AJC-PGI225PGBKR	PGI-225BK	NA	Canon PIXMA MG5120/5220/6120/8120/5320 Canon PIXMA IP4820/4920 Canon PIXMA MX882/IX6520	
AJC-CLI226BKR	CLI-226BK			
AJC-CLI226CR	CLI-226C			
AJC-CLI226MR	CLI-226M			
AJC-CLI226YR	CLI-226Y			
AJC-CLI226GYR	CLI-226GY			
AJC-PGIPGBKR	BGI-325BK	JPN	Canon PIXUS MG5230/5130/6130/8130/MG6230/MG8230/MG5330 Canon PIXUS IP4830/IP4930 Canon PIXUS MX883/IX6530	
AJC-CLI326BKR	BLI-326BK			
AJC-CLI326CR	BLI-326C			
AJC-CLI326MR	BLI-326M			
AJC-CLI326YR	BLI-326Y			
AJC-CLI326GYR	BLI-326GY			
AJC-PGIPGBKR	PGI-425BK	MEA	Canon PIXMA MG5240/5140/6140/8140 Canon PIXMA IP4840 Canon PIXMA MX884/IX6540	
AJC-CLI426BKR	CLI-426BK			
AJC-CLI426CR	CLI-426C			
AJC-CLI426MR	CLI-426M			
AJC-CLI426YR	CLI-426Y			
AJC-CLI426GYR	CLI-426GY			
AJC-PGIPGBKR	PGI-525BK	EUR	Canon PIXMA MG5250/5150/6150/8150/MG8250 Canon PIXMA IP4850 Canon PIXMA MX885/IX6550	
AJC-CLI526BKR	CLI-526BK			
AJC-CLI526CR	CLI-526C			
AJC-CLI526MR	CLI-526M			
AJC-CLI526YR	CLI-526Y			
AJC-CLI526GYR	CLI-526GY			
AJC-PGI725PGBKR	PGI-725BK	AP	Canon PIXMA MG5270/MG5170/MG6170/MG8170/MG5370 Canon PIXMA IP4870/IP4970 Canon PIXMA MX886/IX6560	
AJC-CLI726BKR	CLI-726BK			
AJC-CLI726CR	CLI-726C			
AJC-CLI726MR	CLI-726M			
AJC-CLI726YR	CLI-726Y			
AJC-CLI726GYR	CLI-726GY			
AJC-PGIPGBKR	PGI-825BK	CHN	Canon PIXMA MG5280/5180/6180/8180 Canon PIXMA IP4880/4980 Canon PIXMA MX888/IX6580	
AJC-CLI826BKR	CLI-826BK			
AJC-CLI826CR	CLI-826C			
AJC-CLI826MR	CLI-826M			
AJC-CLI826YR	CLI-826Y			
AJC-CLI826GYR	CLI-826GY			
for Canon II Series CISS				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJC-CLI221BKR	CLI-221BK	NA	Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (USA) Canon PIXMA MX860/MX870	
AJC-CLI221CR	CLI-221C			
AJC-CLI221MR	CLI-221M			
AJC-CLI221YR	CLI-221Y			
AJC-PGI220BKR	PGI-220BK			
AJC-CLI221GYR	CLI-221GY			

AJC-BCI321BKR	BCI-321BK	JPN	Canon PIXUS iP3600/iP4600 (JP) Canon PIXUS MP540/MP620/MP630/MP980/MX860/MX870
AJC-BCI321CR	BCI-321C		
AJC-BCI321MR	BCI-321M		
AJC-BCI321YR	BCI-321Y		
AJC-BCI320PGBKR	BCI-320PGBK		
AJC-BCI321GYR	BCI-321GY		
AJC-CLI521BKR	CLI-521BK	EUR	Canon PIXUS MP980 (JP)
AJC-CLI521CR	CLI-521C		Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (EUR) Canon PIXMA MX860/MX870
AJC-CLI521MR	CLI-521M		
AJC-CLI521YR	CLI-521Y		
AJC-PGI520BKR	PGI-520BK		
AJC-CLI521GYR	CLI-521GY		
AJC-CLI821BKR	CLI-821BK	CHN	Canon PIXMA MP980 (EUR)
AJC-CLI821CR	CLI-821C		Canon PIXMA iP3680/iP4680 Canon PIXMA MP545/MP628/MP988 (CHN) Canon PIXMA MX638/MX868/MX876
AJC-CLI821MR	CLI-821M		
AJC-CLI821YR	CLI-821Y		
AJC-PGI820BKR	PGI-820BK		
AJC-CLI821GYR	CLI-821GY		



for Canon I Series CISS					
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo	
AJC-PGI5BKR	PGI-5BK	WW (ex.JPN)	Canon PIXMA IP4200/IP3300 Canon PIXMA IP4500/IX4000 Canon PIXMA IX5000 /IP4300 Canon PIXMA MP970		
AJC-CLI8BKR	CLI-8BK		Canon PIXMA IP4200/IP4200 Canon PIXMA IP4500/IP4300 Canon PIXMA IP5300/Pro9000		
AJC-CLI8CR	CLI-8C				
AJC-CLI8MR	CLI-8M				
AJC-CLI8YR	CLI-8Y				
AJC-CLI8PCR	CLI-8PC				
AJC-CLI8PMR	CLI-8PM				
AJC-CLI8RR	CLI-8R				
AJC-CLI8GR	CLI-8G	Canon PIXMA Pro9000			
AJC-BCI9BKR	BCI-9PGBK	JPN	Canon PIXUS IP3300/IP4200/IP4300 Canon PIXUS MP950/MP960/MP970		
AJC-BCI7BKR	BCI-7eBK		Canon PIXUS MP950/MP960/MP970/MP900 Canon PIXUS PRO9000 Canon PIXUS ip8600/ip9910		
AJC-BCI7CR	BCI-7eC		Canon PIXUS MP950/MP960/MP970/MP900 Canon PIXUS PRO9000 Canon PIXUS ip8600/ip9910		
AJC-BCI7MR	BCI-7eM		Canon PIXUS ip8100/ip8600/ip9910 Canon PIXUS Pro9000		
AJC-BCI7YR	BCI-7eY		Canon PIXUS ip8600/ip9910 Canon PIXUS Pro9000		
AJC-BCI7PCR	BCI-7ePC		Canon PIXUS Pro9000		
AJC-BCI7PMR	BCI-7ePM				
AJC-BCI7RR	BCI-7eR				
AJC-BCI7GR	BCI-7eG				
AJC-PGI9RR	PGI-9R	WW (ex.JPN)	Canon PIXMA Pro9500		
AJC-PGI9MBKR	PGI-9MBK				
AJC-PGI9GR	PGI-9G				
AJC-PGI9PMR	PGI-9PM				
AJC-PGI9PCR	PGI-9PC				
AJC-PGI9YR	PGI-9Y				
AJC-PGI9CR	PGI-9C				
AJC-PGI9GYR	PGI-9GY				
AJC-PGI9PBKR	PGI-9PBK				
AJC-PGI9MR	PGI-9M				
AJC-BCI19BKR	BCI-19BK	JPN	Canon PIXUS ip100		
AJC-BCI19CR	BCI-19COLOR		Canon PIXUS Mini 260 Canon PIXUS ip100		

AJC-PGI35R	PGI-35	WW (ex.JPN)	Canon PIXUS ip100			
AJC-CLI36CR	CLI-36C		Canon PIXUS Mini 260 Canon PIXUS ip100			
for Canon Wide Format Cartridge						
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo		
AJC-PFI102MK	0894B001	WW	Canon imagePROGRAF 500/510 Canon imagePROGRAF 600/605/610 Canon imagePROGRAF 700/710/720/750/755 Canon imagePROGRAF 605/610/655			
AJC-PFI102K	0985B001					
AJC-PFI102C	0896B001					
AJC-PFI102M	0897B001					
AJC-PFI102Y	0898B001					
AJC-1201BK	BCI-1201BK	JPN	Canon N1000/N2000			
AJC-1201C	BCI-1201C					
AJC-1201M	BCI-1201M					
AJC-1201Y	BCI-1201Y					
AJC-1302BK	BCI-1302BK					
AJC-1302C	BCI-1302C					
AJC-1302M	BCI-1302M					
AJC-1302Y	BCI-1302Y					
AJC-1302LC	BCI-1302LC					
AJC-1302LM	BCI-1302LM					
AJC-1411BK	BCI-1411BK					
AJC-1411C	BCI-1411C					
AJC-1411M	BCI-1411M					
AJC-1411Y	BCI-1411Y					
AJC-1411LC	BCI-1411LC					
AJC-1411LM	BCI-1411LM					
AJC-1401BK	BCI-1401BK					
AJC-1401C	BCI-1401C					
AJC-1401M	BCI-1401M					
AJC-1401Y	BCI-1401Y					
AJC-1401LC	BCI-1401LC					
AJC-1401LM	BCI-1401LM					
AJC-1431BK	BCI-1431BK					
AJC-1431C	BCI-1431C					
AJC-1431M	BCI-1431M					
AJC-1431Y	BCI-1431Y					
AJC-1431LC	BCI-1431LC					
AJC-1431LM	BCI-1431LM					
AJC-1421BK	BCI-1421BK					
AJC-1421C	BCI-1421C					
AJC-1421M	BCI-1421M					
AJC-1421Y	BCI-1421Y					
AJC-1421LC	BCI-1421LC					
AJC-1421LM	BCI-1421LM					
for Lexmark Series Inkjet Cartridge						
Product Code	OEM Product Code		Region		For Use in Printers	Chip Photo
AJL-100BK	14N0820	/	Lexmark prospect pro 205/208 Lexmark impact S305/S308 Lexmark interpret S405/S408 Lexmark intuition S505/S508 Lexmark interact S605/S608 Lexmark prevail pro 705/708 Lexmark prestige pro 805/808 Lexmark platinum pro 905/908 Lexmark S815			
AJL-100C	14N0900	/				
AJL-100M	14N0901	/				
AJL-100Y	14N0902	/				
AJL-100BKXL	14N1068	/				
AJL-100CXL	14N1069	/				
AJL-100MXL	14N1070	/				
AJL-100YXL	14N1071	/				

AJL-150BKXL	14N1614	/	Lexmark pro 715/915 Lexmark S315/S415/S515	
AJL-150CXL	14N1615	/		
AJL-150MXL	14N1616	/		
AJL-150YXL	14N1618	/		
AJL-155BKXL	14N1619	/	Lexmark pro 715/915	
AJL-200BKXL	14L0174	/	Lexmark OfficeEdge Pro 4000 Lexmark OfficeEdge Pro 5500/5500t	
AJL-200CXL	14L0175	/		
AJL-200MXL	14L0176	/		
AJL-200YXL	14L0177	/		
for LG Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJLg-100K	LIP3310S2K.A	KOR	LG LIP3310/3320/3370	
AJLg-100C	LIP3310S2C.A			
AJLg-100M	LIP3310S2M.A			
AJLg-100Y	LIP3310S2Y.A			
AJLg-327XLK	LIP3270S10K.AB		LG LIP3270W/LIP3470DN	
AJLg-327C	LIP3270S3C.AB			
AJLg-327M	LIP3270S3M.AB			
AJLg-327Y	LIP3270S3Y.AB			
for Dell Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJD-905	20#BK	/	Dell 703	
AJD-906	20#Color	/	Dell 703W	
AJD-21BK	3305***	/	Dell V313/V313W Dell P513W Dell V515/515W	
AJD-21C	3305***	/	Dell P713 Dell V715W	
AJD-22BK	3305***	/	Dell V313/V313W Dell P513W Dell V515/515W	
AJD-22C	3305***	/	Dell P713 Dell V716W	
AJD-33BK	331-7377	/	Dell V525w Dell V725w	
AJD-33C	331-7378	/		
AJD-33M	331-7379	/		
AJD-33Y	331-7380	/		
for Ricoh Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJR-BKG7500	G7500 BK	/	Ricoch GX7500	
AJR-CG7500	G7500 C	/		
AJR-MG7500	G7500 M	/		
AJR-YG7500	G7500 Y	/		
AJR-BKG7000	G7000 BK	/	Ricoch GX7000	
AJR-CG7000	G7000 C	/		
AJR-MG7000	G7000 M	/		
AJR-YG7000	G7000 Y	/		
AJR-BKG2500	G2500 BK	/	Ricoch GX2500	
AJR-CG2500	G2500 C	/		
AJR-MG2500	G2500 M	/		
AJR-YG2500	G2500 Y	/		
AJR-GC21BKH	GC21BKH	/	Ricoch GX7000 Ricoch GX5050N	
AJR-GC21CH	GC21CH	/		
AJR-GC21MH	GC21MH	/		
AJR-GC21YH	GC21YH	/		

AJR-GC21BK	GC21BK	/	Ricoh GX7000	
AJR-GC21C	GC21C	/	Ricoh GX5050	
AJR-GC21M	GC21M	/	Ricoh GX3000SF	
AJR-GC21Y	GC21Y	/	Ricoh GX3000S Ricoh GX3000 Ricoh GX2500	
AJR-1K12 SAMPLE!	RC-1K12	/	Ricoh Ipsio G7570	
AJR-1C12 SAMPLE!	RC-1C12	/		
AJR-1M12 SAMPLE!	RC-1M12	/		
AJR-1Y12 SAMPLE!	RC-1Y12	/		
AJR-GC31HBK	GC31HBK	/	Ricoh GX e5550/e5550n Ricoh Ipsio GX e5500	
AJR-GC31HC	GC31HC	/		
AJR-GC31HM	GC31HM	/		
AJR-GC31HY	GC31HY	/		
AJR-GC31BK	GC31BK	/		
AJR-GC31C	GC31C	/		
AJR-GC31M	GC31M	/		
AJR-GC31Y	GC31Y	/		
AJR-GC31MFC	GC31MFC	/	Ricoh Ipsio SG 3100 Ricoh Ipsio SG 2100 Ricoh Ipsio SG 2010L Ricoh Aficio SG 3110Dnw	
AJR-GC41BK	GC41BK	/		
AJR-GC41C	GC41C	/		
AJR-GC41M	GC41M	/		
AJR-GC41Y	GC41Y	/	Ricoh SG 5200	
AJR-GC42BK	GC42BK	/		
AJR-GC42C	GC42C	/		
AJR-GC42M	GC42M	/		
AJR-GC42Y	GC42Y	/		
AJR-GC42BKH	GC42BKH	/		
AJR-GC42CH	GC42CH	/		
AJR-GC42MH	GC42MH	/	Ricoh SG 3300/2300	
AJR-GC42YH	GC42YH	/		
AJR-GC43BK	GC43BK	/		
AJR-GC43C	GC43C	/		
AJR-GC43M	GC43M	/		
AJR-GC43Y	GC43Y	/		
AJR-GC43BKS	GC43BKS	/		
AJR-GC43CS	GC43CS	/	Ricoh SG 3210DNw	
AJR-GC43MS	GC43MS	/		
AJR-GC43YS	GC43YS	/		
AJR-GC51BKH	GC51BKH	/		
AJR-GC51CH	GC51CH	/	SAWGRASS SG400/SG800	
AJR-GC51MH	GC51MH	/		
AJR-GC51YH	GC51YH	/		
for SAWGRASS Series Inkjet Cartridge				
Product Code	OEM Product Code	Region	For Use in Printers	Chip Photo
AJSG-SG400&800BK	SG400&800 BK	/	SAWGRASS SG400/SG800	
AJSG-SG400&800C	SG400&800 C	/		
AJSG-SG400&800M	SG400&800 M	/		
AJSG-SG400&800Y	SG400&800 Y	/		
AJSG-SG500 BK	SG500 BK	/	SAWGRASS SG500/SG1000	
AJSG-SG500 C	SG500 C	/		
AJSG-SG500M	SG500 M	/		
AJSG-SG500 Y	SG500 Y	/		

for Kodak Series Inkjet Cartridge						
Product Code		OEM Product Code	Region	For Use in Printers		Chip Photo
AJK-10B		10B	/	BKodak Easyshare 5100/5300/5500		
AJK-10C		10C	/	BKodak ESP 3/5/7/9		
AJK-10XLB		10XLB	/	BKodak ESP 3250/5250/7250/9250/5210		
AJK-10XLC		-----	/	BKodak ESP Office 6150 BKodak Hero 7.1/9.1 BKodak Office HERO 6.1		
AJK-30BK		30BK	/	BKodak Easyshare ESP C110/C310/C315		
AJK-30C		30C	/	BKodak Easyshare Office 2150/2170		
AJK-30XLBK		30XLBK	/	BKodak Easyshare Hero 3.1/5.1		
AJK-30XLC		30XLC	/	BKodak Easyshare ESP 1.2/3.2/3.2s BKodak Hero 2.2/4.2		
for Advent Series Inkjet Cartridge						
Product Code		OEM Product Code	Region	For Use in Printers		Chip Photo
AJA-ABK10		ABK10	/	Advent A10 Advent AW10		
AJA-ACLR10		ACLR10	/	Advent AWP10		
for Samsung Series Inkjet Cartridge						
Product Code		OEM Product Code	Region	For Use in Printers		Chip Photo
AJS-M210		INK-M210	/	Samsung CJX-1000/1050W/2000FW		
AJS-M215		INK-M215	/			
AJS-C210		INK-C210	/			
AJS-K200		INK-K200	/	Samsung SCX-2000FW Samsung SCX-1490W/SCX-1490W/DOC Samsung SCX-1855F		
AJS-C200		INK-C200	/			
AJS-M200		INK-M200	/			
AJS-Y200		INK-Y200	/	Samsung SL-J2920W Samsung SL-J2960FW		
AJS-K410		INK-BK410	KOR			
AJS-C410		INK-C410				
AJS-M410		INK-M410				
AJS-Y410		INK-Y410				
AJS-K310 (only applicable in recycled cartridges)		INK-BK310	KOR	Samsung SL-J3520W Samsung SL-J3523W Samsung SL-J3525W Samsung SL-J3560FW Samsung SL-J3570FW		
AJS-C310 (only applicable in recycled cartridges)		INK-C310				
AJS-M310 (only applicable in recycled cartridges)		INK-M310				
AJS-Y310 (only applicable in recycled cartridges)		INK-Y310				
AJS-K510 (only applicable in recycled cartridges)		INK-K510	KOR	Samsung SL-J5560FW Samsung SL-J5520W		
AJS-C510 (only applicable in recycled cartridges)		INK-C510				
AJS-M510 (only applicable in recycled cartridges)		INK-M510				
AJS-Y510 (only applicable in recycled cartridges)		INK-Y510				
for HP Series Inkjet Cartridge (One-time Chip)						
OEM Ink Cartridge Type	Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
	AJH-4840A	C4840A		BK	HP Designjet Colorpro ga	
	AJH-4841A	C4841A		C	HP Designjet Colorpro cad	
	AJH-4842A	C4842A		Y	HP Business Inkjet 2000c professional series HP Business Inkjet 2500c professional series	
	AJH-4843A	C4843A		M	HP Designjet 3000	

HP 10	AJH-4844A	C4844A	WW	BK	HP Designjet 500/500PS HP Designjet 800/800PS HP Designjet 815mfp/820MFP HP Designjet 1100 HP Designjet 2200 HP Designjet 2300/2230/2250/2280/2600/1700 HP Designjet100/110 HP Business inkjet 3000/3000n/3000dtn HP Business Inkjet 2000c professional series HP Business Inkjet 2500c professional series HP Business Inkjet 1200/2800 HP OfficeJet Pro K850 HP OfficeJet 9110/9120/9130 HP Business Inkjet 1000
HP 11	AJH-4836A	C4836A	WW	C	HP Business Inkjet 1100 series HP Business Inkjet 2200/2300/2230 HP Business Inkjet 2250/2280/2600 series HP Color Inkjet Printer cp1700
	AJH-4837A	C4837A		M	HP Designjet 100/110/120/10PS/20PS/50PS HP OfficeJet Pro K850 HP OfficeJet 9110/9120/9130 HP Business Inkjet 1000 HP Business Inkjet 2800
	AJH-4838A	C4838A		Y	HP Business Inkjet 1100 series HP Business Inkjet 2200/2300/2230 HP Business Inkjet 2250/2280/2600series HP Color Inkjet Printer cp1700 HP Designjet 100/110 plus Printer series HP Designjet 50ps HP OfficeJet Pro K850 HP OfficeJet 9110/9120/9130 HP Business Inkjet 1000 HP Business Inkjet 2800
HP 12	AJH-4804A	C4804A	WW	C	HP Business Inkjet 3000/3000n/3000dtn
	AJH-4805A	C4805A		M	
	AJH-4806A	C4806A		Y	
HP 13	AJH-4814A	C4814A	WW	BK	HP Business Inkjet 1000 HP Business Inkjet 1200 series HP OfficeJet Pro K850
	AJH-4815A	C4815A		C	
	AJH-4816A	C4816A		M	
	AJH-4817A	C4817A		Y	
HP 18	AJH-4936A	C4936A	WW	BK	HP OfficeJet Pro K5300/5400dn HP OfficeJet Pro L7380 HP OfficeJet Pro L7580 HP OfficeJet K5400dn/K5400dtn
	AJH-4937A	C4937A		C	
	AJH-4938A	C4938A		M	
	AJH-4939A	C4939A		Y	
HP 38	AJH-9412A	C9412A	WW	MBK	HP Photosmart Pro B9180 HP Photosmart Pro B8850
	AJH-9413A	C9413A		PBK	
	AJH-9414A	C9414A		LG	
	AJH-9415A	C9415A		C	
	AJH-9416A	C9416A		M	
	AJH-9417A	C9417A		Y	
	AJH-9418A	C9418A		LC	
	AJH-9419A	C9419A		LM	

HP 72	AJH-9403A	C9403A	WW	MBK	HP Designjet T1110
	AJH-9370A	C9370A		BK	HP Designjet T1120
	AJH-9371A	C9371A		C	HP Designjet T1300
	AJH-9372A	C9372A		M	HP Designjet T2300
	AJH-9373A	C9373A		Y	HP Designjet T610
	AJH-9374A	C9374A		Grey	HP Designjet T770
HP 82	AJH-CH565A	CH565A	WW	BK	HP Designjet T790
	AJH-4911A	C4911A		C	HP Designjet T795
	AJH-4912A	C4912A		M	HP Designjet 510 series
	AJH-4913A	C4913A		Y	HP Designjet 500/500PS HP Designjet 800/800PS HP Designjet 815mfp HP Designjet 820mfp HP Designjet 510 series
HP 84	AJH-5016A	C5016A	WW	BK	HP Designjet 500/500PS HP Designjet 800/800PS HP Designjet 815mfp HP Designjet 820mfp HP Designjet 10PS/20PS/50PS HP Designjet 510 series
	AJH-5017A	C5017A		LC	HP Designjet 90r/10ps/20ps/50ps/30/120/130 series
	AJH-5018A	C5018A		LM	HP Business Inkjet 2600
HP 85	AJH-9425A	C9425A	WW	C	HP Designjet 10ps/20ps/50ps/120 series
	AJH-9426A	C9426A		M	
	AJH-9427A	C9427A		Y	HP Designjet 30/90r/130 series
	AJH-9428A	C9428A		LC	
	AJH-9429A	C9429A		LM	
HP 88	AJH-9385A	C9385A	WW	BK	
	AJH-9386A	C9386A		C	
	AJH-9387A	C9387A		M	HP OfficeJet PRO K550 K8600
	AJH-9388A	C9388A		Y	HP OfficeJet PRO L7780
	AJH-9396A	C9396A		BK	HP OfficeJet PRO L7580/L7590/L7680
	AJH-9391A	C9391A		C	
	AJH-9392A	C9392A		M	
	AJH-9393A	C9393A		Y	
HP 02	AJH-8721W	C8721W	USA/AP	BK	
	AJH-8719W	C8719W		BK	
	AJH-8771W	C8771W		C	HP Photosmart 3210/3310/ 8250/C5180/C6180/C7280/C8180
	AJH-8772W	C8772W		M	HP Photosmart D6160/D7160/D7260/D7360/D7460
	AJH-8773W	C8773W		Y	HP Photosmart D7300/D7100/D6100/C7100/C6100/C5100/8200/3100 series
	AJH-8774W	C8774W		LC	HP Photosmart 3110/8230
	AJH-8775W	C8775W		LM	HP Photosmart C5140/C5150/C6150/C6280/C7180/C7250
	AJH-8730W	C8730WN		C	HP Photosmart D6160/D7145/D7155/D7160/ D7260/D7345/D7355/D7360/D7460
	AJH-8731W	C8731WN		M	
	AJH-8732W	C8732WN		Y	
HP 801	AJH-8721Z	C8721Z	CHN/ IDN	BK	
	AJH-8719Z	C8719Z		BK	
	AJH-8771Z	C8771Z		C	HP Photosmart D7300/D7100/D6100/C7100/ C6100/C5100/8200/3100 series
	AJH-8772Z	C8772Z		M	
	AJH-8773Z	C8773Z		Y	
	AJH-8774Z	C8774Z		LC	
	AJH-8775Z	C8775Z		LM	



HP 363	AJH-8719E	C8719E	EUR	BK	HP Photosmart D7300/D7100/D6100/ C7100/C6100/C5100/8200/3100 series	
	AJH-8721E	C8721E		BK		
	AJH-8771E	C8771E		C		
	AJH-8772E	C8772E		M		
	AJH-8773E	C8773E		Y		
	AJH-8774E	C8774E		LC		
	AJH-8775E	C8775E		LM		
HP 177	AJH-8721H	C8721H	ME/AF/ JPN	BK	HP Photosmart D7300/D7100/D6100/C7100/ C6100/C5100/8200/3100 series	
	AJH-8719H	C8719H		BK		
	AJH-8771H	C8771H		C		
	AJH-8772H	C8772H		M		
	AJH-8773H	C8773H		Y		
	AJH-8774H	C8774H		LC		
	AJH-8775H	C8775H		LM		
HP 14	AJH-5010A	C5010A	WW	Color	HP Color Inkjet Printer CP1160 series	
	AJH-5011A	C5011A		BK	HP OfficeJet D125xi/D135/D135xi/D145/D155xi HP OfficeJet 7110/7130series	
	AJH-5010D	C5010D		Color	HP OfficeJet 7140 series HP Digital Copier 610 series	
	AJH-5011D	C5011D		BK	HP OfficeJet 153Xi/7140	
HP 564	AJH-564K	CB316W	USA/SA/LA/A NZ/AP	BK	HP Photosmart B8550 HP Photosmart B8500	
	AJH-564PK	CB317W		PBK	HP Photosmart C6324/C6340/C6350/C6375/C6380/C6383/C6388 HP Photosmart D5460/D5463/D5468/D7560 HP Photosmart 7510 e-AIO-C331a	
	AJH-564C	CB318W		C	HP Photosmart 7515 - C311a HP Photosmart 7525 e-All-in-One HP Photosmart Plus AIO B209a	
	AJH-564M	CB319W		M	HP Photosmart Plus AIO B210a/b/c/d/e HP Photosmart Premium Fax AIO C309a/g/n HP Photosmart Premium touchsmart WEB AIO C309n	
	AJH-564Y	CB320W		Y	HP Photosmart Premium e-ALL-in-One C310a/b/c HP Photosmart eStation C510a HP Photosmart Premium Fax C410	
	AJH-564XLK	CN684W		BK	HP Photosmart D5445 HP Photosmart D5400 HP Photosmart 7520	
	AJH-564XLPK	CB322W		PBK	HP Photosmart 5510 e-AIO B111a HP Photosmart 5520 HP Photosmart 5514 e-AIO B111h	
	AJH-564XLC	CB323W		C	HP Photosmart 6510 e-AIO B211a HP Photosmart 6512 e-AIO B211a HP Photosmart 6515 e-AIO B211a	
	AJH-564XLM	CB324W		M	HP OfficeJet 4610 All-in-One Printer HP OfficeJet 4622 e-All-in-One Printer HP OfficeJet 4620 e-All-in-One Printer	
	AJH-564XLY	CB325W		Y	HP Deskjet 3070A AIO HP Deskjet 3520	
	AJH-364K	CB316E		BK	HP Photosmart Premium e-All-in-One Printer HP Photosmart 7510 e-AIO-C311a	
	AJH-364PK	CB317E		PBK	HP Photosmart Plus AIO HP Photosmart Pro B8550/B8553 HP Photosmart C5324/C5370/C5373/C5380/C5383/C5388	
	AJH-364C	CB318E		C	HP Photosmart C5390/C5393/C6300/C6324/C6380 HP Photosmart D5460/D5463/D5468 HP Photosmart B109a/b/c/d AIO	

HP 364	AJH-364M	CB319E	EUR	M	HP Photosmart B109f Special Edition AIO HP Photosmart B109n/q/a/c/d/e Wireless AIO HP Photosmart Plus B210a/b/c/e AIO HP Photosmart Premium C309/a/c/g/h/n AIO HP Photosmart Premium C310A-AIO HP Photosmart Premium C310 e-AIO HP Photosmart Premium FAX C309 AIO HP Photosmart Premium Fax C309a HP Photosmart Premium FAX e-AIO C410b HP Photosmart eStation C510a HP Photosmart C410b HP Photosmart 5510 e-AIO B111a/h/c HP Photosmart 5515 e-All-in-One Printer HP Photosmart 6510 e-AIO B211b HP OfficeJet 4620 e-All-in-One Printer HP Deskjet 3070A AIO HP Photosmart plus B209a HP Photosmart B110a HP Photosmart B109n
	AJH-364Y	CB320E		Y	
	AJH-364XLK	CN684E		BK	
	AJH-364XLPK	CB322E		PBK	
	AJH-364XLC	CB323E		C	
	AJH-364XLM	CB324E		M	
	AJH-364XLY	CB325E		Y	
HP 178	AJH-178K	CB316H	JPN/ ME	BK	HP Photosmart AIO HP Photosmart 7510 e-AIO-C311a HP Photosmart Plus AIO HP Photosmart Pro B8550/B8553 HP Photosmart C5324/C5370/C5373/C5380/C5383/C5388 HP Photosmart C5390/C5393/C6300/C6324/C6380 HP Photosmart D5460/D5463/D5468 HP Photosmart B109a/c/d AIO HP Photosmart B109f Special Edition AIO HP Photosmart B109n/q/a/c/d/e Wireless AIO HP Photosmart Plus B209a/b/c HP Photosmart Plus B210a/b/c/e AIO HP Photosmart Premium C309/a/c/g/h/n AIO HP Photosmart Premium C309A-AIO HP Photosmart Premium C309 e-AIO HP Photosmart Premium FAX C309 AIO HP Photosmart Premium Fax C309a HP Photosmart Premium FAX e-AIO C410b HP Photosmart Premium C410c HP Photosmart 5510 e-AIO B111a/h/c HP Photosmart 6510 e-AIO B211b HP Deskjet 3070A AIO
	AJH-178PK	CB317H		PBK	
	AJH-178C	CB318H		C	
	AJH-178M	CB319H		M	
	AJH-178Y	CB320H		Y	
	AJH-178XLK	CN684H		BK	
	AJH-178XLPK	CB322H		PBK	
	AJH-178XLC	CB323H		C	
	AJH-178XLM	CB324H		M	
	AJH-178XLY	CB325H		Y	
HP 862	AJH-862K	CB316Z	CN	BK	HP Photosmart B5468/B8550/B8553/B8558 HP Photosmart B110a/B209a HP Photosmart C5324/C5370/C5373/C5380/C5383/C5388 HP Photosmart C5390/C5393/C6324/C6388 HP Photosmart D5460/D5468/D7560 HP Photosmart 7510 e-AIO-C311a HP Photosmart Plus AIO B209a HP Photosmart Plus e-AIO B210a HP Photosmart Premium AIO C309g HP Photosmart Premium e-AIO C310a HP Photosmart Premium Fax AIO C309a HP Photosmart Premium Fax e-AIO C410d HP Photosmart Wireless e-AIO B110 HP Photosmart 5510 e-AIO B111a/g HP Photosmart 6510 e-AIO B211e HP Deskjet 3070A AIO HP Photosmart B110a
	AJH-862PK	CB317Z		PBK	
	AJH-862C	CB318Z		C	
	AJH-862M	CB319Z		M	
	AJH-862Y	CB320Z		Y	
	AJH-862XLK	CN684Z		BK	
	AJH-862XLPK	CB322Z		PBK	
	AJH-862XLC	CB323Z		C	
	AJH-862XLM	CB324Z		M	
	AJH-862XLY	CB325Z		Y	



HP 920	AJH-920K	CD971A	WW	BK	HP OfficeJet 6000 HP OfficeJet 6000 AIO-E608a	
	AJH-920C	CH634A		C	HP OfficeJet 6000 Printer - E609a HP OfficeJet 6000 W AIO-E609n HP OfficeJet 6000 W	
	AJH-920M	CH635A		M	HP OfficeJet 6500 AIO HP OfficeJet 6500 W AIO	
	AJH-920Y	CH636A		Y	HP OfficeJet 6500 W AIO-E609a HP OfficeJet 6500 AIO(US)E709 HP OfficeJet 6500 AIO-E709a/n	
	AJH-920XLK	CD975A		BK	HP OfficeJet 6500 W AIO-E709n HP OfficeJet 6500A e-AIO E710a HP OfficeJet 6500A AIO-E710a	
	AJH-920XLC	CD972A		C	HP OfficeJet 6500A Plus e-AIO E710n HP OfficeJet 6500A C-AIO	
	AJH-920XLM	CD973A		M	HP OfficeJet 7000 WF HP OfficeJet 7000 WF-E809a HP OfficeJet 7500A WF	
	AJH-920XLY	CD974A		Y	HP OfficeJet 7500A e-AIO E910 HP OfficeJet 7500A WF e-AIO E910a	
HP 685	AJH-685K	CZ121AA	ANZ/ AP/ CHN	BK	HP DeskJet Ink Advantage 3525 HP DeskJet Ink Advantage 4615 HP DeskJet Ink Advantage 4625 HP DeskJet Ink Advantage 5525 HP DeskJet Ink Advantage 6525	
	AJH-685C	CZ122AA		C		
	AJH-685M	CZ123AA		M		
	AJH-685Y	CZ124AA		Y		
	AJH-685XLK	-		BK		
	AJH-685XLC	-		C		
	AJH-685XLM	-		M		
	AJH-685XLY	-		Y		
HP 655	AJH-655K	CZ109AE	MEA/ RUS	BK	HP DeskJet Ink Advantage 3525 HP DeskJet Ink Advantage 4615 HP DeskJet Ink Advantage 4625 HP DeskJet Ink Advantage 5525 HP DeskJet Ink Advantage 6525	
	AJH-655C	CZ110AE		C		
	AJH-655M	CZ111AE		M		
	AJH-655Y	CZ112AE		Y		
HP 670	AJH-670XLK	CZ117AB	LA	BK	HP DeskJet Ink Advantage 4615 HP DeskJet Ink Advantage 4625 HP DeskJet Ink Advantage 5525	
	AJH-670XLC	CZ118AB		C		
	AJH-670XLM	CZ119AB		M		
	AJH-670XLY	CZ120AB		Y		
	AJH-670K	CZ113AB		BK		
	AJH-670C	CZ114AB		C		
	AJH-670M	CZ115AB		M		
	AJH-670Y	CZ116AB		Y		
HP 940	AJH-940K	C4902AA	WW	BK	HP OfficeJet Pro 8000 -A809a HP OfficeJet Pro 8000 Enterprise Printer - A811a HP OfficeJet Pro 8000 Printer - A809a HP OfficeJet Pro 8000 Wireless Printer - A809n HP OfficeJet Pro 8500 - A909b HP OfficeJet Pro 8500 AIO Printer - A909a HP OfficeJet Pro 8500 Premier AIO Printer - A909n HP OfficeJet Pro 8500 Wireless AIO Printer - A909g HP OfficeJet Pro 8500A -A910a HP OfficeJet Pro 8500A e-AIO Printer - A910a HP OfficeJet Pro 8500A Plus e-AIO Printer - A910g HP OfficeJet Pro 8500A Premium e-AIO Printer - A910n	
	AJH-940C	C4901A		C		
	AJH-940M	C4902A		M		
	AJH-940Y	C4903A		Y		
	AJH-940XLK	C4906A		BK		
	AJH-940XLC	C4907A		C		
	AJH-940XLM	C4908A		M		
	AJH-940XLY	C4909A		Y		

HP 950	AJH-950XLK	CN045A	WW	BK	HP OfficeJet Pro 8100 ePrinter HP OfficeJet Pro 8600 e-AIO Printer HP OfficeJet Pro 8600 Plus e-AIO Printer HP OfficeJet Pro 8600 Premium e-AIO Printer-N911 HP OfficeJet Pro 8610/8620/8630/8640/8660/8615/8625 HP OfficeJet Pro 251DW/276DW	
	AJH-951XLC	CN046A		C		
	AJH-951XLM	CN047A		M		
	AJH-951XLY	CN048A		Y		
	AJH-950K	CN049A		BK		
	AJH-951C	CN050A		C		
	AJH-951M	CN051A		M		
	AJH-951Y	CN052A		Y		
HP 932	AJH-932XLK	CN053A	WW	BK	HP OfficeJet 6100 ePrinter - H611a HP OfficeJet 6600 e-AIO Printer - H711a HP OfficeJet 6700 Premium e-AIO Printer - H711n HP OfficeJet OfficeJet 7110 wide Format ePrinter HP OfficeJet 7612 HP OfficeJet 7610 HP OfficeJet 7510	
	AJH-933XLC	CN054A		C		
	AJH-933XLM	CN055A		M		
	AJH-933XLY	CN056A		Y		
	AJH-932K	CN057A		BK		
	AJH-933C	CN058A		C		
	AJH-933M	CN059A		M		
	AJH-933Y	CN060A		Y		
HP 970	AJH-970K	CN621A	WW	BK	HP OfficeJet Pro X451dn HP OfficeJet Pro X551dw HP OfficeJet Pro X476dn HP OfficeJet Pro X576dw	
	AJH-971C	CN622A		C		
	AJH-971M	CN623A		M		
	AJH-971Y	CN624A		Y		
	AJH-970XLK	CN625A		BK		
	AJH-971XLC	CN626A		C		
	AJH-971XLM	CN627A		M		
	AJH-971XLY	CN628A		Y		
HP 960	AJH-960K	CZ665AA	WW	BK	HP OfficeJet Pro 3610	
	AJH-960XLK	CZ666AA		BK	HP OfficeJet Pro 3620	
HP 711	AJH-711XLK	CZ133A	WW	BK	HP DesignJet T120 HP DesignJet T520	
	AJH-711C	CZ130A		C		
	AJH-711M	CZ131A		M		
	AJH-711Y	CZ132A		Y		
HP 980	AJH-980K	D8J10A	WW	BK	HP OfficeJet Enterprise X555xh/dn HP OfficeJet Enterprise Color Flow X585z/dn/f	
	AJH-980C	D8J07A		C		
	AJH-980M	D8J08A		M		
	AJH-980Y	D8J09A		Y		
HP 934	AJH-934K	C2P19A	WW	BK	HP OfficeJet Pro 6230 ePrinter HP OfficeJet Pro 6830 e-All-in-One HP OfficeJet 6815 e-AiO Printer HP OfficeJet 6812 e-AiO Printer HP OfficeJet Pro 6835 e-AiO printer HP OfficeJet 6820 e-tout-en-un	
	AJH-935C	C2P20A		C		
	AJH-935M	C2P21A		M		
	AJH-935Y	C2P22A		Y		
	AJH-934XLK	C2P23A		BK		
	AJH-935XLC	C2P24A		C		
	AJH-935XLM	C2P25A		M		
	AJH-935XLY	C2P26A		Y		
HP 902 (only applicable in recycled cartridges)	AJH-906XLK	T6M18AN	NA	BK	HP OfficeJet 6960 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6968 All-in-One Printer HP OfficeJet Pro 6975 All-in-One Printer HP OfficeJet Pro 6978 All-in-One Printer	
	AJH-902XLK	T6M14AN		BK	HP OfficeJet 6954 All-in-One Printer HP OfficeJet 6960 All-in-One Printer HP OfficeJet 6962 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6968 All-in-One Printer HP OfficeJet Pro 6975 All-in-One Printer HP OfficeJet Pro 6978 All-in-One Printer	
	AJH-902XLC	T6M02AN		C		
	AJH-902XLM	T6M06AN		M		
	AJH-902XLY	T6M10AN		Y		
	AJH-902K	T6L98AN		BK		

HP 903 (only applicable in recycled cartridges)	AJH-907XLK	T6M19AE	EUR	BK	HP OfficeJet 6960 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6970 All-in-One Printer
	AJH-903XLK	T6M15AE		BK	HP OfficeJet 6950 All-in-One Printer HP OfficeJet 6960 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6970 All-in-One Printer
	AJH-903XLC	T6M03AE		C	
	AJH-903XLM	T6M07AE		M	
	AJH-903XLY	T6M11AE		Y	
	AJH-903K	T6L99AE		BK	
HP 905 (only applicable in recycled cartridges)	AJH-909XLK	T6M21AA	AP	BK	HP OfficeJet 6960 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6970 All-in-One Printer
	AJH-905XLK	T6M17AA		BK	HP OfficeJet 6960 All-in-One Printer HP OfficeJet Pro 6960 All-in-One Printer HP OfficeJet Pro 6970 All-in-One Printer
	AJH-905XLC	T6M05AA		C	
	AJH-905XLM	T6M09AA		M	
	AJH-905XLY	T6M13AA		Y	
	AJH-905K	T6M01AA		BK	
HP 904 (only applicable in recycled cartridges)	AJH-908XLK	T6M20AL	SA	BK	HP OfficeJet Pro 6970 All-in-One Printer
	AJH-904XLK	T6M16AL		BK	
	AJH-904XLC	T6M04AL		C	
	AJH-904XLM	T6M08AL		M	
	AJH-904XLY	T6M12AL		Y	
	AJH-904K	T6M00AL		BK	
HP 952 (only applicable in recycled cartridges)	AJH-956XLBK	L0R39AN	NA	BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 8216 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer
	AJH-952XLK	F6U19AN		BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 7740 Wide Format All-in-One Printer HP OfficeJet Pro 8210 All-in-One Printer
	AJH-952XLC	L0S61AN		C	HP OfficeJet Pro 8216 All-in-One Printer HP OfficeJet Pro 8702 All-in-One Printer
	AJH-952XLM	L0S64AN		M	HP OfficeJet Pro 8710 All-in-One Printer HP OfficeJet Pro 8715 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer
	AJH-952XLY	L0S67AN		Y	HP OfficeJet Pro 8725 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer
	AJH-957XLK	L0R40AE		BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 7730 Wide Format All-in-One Printer HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8218 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer HP OfficeJet Pro 8728 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer

HP 953 (only applicable in recycled cartridges)	AJH-953XLK	L0S70AE	EUR	BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 7730 Wide Format All-in-One Printer HP OfficeJet Pro 7740 Wide Format All-in-One Printer
	AJH-953XLC	F6U16AE		C	HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8218 All-in-One Printer HP OfficeJet Pro 8710 All-in-One Printer HP OfficeJet Pro 8715 All-in-One Printer
	AJH-953XLM	F6U17AE		M	HP OfficeJet Pro 8718 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer
	AJH-953XLY	F6U18AE		Y	HP OfficeJet Pro 8728 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer
HP 955 (only applicable in recycled cartridges)	AJH-959XLK	L0R42AA	AP	BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 7730 Wide Format All-in-One Printer HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer HP OfficeJet Pro 8745 All-in-One Printer
	AJH-955XLK	L0S72AA		BK	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 7730 Wide Format All-in-One Printer HP OfficeJet Pro 7740 Wide Format All-in-One Printer
	AJH-955XLC	L0S63AA		C	HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8216 All-in-One Printer
	AJH-955XLM	L0S66AA		M	HP OfficeJet Pro 8710 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer
	AJH-955XLY	L0S69AA		Y	HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer HP OfficeJet Pro 8745 All-in-One Printer
HP 954 (only applicable in recycled cartridges)	AJH-958XLK	L0R41AL	SA	BK	HP OfficeJet Pro 7720 de gran formato HP OfficeJet Pro 8720 HP OfficeJet Pro 8730
	AJH-954XLK	L0S71AL		BK	HP OfficeJet Pro 7720 de gran formato
	AJH-954XLC	L0S62AL		C	HP OfficeJet 7740 Todo-en-Uno de formato ancho HP OfficeJet Pro 8210
	AJH-954XLM	L0S65AL		M	HP OfficeJet Pro 8710 HP OfficeJet Pro 8720
	AJH-954XLY	L0S68AL		Y	HP OfficeJet Pro 8730
HP 972 (only applicable in recycled cartridges)	AJH-972XLK	F6T84AN	NA	BK	HP pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw
	AJH-972XLC	L0R98AN		C	HP PageWide Pro 552dn/dw
	AJH-972XLM	L0S01AN		M	HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw
	AJH-972XLY	L0S04AN		Y	HP PageWide Managed MFP P57750dw
	AJH-972K	F6T80AN		BK	HP Pagewide 352dw HP Pagewide MFP 377dw
	AJH-972C	L0R86AN		C	HP Pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw
	AJH-972M	L0R89AN		M	HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z
	AJH-972Y	L0R92AN		Y	HP PageWide Managed P55250dw HP PageWide Managed P57750dw

HP 973 (only applicable in recycled cartridges)	AJH-973XLK	L0S07AE	EUR	BK	HP PageWide pro 452dn/dw
	AJH-973XLC	F6T81AE		C	HP PageWide Pro MFP 477dn/dw HP PageWide Pro 552dw
	AJH-973XLM	F6T82AE		M	HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw
	AJH-973XLY	F6T83AE		Y	HP PageWide Managed MFP P57750dw
	AJH-913K	L0R95AE		BK	HP PageWide 352dw HP PageWide MFP 377dw
	AJH-913C	F6T77AE		C	HP PageWide pro 452dn/dw HP PageWide Pro MFP 477dn/dw
	AJH-913M	F6T78AE		M	HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z
	AJH-913Y	F6T79AE		Y	HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
HP 975 (only applicable in recycled cartridges)	AJH-975XLK	L0S09AA	AP	BK	HP PageWide Pro 452dn/dw
	AJH-975XLC	L0S00AA		C	HP PageWide Pro MFP 477dw/dn HP PageWide Pro 552dw
	AJH-975XLM	L0S03AA		M	HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw
	AJH-975XLY	L0S06AA		Y	HP PageWide Managed MFP P57750dw
	AJH-975K	L0R97AA		BK	HP Pagewide 352dw HP Pagewide MFP 377dw/dn
	AJH-975C	L0R88AA		C	HP PageWide Pro 452dw/dn HP PageWide Pro MFP 477dw/dn
	AJH-975M	L0R91AA		M	HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/Z
	AJH-975Y	L0R94AA		Y	HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
HP 974 (only applicable in recycled cartridges)	AJH-974XLK	L0S08AL	SA	BK	HP PageWide Pro 452dw
	AJH-974XLC	L0R99AL		C	HP PageWide Pro MFP 477dw HP PageWide Pro 552dw
	AJH-974XLM	L0S02AL		M	HP PageWide Pro MFP 577dw HP PageWide Managed P55250dw
	AJH-974XLY	L0S05AL		Y	HP PageWide Managed MFP P57750dw
	AJH-974K	L0R96AL		BK	HP Pagewide 352dw HP Pagewide MFP 377dw
	AJH-974C	L0R87AL		C	HP PageWide Pro 452dw HP PageWide Pro MFP 477dw
	AJH-974M	L0R90AL		M	HP PageWide Pro 552dw HP PageWide Pro MFP 577dw
	AJH-974Y	L0R93AL		Y	HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
HP 976Y (only applicable in recycled cartridges)	AJH-976YK	L0R08A	WW	BK	HP PageWide Pro 552dw/dn
	AJH-976YC	L0R05A		C	HP PageWide Pro MFP 577dw/z
	AJH-976YM	L0R06A		M	HP PageWide Managed P55250dw
	AJH-976YY	L0R07A		Y	HP PageWide Managed MFP P57750dw
	AJH-843BK	C1Q61A	AP	BK	HP PageWide XL 4000 Printer Series
	AJH-843BC	C1Q62A		C	HP PageWide XL 4100 Printer Series
	AJH-843BM	C1Q63A		M	HP PageWide XL 4500 Printer Series
	AJH-843BY	C1Q64A		Y	HP PageWide XL 5100 Printer Series



HP 843	AJH-843AK	C1Q57A	NA	BK	HP Pagewide XL 4100 MFP HP Pagewide XL 4100 Printer
	AJH-843AC	C1Q58A		C	HP PageWide XL 4500
	AJH-843AM	C1Q59A		M	HP Pagewide XL 4600 MFP HP Pagewide XL 4600 Printer
	AJH-843AY	C1Q60A		Y	HP PageWide XL 5100 MFP High Capacity Stacker HP PageWide XL 6000 Printer
	AJH-848AK	F9J82A	NA	BK	HP PageWide XL 5000 Printer Series HP PageWide XL 5100 Printer Series
	AJH-848AC	F9J83A		C	
	AJH-848AM	F9J84A		M	
	AJH-848AY	F9J85A		Y	
HP 981 (only applicable in recycled cartridges)	AJH-981YK	L0R16A	WW	BK	HP PageWide Enterprise Color 556xh/dn HP PageWide Enterprise Color MFP 586dn/f/z HP PageWide Managed Color MFP E58650dn (NA) HP PageWide Managed Color MFP E55650 (AP)
	AJH-981YC	L0R13A		C	
	AJH-981YM	L0R14A		M	
	AJH-981YY	L0R15A		Y	
	AJH-981XLK	L0R12A		BK	
	AJH-981XLC	L0R09A		C	
	AJH-981XLM	L0R10A		M	
	AJH-981XLY	L0R11A		Y	
	AJH-981K	J3M71A		BK	
	AJH-981C	J3M68A		C	
	AJH-981M	J3M69A		M	
	AJH-981Y	J3M70A		Y	
	HP 990 (only applicable in recycled cartridges)	AJH-990XK		M0K01AN	
AJH-990XC		M0J89AN	C		
AJH-990XM		M0J93AN	M		
AJH-990XY		M0J97AN	Y		
HP 991 (only applicable in recycled cartridges)	AJH-991XK	M0K02AE	EUR	BK	HP PageWide Pro MFP 777z HP PageWide Pro MFP 772dn HP PageWide Pro 750dw
	AJH-991XC	M0J90AE		C	
	AJH-991XM	M0J94AE		M	
	AJH-991XY	M0J98AE		Y	
HP 992 (only applicable in recycled cartridges)	AJH-992XK	M0K03AL	SA	BK	HP PageWide Color MFP 774dn/dns HP PageWide Color MFP 779dn/dns HP PageWide Color 755dn
	AJH-992XC	M0J91AL		C	
	AJH-992XM	M0J95AL		M	
	AJH-992XY	M0J99AL		Y	
HP 993 (only applicable in recycled cartridges)	AJH-993XK	M0K04AA	AP	BK	
	AJH-993XC	M0J92AA		C	
	AJH-993XM	M0J96AA		M	
	AJH-993XY	M0K00AA		Y	
HP 982 (only applicable in recycled cartridges)	AJH-982XK	T0B30A	WW	BK	HP PageWide Enterprise Color 765dn HP PageWide Enterprise Color MFP 780dn HP PageWide Enterprise Color Flow MFP 785f/zs HP PageWide Enterprise Color Flow MFP 785z+
	AJH-982XC	T0B27A		C	
	AJH-982XM	T0B28A		M	
	AJH-982XY	T0B29A		Y	
HP 993 (only applicable in recycled cartridges)	AJH-W1B44A	W1B44A	WW	/	HP PageWide Pro MFP 777z HP PageWide Pro MFP 772dn HP PageWide Pro 750dw HP PageWide Color MFP 774dn/dns HP PageWide Color MFP 779dn/dns HP PageWide Color 755dn HP PageWide Enterprise Color 765dn HP PageWide Enterprise Color MFP 780dn HP PageWide Enterprise Color Flow MFP 785f/zs/z+

HP 962	AJH-966XLK	3JA04AN	NA	BK	HP OfficeJet Pro 9020 All-in-One Printer HP OfficeJet Pro 9025 All-in-One Printer
	AJH-962XLK	3JA03AN		BK	HP OfficeJet Pro 9010 All-in-One Printer
	AJH-962XLC	3JA00AN		C	HP OfficeJet Pro 9012 All-in-One Printer
	AJH-962XLM	3JA01AN		M	HP OfficeJet Pro 9015 All-in-One Printer
	AJH-962XLY	3JA02AN		Y	HP OfficeJet Pro 9016 All-in-One Printer
	AJH-962K	3HZ99AN		BK	HP OfficeJet Pro 9018 All-in-One Printer
	AJH-962C	3HZ96AN		C	HP OfficeJet Pro 9019 All-in-One Printer
	AJH-962M	3HZ97AN		M	HP OfficeJet Pro 9020 All-in-One Printer
	AJH-962Y	3HZ98AN		Y	HP OfficeJet Pro 9025 All-in-One Printer
HP 963	AJH-967XLK	3JA31AE	EUR	BK	HP OfficeJet Pro 9020 All-in-One Printer HP OfficeJet Pro 9022 All-in-One Printer HP OfficeJet Pro 9025 All-in-One Printer
	AJH-963XLK	3JA30AE		BK	HP OfficeJet Pro 9010 All-in-One Printer
	AJH-963XLC	3JA27AE		C	HP OfficeJet Pro 9012 All-in-One Printer
	AJH-963XLM	3JA28AE		M	HP OfficeJet Pro 9014 All-in-One Printer
	AJH-963XLY	3JA29AE		Y	HP OfficeJet Pro 9015 All-in-One Printer
	AJH-963K	3JA26AE		BK	HP OfficeJet Pro 9016 All-in-One Printer
	AJH-963C	3JA23AE		C	HP OfficeJet Pro 9019 All-in-One Printer
	AJH-963M	3JA24AE		M	HP OfficeJet Pro 9020 All-in-One Printer
	AJH-963Y	3JA25AE		Y	HP OfficeJet Pro 9022 All-in-One Printer HP OfficeJet Pro 9025 All-in-One Printer
HP 964	AJH-964XLK	3JA57AL	SA	BK	HP OfficeJet Pro 9010 All-in-One Printer HP OfficeJet Pro 9016 All-in-One Printer HP OfficeJet Pro 9018 All-in-One Printer HP OfficeJet Pro 9020 All-in-One Printer
	AJH-964XLC	3JA54AL		C	
	AJH-964XLM	3JA55AL		M	
	AJH-964XLY	3JA56AL		Y	
	AJH-964K	3JA53AL		BK	
	AJH-964C	3JA50AL		C	
	AJH-964M	3JA51AL		M	
HP 965	AJH-969XLK	3JA85AA	AP	Y	HP OfficeJet Pro 9010 All-in-One Printer HP OfficeJet Pro 9016 All-in-One Printer HP OfficeJet Pro 9018 All-in-One Printer HP OfficeJet Pro 9019 All-in-One Printer HP OfficeJet Pro 9020 All-in-One Printer HP OfficeJet Pro 9026 All-in-One Printer HP OfficeJet Pro 9028 All-in-One Printer
	AJH-965XLK	3JA84AA		BK	
	AJH-965XLC	3JA81AA		C	
	AJH-965XLM	3JA82AA		M	
	AJH-965XLY	3JA83AA		Y	
	AJH-965K	3JA80AA		BK	
	AJH-965C	3JA77AA		C	
	AJH-965M	3JA78AA		M	
	AJH-965Y	3JA79AA		Y	
HP 910	AJH-916XLK	3YL66AN	NA	BK	HP OfficeJet Pro 8035 All-in-One Printer
	AJH-910XLK	3YL65AN		BK	HP OfficeJet 8010 All-in-One Printer
	AJH-910XLC	3YL62AN		C	HP OfficeJet 8015 All-in-One Printer
	AJH-910XLM	3YL63AN		M	HP OfficeJet 8018 All-in-One Printer
	AJH-910XLY	3YL64AN		Y	HP OfficeJet 8022 All-in-One Printer
	AJH-910K	3YL61AN		BK	HP OfficeJet Pro 8020 All-in-One Printer
	AJH-910C	3YL58AN		C	HP OfficeJet Pro 8025 All-in-One Printer
	AJH-910M	3YL59AN		M	HP OfficeJet Pro 8028 All-in-One Printer
	AJH-910Y	3YL60AN		Y	HP OfficeJet Pro 8035 All-in-One Printer
	AJH-917XLK	3YL85AE		BK	HP OfficeJet Pro 8022 All-in-One Printer HP OfficeJet Pro 8023 All-in-One Printer HP OfficeJet Pro 8024 All-in-One Printer HP OfficeJet Pro 8025 All-in-One Printer



HP 912	AJH-912XLK	3YL84AE	EUR	BK	HP OfficeJet 8012 All-in-One Printer HP OfficeJet 8014 All-in-One Printer HP OfficeJet 8015 All-in-One Printer HP OfficeJet 8017 All-in-One Printer HP OfficeJet Pro 8022 All-in-One Printer HP OfficeJet Pro 8023 All-in-One Printer HP OfficeJet Pro 8024 All-in-One Printer HP OfficeJet Pro 8025 All-in-One Printer		
	AJH-912XLC	3YL81AE		C			
	AJH-912XLM	3YL82AE		M			
	AJH-912XLY	3YL83AE		Y			
	AJH-912K	3YL80AE		BK			
	AJH-912C	3YL77AE		C			
	AJH-912M	3YL78AE		M			
	AJH-912Y	3YL79AE		Y			
HP 915	AJH-919XLK	3YM23AA	AP	BK	HP OfficeJet Pro 8020 All-in-One Printer HP OfficeJet Pro 8022 All-in-One Printer HP OfficeJet Pro 8026 All-in-One Printer HP OfficeJet Pro 8028 All-in-One Printer		
	AJH-915XLK	3YM22AA		BK			
	AJH-915XLC	3YM19AA		C			
	AJH-915XLM	3YM20AA		M			
	AJH-915XLY	3YM21AA		Y			
	AJH-915K	3YM18AA		BK			
	AJH-915C	3YM15AA		C			
	AJH-915M	3YM16AA		M			
AJH-915Y	3YM17AA	Y					
HP 745	AJH-745XLK	F9K05A	WW	BK/MBK	HP DesignJet Z2600 24-in PostScript Printer HP DesignJet Z5600 44-in PostScript Printer		
	AJH-745XLC	F9K03A		C			
	AJH-745XLM	F9K01A		M			
	AJH-745XLY	F9K02A		Y			
	AJH-745XLPK	F9K04A		PBK			
	AJH-745XLR	F9K06A		RED/R			
	AJH-745K	F9J99A		BK/MBK			
	AJH-745C	F9J97A		C			
	AJH-745M	F9J95A		M			
	AJH-745Y	F9J96A		Y			
	AJH-745PK	F9J98A		PBK			
	AJH-745R	F9K00A		RED/R			
HP 746	AJH-746XLK	P2V83A	AP/ NA/EUR	BK	HP DesignJet Z9+ Large Format Printer HP DesignJet Z6 Large Format Printer HP DesignJet Z6dr Large Format Dual-Roll PostScript® Graphics Printer		
	AJH-746XLC	3WX36A/P2V80A		C			
	AJH-746XLM	3WX37A/P2V78A		M			
	AJH-746XLY	3WX38A/P2V79A		Y			
	AJH-746XLPK	3WX35A/P2V82A	WW	PBK			HP DesignJet Z9+
	AJH-746XLR	P2V81A		RED/R			
	AJH-747B	P2V85A		B			
	AJH-747GY	P2V86A		GY			
AJH-747G	P2V84A	G					
for Primera Series Inkjet Cartridge							
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo		
AJP-53425	53425BK	/	BK	Primera LX900			
AJP-53422	53422C		C				
AJP-53423	53423M		M				
AJP-53424	53424Y		Y				
AJP-53604	53604BK	/	BK	Primera Bravo 4100			
AJP-53601	53601C		C				
AJP-53602	53602M		M				
AJP-53603	53603Y		Y				

AJP-53464	53464 K	/	BK	Primera LX1000/LX2000	
AJP-53461	53461 C		C		
AJP-53462	53462 M		M		
AJP-53463	53463 Y		Y		
for Brother I Series Cartridge					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC110BK	LC110BK	JPN	BK	Brother DCP-J152N Brother DCP-J132N Brother DCP-J137N	
AJB-LC110C	LC110C		C		
AJB-LC110M	LC110M		M		
AJB-LC110Y	LC110Y		Y		
AJB-LC111BK	LC111BK		BK	Brother MFC-J980DN/DWN Brother MFC-J870N/J890DN/DWN Brother MFC-J820DN/J827DWN /J720/727D/DW Brother DCP-J952N/J752N/J552NW/J957N-B/W Brother MFC-J877N/J987DN/DW Brother MFC-J897DNDWN/J827DN/DWN /J727D/DW Brother DCP-J757N/J557	
AJB-LC111C	LC111C		C		
AJB-LC111M	LC111M		M		
AJB-LC111Y	LC111Y		Y		
AJB-LC113BK	LC113BK		BK	Brother MFC-J4910CDW/J4810DN /J4510N Brother DCP-J4215N/J4210N Brother MFC-J6975CDW/J6970CDW Brother MFC-J6770CDW/J6570CDW Brother MFC-J6573CDW Brother MFC-J6973CD	
AJB-LC113C	LC113C		C		
AJB-LC113M	LC113M		M		
AJB-LC113Y	LC113Y		Y		
AJB-LC115C	LC115C		C	Brother MFC-J4910CDW/J4810DN/J4510N Brother DCP-J4215N/J4210N	
AJB-LC115M	LC115M		M		
AJB-LC115Y	LC115Y		Y		
AJB-LC117BK	LC117BK		BK	Brother MFC-J4910CDW/J4810DN/J4510N Brother DCP-J4215N/J4210N	
AJB-LC119BK	LC119BK		BK		
AJB-LC121BK	LC121BK	EUR	BK	Brother DCP-J132W/J152W/J552W Brother DCP-J172W/J752W Brother MFC-J870DW/J650DW/J470DW	
AJB-LC121C	LC121C		C		
AJB-LC121M	LC121M		M		
AJB-LC121Y	LC121Y		Y		
AJB-LC123BK	LC123BK		BK	Brother DCP-J132W/J152W/J552W Brother DCP-J172W/J752W Brother MFC-J870DW/J650DW/J470DW Brother DCP-J4110DW Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW Brother MFC-J6920DW/J6720DW/J6520DW	
AJB-LC123C	LC123C		C		
AJB-LC123M	LC123M		M		
AJB-LC123Y	LC123Y		Y		
AJB-LC125C	LC125C		C	Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW Brother MFC-J6920DW/J6720DW/J6520DW	
AJB-LC125M	LC125M		M		
AJB-LC125Y	LC125Y		Y		
AJB-LC127BK	LC127BK		BK	Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW Brother MFC-J6920DW/J6720DW/J6520DW	
AJB-LC129BK	LC129BK		BK		
AJB-LC101BK	LC101BK	USA	BK	Brother DCP-J152W Brother MFC-J245/J285DW/J450DW/J470DW/J475DW Brother MFC-J650DW/J870DW/J875DW	
AJB-LC101C	LC101C		C		
AJB-LC101M	LC101M		M		
AJB-LC101Y	LC101Y		Y		
AJB-LC103BK	LC103BK		BK	Brother DCP-J152W Brother MFC-J245/J285DW/J450DW/J470DW/J475DW Brother MFC-J650DW/J870DW/J875DW Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW Brother MFC-J6520DW/J6720DW/J6920DW	
AJB-LC103C	LC103C		C		
AJB-LC103M	LC103M		M		
AJB-LC103Y	LC103Y		Y		

AJB-LC105C	LC105C	AP	C	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW
AJB-LC105M	LC105M		M	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC105Y	LC105Y		Y	
AJB-LC107BK	LC107BK		BK	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW
AJB-LC109BK	LC109BK		BK	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC563BK	LC563BK		BK	
AJB-LC563C	LC563C		C	
AJB-LC563M	LC563M		M	Brother MFC-J3720
AJB-LC563Y	LC563Y		Y	Brother MFC-J2510
AJB-LC565XLC	LC565XLC		C	Brother MFC-J2310
AJB-LC565XLM	LC565XLM	AUS	M	Brother MFC-J3520
AJB-LC565XLY	LC565XLY		Y	
AJB-LC567XLBK	LC567XLBK		BK	Brother MFC-J2510/MFC-J2310
AJB-LC569BK	LC569BK		BK	Brother MFC-J3720/MFC-J3520
AJB-LC131BK	LC131BK		BK	
AJB-LC131C	LC131C		C	Brother DCP-J152W/J552W/J752W/J172W
AJB-LC131M	LC131M		M	Brother MFC-J870DW/J650DW/J470DW
AJB-LC131Y	LC131Y		Y	
AJB-LC133BK	LC133BK		BK	Brother DCP-J152W/J552W/J752W/J172W
AJB-LC133C	LC133C		C	Brother MFC-J870DW/J650DW/J470DW
AJB-LC133M	LC133M	AP	M	Brother DCP-J4110DW
AJB-LC133Y	LC133Y		Y	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC135C	LC135C		C	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC135M	LC135M		C	Brother DCP-J4110DW
AJB-LC135Y	LC135Y		M	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC137BK	LC137BK		Y	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC139BK	LC139BK		BK	Brother DCP-J4110DW
AJB-LC161BK	LC161BK		M	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC161C	LC161C		Y	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC161M	LC161M	IND	BK	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC161Y	LC161Y		C	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC163BK	LC163BK		M	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC163C	LC163C		Y	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC163M	LC163M		BK	Brother MFC-J4410N/J4510N/J4710DW
AJB-LC163Y	LC163Y		BK	Brother MFC-J6520DW/J6720DW/J6920DW
AJB-LC583BK	LC583BK		C	Brother DCP-J152W
AJB-LC583C	LC583C		M	Brother DCP-J752DW
AJB-LC583M	LC583M		Y	Brother MFC-J245
AJB-LC583Y	LC583Y		BK	Brother MFC-J470DW
AJB-LC589XLBK	LC589XLBK	USA	C	Brother MFC-650DW
AJB-LC585XLC	LC585XLC		M	Brother MFC-J870DW
AJB-LC585XLM	LC585XLM		Y	
AJB-LC585XLY	LC585XLY		BK	Brother MFC-J3720
AJB-LC10EBK	LC10EBK		C	Brother MFC-J3520
AJB-LC10EC	LC10EC		M	
AJB-LC10EM	LC10EM		Y	
AJB-LC10EY	LC10EY		BK	
AJB-LC12EBK	LC12EBK		C	
AJB-LC12EC	LC12EC	EUR	M	Brother MFC-J6925DW
AJB-LC12EM	LC12EM		Y	
AJB-LC12EY	LC12EY		BK	
AJB-LC15EBK	LC15EBK		C	
AJB-LC15EC	LC15EC		M	
AJB-LC15EM	LC15EM		Y	
AJB-LC15EY	LC15EY		BK	
			C	
			M	
			Y	

For Brother I Series CISS Chip					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC103BKR	LC103BK	USA	BK	Brother DCP-J152W	
AJB-LC103CR	LC103C		C	Brother MFC-J245/J285DW/J450DW/J470DW/J475DW	
AJB-LC103MR	LC103M		M	Brother MFC-J650DW/J870DW/J875DW	
AJB-LC103YR	LC103Y		Y	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW	
AJB-LC105CR	LC105C		C	Brother MFC-J6520DW/J6720DW/J6920DW	
AJB-LC105MR	LC105M		M	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW	
AJB-LC105YR	LC105Y		Y	Brother MFC-J6520DW/J6720DW/J6920DW	
AJB-LC107BKR	LC107BK		BK		
AJB-LC109BKR	LC109BK		BK	Brother MFC-J6520DW/J6720DW/J6920DW	
AJB-LC111BKR	LC111BK	JPN	BK	Brother MFC-J980DN/DWN	
AJB-LC111CR	LC111C		C	Brother MFC-J870N/J890DN/DWN	
AJB-LC111MR	LC111M		M	Brother MFC-J820DN/J827DWN/J720/J727D/DW	
AJB-LC111YR	LC111Y		Y	Brother DCP-J952N/J752N/J552NW/J957N-B/W	
AJB-LC113BKR	LC113BK		BK	Brother MFC-J877N/J987DN/DW	
AJB-LC113CR	LC113C		C	Brother MFC-J897DNDWN/J827DN/DWN/J727D/DW	
AJB-LC113MR	LC113M		M	Brother DCP-J757N/J557	
AJB-LC113YR	LC113Y		Y		
AJB-LC115CR	LC115C		C	Brother MFC-J4910CDW/J4810DN/J4510N	
AJB-LC115MR	LC115M		M	Brother DCP-J4215N/J4210N	
AJB-LC115YR	LC115Y		Y	Brother MFC-J6975CDW/J6970CDW	
AJB-LC117BKR	LC117BK		BK	Brother MFC-J6770CDW/J6570CDW	
AJB-LC123BKR	LC123BK	EUR	BK	Brother MFC-J4910CDW/J4810DN/J4510N	
AJB-LC123CR	LC123C		C	Brother DCP-J132W/J152W/J552W	
AJB-LC123MR	LC123M		M	Brother DCP-J172W/J752W	
AJB-LC123YR	LC123Y		Y	Brother MFC-J870DW/J650DW/J470DW	
AJB-LC125CR	LC125C		C	Brother DCP-J4110DW	
AJB-LC125MR	LC125M		M	Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW	
AJB-LC125YR	LC125Y		Y	Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW	
AJB-LC127BKR	LC127BK		BK	Brother MFC-J6920DW/J6720DW/J6520DW	
AJB-LC133BKR	LC133BK		BK	Brother MFC-J4410DW/J4510DW/J4610DW/J4710DW	
AJB-LC133CR	LC133C		C	Brother DCP-J152W/J552W/J752W/J172W	
AJB-LC133MR	LC133M	AUS	M	Brother MFC-J870DW/J650DW/J470DW	
AJB-LC133YR	LC133Y		Y	Brother DCP-J4110DW	
AJB-LC163BKR	LC163BK		BK	Brother MFC-J4410N/J4510N/J4710DW	
AJB-LC163CR	LC163C		C	Brother MFC-J6520DW/J6720DW/J6920DW	
AJB-LC163MR	LC163M	AP	M	Brother DCP-J152W	
AJB-LC163YR	LC163Y		Y	Brother DCP-J752DW	
AJB-LC563BKR	LC563BK		BK	Brother MFC-J245	
AJB-LC563CR	LC563C		C	Brother MFC-J470DW	
AJB-LC563MR	LC563M		M	Brother MFC-650DW	
AJB-LC563YR	LC563Y		Y	Brother MFC-J870DW(HK)	
AJB-LC567BKR	LC567BK		BK	Brother MFC-J3720	
			C	Brother MFC-J2510	
			M	Brother MFC-J2310	
			Y	Brother MFC-J3520	
			BK	Brother MFC-J2510/J2310	

For Brother II Series Cartridge					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC209XXLBK	LC209XXLBK	USA	BK	Brother MFC-J5520DW/J5620DW/J5720DW	
AJB-LC207XXLBK	LC207XXLBK		BK	Brother MFC-J4320DW/J4420DW/J4620DW	
AJB-LC205XXLC	LC205XXLC		C	Brother MFCJ4320DW/J4420DW/J4620DW Brother MFCJ5520DW/J5620DW/J5720DW	
AJB-LC205XXLM	LC205XXLM		M		
AJB-LC205XXLY	LC205XXLY		Y		
AJB-LC203BK	LC203BK		BK	Brother MFCJ4320DW/J4420DW/J4620DW Brother MFCJ5520DW/J5620DW/J5720DW Brother MFC-J460DW/MFC-J480DW/MFC-J485DW/MFC-J680DW/MFC-J880DW/MFC-J885DW	
AJB-LC203C	LC203C		C		
AJB-LC203M	LC203M		M		
AJB-LC203Y	LC203Y		Y		
AJB-LC201BK	LC201BK		BK		
AJB-LC201C	LC201C		C		
AJB-LC201M	LC201M		M		
AJB-LC201Y	LC201Y		Y		
AJB-LC229XLBK	LC229XLBK		EUR	BK	
AJB-LC227XLBK	LC227XLBK	BK		Brother DCP-4120DW Brother MFC-J4420DW/J4620DW/J4625DW	
AJB-LC225XLC	LC225XLC	C		Brother DCP-4120DW	
AJB-LC225XLM	LC225XLM	M		Brother MFC-J4420DW/J4620DW/J4625DW	
AJB-LC225XLY	LC225XLY	Y		Brother MFC-J5320DW/ J5620DW/J5625DW/J5720DW	
AJB-LC223BK	LC223BK	BK		Brother DCP-4120DW Brother MFC-J4420DW/J4620DW/J4625DW Brother MFC-J5320DW/ J5620DW/J5625DW/J5720DW Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW	
AJB-LC223C	LC223C	C			
AJB-LC223M	LC223M	M			
AJB-LC223Y	LC223Y	Y			
AJB-LC221BK	LC221BK	BK			
AJB-LC221C	LC221C	C			
AJB-LC221M	LC221M	M			
AJB-LC221Y	LC221Y	Y			
AJB-LC219XLBK	LC219XLBK	JPN		BK	
AJB-LC217XLBK	LC217XLBK		BK	Brother DCP-J4220N-B/W Brother MFC-J4720N	
AJB-LC215XLC	LC215XLC		C	Brother DCP-J4220N-B/W/4225N-W/B Brother MFC-J4720N/J4725N Brother MFC-J5620CDW/J5720CDW/J5820DW	
AJB-LC215XLM	LC215XLM		M		
AJB-LC215XLY	LC215XLY		Y		
AJB-LC213BK	LC213BK		BK		
AJB-LC213C	LC213C		C	Brother DCP-J963N-W/B/DCP-J962N/DCP-J968N-B Brother DCP-J762N/J562N Brother MFC-J880N/J730DW/J830DW/J900DW/J990DW/J968N-W Brother DCP-J968N-W/B/J767N/J567N Brother MFC-J887N/J837DN/DWN/J907DN/DWN/J997DN/DWN/J737DN/DWN	
AJB-LC213M	LC213M		M		
AJB-LC213Y	LC213Y		Y		
AJB-LC211BK	LC211BK		BK		
AJB-LC211C	LC211C		C	Brother MFC-J2320 Brother MFC-J2720(HK)	
AJB-LC211M	LC211M		M		
AJB-LC211Y	LC211Y		Y		
AJB-LC669XLBK	LC669XLBK		AP	BK	Brother MFC-J2320 Brother MFC-J2720(HK)
AJB-LC665XLC	LC665XLC	C			
AJB-LC665XLM	LC665XLM	M			
AJB-LC665XLY	LC665XLY	Y			
AJB-LC663BK	LC663BK	BK			
AJB-LC663C	LC663C	C			
AJB-LC663M	LC663M	M			
AJB-LC663Y	LC663Y	Y			
AJB-LC261BK	LC261BK	BK			
AJB-LC261C	LC261C	C			
AJB-LC261M	LC261M	M			

AJB-LC261Y	LC261Y		Y	Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW	
AJB-LC263BK	LC263BK		BK		
AJB-LC263C	LC263C		C		
AJB-LC263M	LC263M		M		
AJB-LC263Y	LC263Y		Y		
AJB-LC239XLBK	LC239XLBK	AUS	BK	Brother MFC-J5320 Brother MFC-J5720	
AJB-LC237XLBK	LC237XLBK		BK	Brother MFC-J4120 Brother MFC-J4620	
AJB-LC235XLC	LC235XLC		C	Brother MFC-J5720	
AJB-LC235XLM	LC235XLM		M	Brother MFC-J4120 Brother MFC-J4620	
AJB-LC235XLY	LC235XLY		Y	Brother MFC-J5320	
AJB-LC233BK	LC233BK		BK	Brother DCP-J562DW Brother MFC-J5720/J4120/J4620/J5320 Brother MFC-J480DW/J680DW/J880DW	
AJB-LC233C	LC233C		C		
AJB-LC233M	LC233M		M		
AJB-LC233Y	LC233Y		Y		
AJB-LC231BK	LC231BK		BK		
AJB-LC231C	LC231C		C		
AJB-LC231M	LC231M		M		
AJB-LC231Y	LC231Y		Y		
AJB-LC679XLBK	LC679XLBK		SA	BK	Brother MFC-J2720/J2320
AJB-LC675XLC	LC675XLC			C	
AJB-LC675XLM	LC675XLM			M	
AJB-LC675XLY	LC675XLY			Y	
AJB-LC673BK	LC673BK			BK	
AJB-LC673C	LC673C			C	
AJB-LC673M	LC673M			M	
AJB-LC673Y	LC673Y	Y			
AJB-LC20EBK	LC20EBK	USA	BK	Brother MFC-J5920DW Brother MFC-J985DW/J985DWXL	
AJB-LC20EC	LC20EC		C		
AJB-LC20EM	LC20EM		M		
AJB-LC20EY	LC20EY		Y		
AJB-LC21EBK	LC21EBK	JPN	BK	Brother DCP-J983N	
AJB-LC21EC	LC21EC		C		
AJB-LC21EM	LC21EM		M		
AJB-LC21EY	LC21EY		Y		
AJB-LC22EBK	LC22EBK	EUR	BK	Brother MFC-J5920DW	
AJB-LC22EC	LC22EC		C		
AJB-LC22EM	LC22EM		M		
AJB-LC22EY	LC22EY		Y		
AJB-LC22UBK	LC22UBK	EUR	BK	Brother MFC-J985DW/DCP-J785DW	
AJB-LC22UC	LC22UC		C		
AJB-LC22UM	LC22UM		M		
AJB-LC22UY	LC22UY		Y		
AJB-LC23EBK	LC23EBK	AU	BK	Brother MFC-J5920DW	
AJB-LC23EC	LC23EC		C		
AJB-LC23EM	LC23EM		M		
AJB-LC23EY	LC23EY		Y		
For Brother II Series CISS Chip					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC209XXLBKR	LC209XXLBK		BK	Brother MFC-J5520DW/J5620DW/J5720DW	
AJB-LC207XXLBKR	LC207XXLBK		BK	Brother MFC-J4320DW/J4420DW/J4620DW	
AJB-LC205XXLCR	LC205XXLC		C	Brother MFCJ4320DW/J4420DW/J4620DW Brother MFCJ5520DW/J5620DW/J5720DW	
AJB-LC205XXLMR	LC205XXLM		M		
AJB-LC205XXLYR	LC205XXLY		Y		

AJB-LC203BKR	LC203BK
AJB-LC203CR	LC203C
AJB-LC203MR	LC203M
AJB-LC203YR	LC203Y
AJB-LC201BKR	LC201BK
AJB-LC201CR	LC201C
AJB-LC201MR	LC201M
AJB-LC201YR	LC201Y
AJB-LC229XLBKR	LC229XLBK
AJB-LC227XLBKR	LC227XLBK
AJB-LC225XLCR	LC225XLC
AJB-LC225XLMR	LC225XLM
AJB-LC225XLYR	LC225XLY
AJB-LC223BKR	LC223BK
AJB-LC223CR	LC223C
AJB-LC223MR	LC223M
AJB-LC223YR	LC223Y
AJB-LC221BKR	LC221BK
AJB-LC221CR	LC221C
AJB-LC221MR	LC221M
AJB-LC221YR	LC221Y
AJB-LC219XLBKR	LC219XLBK
AJB-LC217XLBKR	LC217XLBK
AJB-LC215XLCR	LC215XLC
AJB-LC215XLMR	LC215XLM
AJB-LC215XLYR	LC215XLY
AJB-LC213BKR	LC213BK
AJB-LC213CR	LC213C
AJB-LC213MR	LC213M
AJB-LC213YR	LC213Y
AJB-LC211BKR	LC211BK
AJB-LC211CR	LC211C
AJB-LC211MR	LC211M
AJB-LC211YR	LC211Y
AJB-LC669XLBKR	LC669XLBK
AJB-LC665XLCR	LC665XLC
AJB-LC665XLMR	LC665XLM
AJB-LC665XLYR	LC665XLY
AJB-LC663BKR	LC663BK
AJB-LC663CR	LC663C
AJB-LC663MR	LC663M
AJB-LC663YR	LC663Y
AJB-LC261BKR	LC261BK
AJB-LC261CR	LC261C
AJB-LC261MR	LC261M
AJB-LC261YR	LC261Y
AJB-LC263BKR	LC263BK
AJB-LC263CR	LC263C
AJB-LC263MR	LC263M
AJB-LC263YR	LC263Y

USA	BK	Brother MFCJ4320DW/J4420DW/J4620DW Brother MFCJ5520DW/J5620DW/J5720DW Brother MFC-J460DW/MFC-J480DW/MFC-J485DW/MFC-J680DW/MFC-J880DW/MFC-J885DW
	C	
	M	
	Y	
	BK	
	C	
EUR	M	Brother DCP-4120DW Brother MFC-J4420DW/J4620DW/J4625DW Brother MFC-J5320DW/J5620DW/J5625DW/J5720DW
	Y	
	BK	
	C	
	M	Brother DCP-4120DW Brother MFC-J4420DW/J4620DW/J4625DW Brother MFC-J5320DW/J5620DW/J5625DW/J5720DW Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW
	Y	
	BK	
	C	
	M	
	Y	
JPN	BK	Brother MFC-J5620CDW/J5720CDW/J5820DW
	BK	Brother DCP-J4220N-B/W Brother MFC-J4720N
	C	Brother DCP-J4220N-B/W/4225N-W/B Brother MFC-J4720N/J4725N Brother MFC-J5620CDW/J5720CDW/J5820DW
	M	
	Y	
	BK	
	C	Brother DCP-J963N-W/B/DCP-J962N/DCP-J968N-B Brother DCP-J762N/J562N (JPN) Brother MFC-J880N/J730DW/J830DW/J900DW/J990DW/J968N-W Brother DCP-J968N-W/B/J767N/J567N Brother MFC-J887N/J837DN/DWN/J907DN/DWN/J997DN/DWN/J737DN/DWN
	M	
	Y	
	BK	
AP	C	Brother MFC-J2320 Brother MFC-J2720 (HK)
	M	
	Y	
	BK	
	C	Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW
	M	
	Y	
	BK	
	C	
	M	
	Y	
	BK	



AJB-LC239XLBKR	LC239XLBK	AUS	BK	Brother MFC-J5320 Brother MFC-J5720
AJB-LC237XLBKR	LC237XLBK		BK	Brother MFC-J4120 Brother MFC-J4620
AJB-LC235XLCR	LC235XLC		C	Brother MFC-J5720 Brother MFC-J4120 Brother MFC-J4620 Brother MFC-J5320
AJB-LC235XLMR	LC235XLM		M	
AJB-LC235XLYR	LC235XLY		Y	
AJB-LC233BKR	LC233BK		BK	
AJB-LC233CR	LC233C		C	
AJB-LC233MR	LC233M		M	
AJB-LC233YR	LC233Y		Y	
AJB-LC231BKR	LC231BK		BK	
AJB-LC231CR	LC231C		C	
AJB-LC231MR	LC231M		M	
AJB-LC231YR	LC231Y		Y	
AJB-LC679XLBKR	LC679XLBK	SA	BK	Brother MFC-J2720
AJB-LC675XLCR	LC675XLC		C	
AJB-LC675XLMR	LC675XLM		M	
AJB-LC675XLYR	LC675XLY		Y	
AJB-LC673BKR	LC673BK		BK	
AJB-LC673CR	LC673C		C	
AJB-LC673MR	LC673M		M	
AJB-LC673YR	LC673Y		Y	
AJB-LC20EBKR	LC20EBK	USA	BK	Brother MFC-J5920DW Brother MFC-J985DW/J985DWWXL
AJB-LC20ECR	LC20EC		C	
AJB-LC20EMR	LC20EM		M	
AJB-LC20EYR	LC20EY		Y	
AJB-LC21EBKR	LC21EBK	JPN	BK	Brother DCP-J983N
AJB-LC21ECR	LC21EC		C	
AJB-LC21EMR	LC21EM		M	
AJB-LC21EYR	LC21EY		Y	
AJB-LC22EBKR	LC22EBK	EUR	BK	Brother MFC-J5920DW
AJB-LC22ECR	LC22EC		C	
AJB-LC22EMR	LC22EM		M	
AJB-LC22EYR	LC22EY		Y	
AJB-LC22UBKR	LC22UBK	EUR	BK	Brother MFC-J985DW/DCP-J785DW
AJB-LC22UCR	LC22UC		C	
AJB-LC22UMR	LC22UM		M	
AJB-LC22UYR	LC22UY		Y	
AJB-LC23EBKR	LC23EBK	AU	BK	Brother MFC-J5920DW
AJB-LC23ECR	LC23EC		C	
AJB-LC23EMR	LC23EM		M	
AJB-LC23EYR	LC23EY		Y	

For Brother III Series Cartridge					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC3029BK	LC3029BK	USA	BK	Brother MFC-J5830DW	
AJB-LC3029C	LC3029C		C	Brother MFC-J5830DW XL Brother MFC-J6535DW	
AJB-LC3029M	LC3029M		M	Brother MFC-J6535DW XL Brother MFC-J5930DW	
AJB-LC3029Y	LC3029Y		Y	Brother MFC-J6935DW	
AJB-LC3017BK	LC3017BK		BK	Brother MFC-J5330DW Brother MFC-J6530DW	
AJB-LC3017C	LC3017C		C		
AJB-LC3017M	LC3017M		M		
AJB-LC3017Y	LC3017Y		Y		

AJB-LC3019BK	LC3019BK		BK	Brother MFC-J6930DW
AJB-LC3019C	LC3019C		C	Brother MFC-J6730DW
AJB-LC3019M	LC3019M		M	
AJB-LC3019Y	LC3019Y		Y	
AJB-LC3217BK	LC3217BK	EUR	BK	
AJB-LC3217C	LC3217C		C	Brother MFC-J5330DW
AJB-LC3217M	LC3217M		M	Brother MFC-J5335DW
AJB-LC3217Y	LC3217Y		Y	Brother MFC-J5730DW
AJB-LC3219BK	LC3219BK		BK	Brother MFC-J5930DW
AJB-LC3219C	LC3219C		C	Brother MFC-J6530DW
AJB-LC3219M	LC3219M		M	Brother MFC-J6930DW
AJB-LC3219Y	LC3219Y		Y	Brother MFC-J6935DW
AJB-LC3317BK	LC3317BK	AUS	BK	
AJB-LC3317C	LC3317C		C	Brother MFC-J5330DW
AJB-LC3317M	LC3317M		M	Brother MFC-J5335DW
AJB-LC3317Y	LC3317Y		Y	Brother MFC-J5730DW
AJB-LC3319BK	LC3319BK		BK	Brother MFC-J5930DW
AJB-LC3319C	LC3319C		C	Brother MFC-J6530DW
AJB-LC3319M	LC3319M		M	Brother MFC-J6930DW
AJB-LC3319Y	LC3319Y		Y	Brother MFC-J6935DW
AJB-LC3329BK	LC3329BK		BK	
AJB-LC3329C	LC3329C		C	Brother MFC-J5930DW
AJB-LC3329M	LC3329M		M	Brother MFC-J6935DW
AJB-LC3329Y	LC3329Y		Y	
AJB-LC3129BK	LC3129BK	JPN	BK	
AJB-LC3129C	LC3129C		C	Brother MFC-J6995CDW
AJB-LC3129M	LC3129M		M	
AJB-LC3129Y	LC3129Y		Y	
AJB-LC3117BK	LC3117BK		BK	
AJB-LC3117C	LC3117C		C	
AJB-LC3117M	LC3117M		M	Brother MFC-J6980CDW
AJB-LC3117Y	LC3117Y		Y	Brother MFC-J6580CDW
AJB-LC3119BK	LC3119BK		BK	Brother MFC-J6583CDW
AJB-LC3119C	LC3119C		C	Brother MFC-J6983CDW
AJB-LC3119M	LC3119M		M	Brother MFC-J5630CDW
AJB-LC3119Y	LC3119Y		Y	
AJB-LC3617BK	LC3617BK	AP	BK	
AJB-LC3617C	LC3617C		C	
AJB-LC3617M	LC3617M		M	Brother MFC-J2330DW
AJB-LC3617Y	LC3617Y		Y	Brother MFC-J2730DW
AJB-LC3619BK	LC3619BK		BK	Brother MFC-J3530DW
AJB-LC3619C	LC3619C		C	Brother MFC-J3930DW
AJB-LC3619M	LC3619M		M	
AJB-LC3619Y	LC3619Y		Y	
AJB-LC3717BK	LC3717BK	ME	BK	
AJB-LC3717C	LC3717C		C	
AJB-LC3717M	LC3717M		M	
AJB-LC3717Y	LC3717Y		Y	Brother MFC-J2330DW
AJB-LC3719BK	LC3719BK		BK	Brother MFC-J3930DW
AJB-LC3719C	LC3719C		C	
AJB-LC3719M	LC3719M		M	
AJB-LC3719Y	LC3719Y		Y	



AJB-LC3111BK	LC3111BK	JPN	BK	Brother DCP-J972N/DCP-J973N-W/B
AJB-LC3111C	LC3111C		C	Brother DCP-J978N/DCP-J572N Brother DCP-J577N/MFC-J893N
AJB-LC3111M	LC3111M		M	Brother MFC-J898N/MFC-J998DN/DWN Brother MFC-J738DN/DCP-J982N-B/W
AJB-LC3111Y	LC3111Y		Y	Brother DCP-J582N/MFC-J903N
AJB-LC3213BK	LC3213BK	EUR	BK	Brother MFC-J890DW/J895DW Brother DCP-J772DW/J774DW Brother DCP-J572DW Brother MFC-J491DW/J497DW
AJB-LC3213C	LC3213C		C	
AJB-LC3213M	LC3213M		M	
AJB-LC3213Y	LC3213Y		Y	
AJB-LC3211BK	LC3211BK		BK	
AJB-LC3211C	LC3211C		C	
AJB-LC3211M	LC3211M		M	
AJB-LC3211Y	LC3211Y		Y	
AJB-LC3011BK	LC3011BK	USA	BK	Brother MFC-J491DW Brother MFC-J497DW Brother MFC-J690DW Brother MFC-J895DW
AJB-LC3011C	LC3011C		C	
AJB-LC3011M	LC3011M		M	
AJB-LC3011Y	LC3011Y		Y	
AJB-LC3013BK	LC3013BK		BK	
AJB-LC3013C	LC3013C		C	
AJB-LC3013M	LC3013M		M	
AJB-LC3013Y	LC3013Y		Y	
AJB-LC3311BK	LC3311BK	AUS	BK	Brother DCP-J772DW Brother MFC-J491DW Brother MFC-J890DW
AJB-LC3311C	LC3311C		C	
AJB-LC3311M	LC3311M		M	
AJB-LC3311Y	LC3311Y		Y	
AJB-LC3313BK	LC3313BK		BK	
AJB-LC3313C	LC3313C		C	
AJB-LC3313M	LC3313M		M	
AJB-LC3313Y	LC3313Y		Y	
AJB-LC3511BK	LC3511BK	AP	BK	Brother MFC-J690DW Brother MFC-J890DW Brother DCP-J572DW Brother MFC-J491DW
AJB-LC3511C	LC3511C		C	
AJB-LC3511M	LC3511M		M	
AJB-LC3511Y	LC3511Y		Y	
AJB-LC3513BK	LC3513BK		BK	
AJB-LC3513C	LC3513C		C	
AJB-LC3513M	LC3513M		M	
AJB-LC3513Y	LC3513Y		Y	

For Brother IV Series Cartridge

Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC3033BK	LC3033BK	USA	BK	Brother MFC-J995DW Brother MFC-J815DW Brother MFC-J805DW/XLDW	
AJB-LC3033C	LC3033C		C		
AJB-LC3033M	LC3033M		M		
AJB-LC3033Y	LC3033Y		Y		
AJB-LC3035BK	LC3035BK		BK		
AJB-LC3035C	LC3035C		C		
AJB-LC3035M	LC3035M		M		
AJB-LC3035Y	LC3035Y		Y		
AJB-LC3037BK	LC3037BK		BK	Brother MFC-J5845DW Brother MFC-J5945DW Brother MFC-J6545DW Brother MFC-J6945DW	
AJB-LC3037C	LC3037C		C		
AJB-LC3037M	LC3037M		M		
AJB-LC3037Y	LC3037Y		Y		
AJB-LC3039BK	LC3039BK		BK		
AJB-LC3039C	LC3039C		C		
AJB-LC3039M	LC3039M		M		
AJB-LC3039Y	LC3039Y		Y		

AJB-LC3133BK	LC3133BK	JPN	BK	Brother MFC-J1500N Brother DCP-J988N Brother MFC-J1605DN	
AJB-LC3133C	LC3133C		C		
AJB-LC3133M	LC3133M		M		
AJB-LC3133Y	LC3133Y		Y		
AJB-LC3135BK	LC3135BK		BK		
AJB-LC3135C	LC3135C		C		
AJB-LC3135M	LC3135M		M		
AJB-LC3135Y	LC3135Y		Y		
AJB-LC3139BK	LC3139BK		BK	Brother MFC-J6999CDW Brother MFC-J6997CDW Brother HL-J6000CDW	
AJB-LC3139C	LC3139C		C		
AJB-LC3139M	LC3139M		M		
AJB-LC3139Y	LC3139Y		Y		
AJB-LC3233BK	LC3233BK	BK	Brother DCP-J1100DW Brother MFC-J1300		
AJB-LC3233C	LC3233C	C			
AJB-LC3233M	LC3233M	M			
AJB-LC3233Y	LC3233Y	Y			
AJB-LC3235BK	LC3235BK	BK			
AJB-LC3235C	LC3235C	C			
AJB-LC3235M	LC3235M	M			
AJB-LC3235Y	LC3235Y	Y			
AJB-LC3237BK	LC3237BK	BK		Brother HL-J6000DW Brother HL-J6100DW Brother MFC-J5945DW Brother MFC-J6945DW Brother MFC-J6947DW	
AJB-LC3237C	LC3237C	C			
AJB-LC3237M	LC3237M	M			
AJB-LC3237Y	LC3237Y	Y			
AJB-LC3239BK	LC3239BK	BK			
AJB-LC3239C	LC3239C	C			
AJB-LC3239M	LC3239M	M			
AJB-LC3239Y	LC3239Y	Y			
AJB-LC3333BK	LC3333BK	BK	Brother DCP-J1100DW Brother MFC-J1300		
AJB-LC3333C	LC3333C	C			
AJB-LC3333M	LC3333M	M			
AJB-LC3333Y	LC3333Y	Y			
AJB-LC3337BK	LC3337BK	BK		Brother MFC-J6945DW Brother MFC-J5945DW Brother MFC-J5845DW Brother MFC-J6545DW	
AJB-LC3337C	LC3337C	C			
AJB-LC3337M	LC3337M	M			
AJB-LC3337Y	LC3337Y	Y			
AJB-LC3339BK	LC3339BK	BK			
AJB-LC3339C	LC3339C	C			
AJB-LC3339M	LC3339M	M			
AJB-LC3339Y	LC3339Y	Y			
For Brother V Series Cartridge					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJB-LC401BK	LC401BK	USA	BK	Brother MFC-J1010DW/J1012DW/J1170DW	
AJB-LC401C	LC401C		C		
AJB-LC401M	LC401M		M		
AJB-LC401Y	LC401Y		Y		
AJB-LC401XLBK	LC401XLBK		BK		
AJB-LC401XLC	LC401XLC		C		
AJB-LC401XLM	LC401XLM		M	Brother MFC-J5340DW/J6540DW/J6740DW/J6940DW	
AJB-LC401XLY	LC401XLY		Y		
AJB-LC402BK	LC402BK		BK		
AJB-LC402C	LC402C		C		
AJB-LC402M	LC402M		M		
AJB-LC402Y	LC402Y		Y		
AJB-LC402XLBK	LC402XLBK	BK			
AJB-LC402XLC	LC402XLC	C			
AJB-LC402XLM	LC402XLM	M			

AJB-LC402XLY	LC402XLY
AJB-LC404BK	LC404BK
AJB-LC404C	LC404C
AJB-LC404M	LC404M
AJB-LC404Y	LC404Y
AJB-LC406BK	LC406BK
AJB-LC406C	LC406C
AJB-LC406M	LC406M
AJB-LC406Y	LC406Y
AJB-LC406XLBK	LC406XLBK
AJB-LC406XLC	LC406XLC
AJB-LC406XLM	LC406XLM
AJB-LC406XLY	LC406XLY
AJB-LC411BK	LC411BK
AJB-LC411C	LC411C
AJB-LC411M	LC411M
AJB-LC411Y	LC411Y
AJB-LC412BK	LC412BK
AJB-LC412C	LC412C
AJB-LC412M	LC412M
AJB-LC412Y	LC412Y
AJB-LC412XLBK	LC412XLBK
AJB-LC412XLC	LC412XLC
AJB-LC412XLM	LC412XLM
AJB-LC412XLY	LC412XLY
AJB-LC414BK	LC414BK
AJB-LC414C	LC414C
AJB-LC414M	LC414M
AJB-LC414Y	LC414Y
AJB-LC416BK	LC416BK
AJB-LC416C	LC416C
AJB-LC416M	LC416M
AJB-LC416Y	LC416Y
AJB-LC416XLBK	LC416XLBK
AJB-LC416XLC	LC416XLC
AJB-LC416XLM	LC416XLM
AJB-LC416XLY	LC416XLY
AJB-LC417XLBK	LC417XLBK
AJB-LC417XLC	LC417XLC
AJB-LC417XLM	LC417XLM
AJB-LC417XLY	LC417XLY
AJB-LC421BK	LC421BK
AJB-LC421C	LC421C
AJB-LC421M	LC421M
AJB-LC421Y	LC421Y
AJB-LC421XLBK	LC421XLBK
AJB-LC421XLC	LC421XLC
AJB-LC421XLM	LC421XLM
AJB-LC421XLY	LC421XLY
AJB-LC422BK	LC422BK
AJB-LC422C	LC422C
AJB-LC422M	LC422M
AJB-LC422Y	LC422Y
AJB-LC422XLBK	LC422XLBK
AJB-LC422XLC	LC422XLC
AJB-LC422XLM	LC422XLM
AJB-LC422XLY	LC422XLY

JPN

Y	
BK	
C	Brother MFC-J1205W/J1215W
M	
Y	
BK	
C	
M	
Y	Brother MFC-J4335DW/J4345DW/J4535DW/J5855DW/J5955DW/J6555DW/J6955DW
BK	
C	
M	
Y	
BK	
C	Brother DCP-J526N/J914N/J926N/J926N-W/J1800N/J1800DW/J528N/J928N-W/B
M	Brother MFC-J739DN/J739DWN/J904N/J939DN/J939DWN/J905N
Y	
BK	
C	
M	
Y	Brother MFC-J7100CDW/J7300CDW
BK	
C	
M	
Y	
BK	
C	
M	
Y	
BK	
C	
M	
Y	Brother DCP-J4140N/J4143N
BK	Brother MFC-J4440N/J4540N/J4940DN/J4443N/J4543N
C	
M	
Y	
BK	
C	Brother MFC-J5800CDW/J7500CDW/J7600CDW
M	Brother HL-J7010CDW
Y	
BK	
C	
M	
Y	Brother DCP-J1050DW/J1140DW
BK	Brother MFC-J1010DW
C	
M	
Y	
BK	
C	
M	
Y	Brother MFC-J5340DW/J5345DW/J5740DW/J6540DW/J6940DW
BK	
C	
M	
Y	



AJB-LC424BK	LC424BK
AJB-LC424C	LC424C
AJB-LC424M	LC424M
AJB-LC424Y	LC424Y
AJB-LC426BK	LC426BK
AJB-LC426C	LC426C
AJB-LC426M	LC426M
AJB-LC426Y	LC426Y
AJB-LC426XLBK	LC426XLBK
AJB-LC426XLC	LC426XLC
AJB-LC426XLM	LC426XLM
AJB-LC426XLY	LC426XLY
AJB-LC427BK	LC427BK
AJB-LC427C	LC427C
AJB-LC427M	LC427M
AJB-LC427Y	LC427Y
AJB-LC427XLBK	LC427XLBK
AJB-LC427XLC	LC427XLC
AJB-LC427XLM	LC427XLM
AJB-LC427XLY	LC427XLY
AJB-LC462BK	LC462BK
AJB-LC462C	LC462C
AJB-LC462M	LC462M
AJB-LC462Y	LC462Y
AJB-LC462XLBK	LC462XLBK
AJB-LC462XLC	LC462XLC
AJB-LC462XLM	LC462XLM
AJB-LC462XLY	LC462XLY
AJB-LC451BK	LC451BK
AJB-LC451C	LC451C
AJB-LC451M	LC451M
AJB-LC451Y	LC451Y
AJB-LC451XLBK	LC451XLBK
AJB-LC451XLC	LC451XLC
AJB-LC451XLM	LC451XLM
AJB-LC451XLY	LC451XLY
AJB-LC456BK	LC456BK
AJB-LC456C	LC456C
AJB-LC456M	LC456M
AJB-LC456Y	LC456Y
AJB-LC456XLBK	LC456XLBK
AJB-LC456XLC	LC456XLC
AJB-LC456XLM	LC456XLM
AJB-LC456XLY	LC456XLY
AJB-LC462BK	LC462BK
AJB-LC462C	LC462C
AJB-LC462M	LC462M
AJB-LC462Y	LC462Y
AJB-LC462XLBK	LC462XLBK
AJB-LC462XLC	LC462XLC
AJB-LC462XLM	LC462XLM
AJB-LC462XLY	LC462XLY
AJB-LC472BK	LC472BK
AJB-LC472C	LC472C
AJB-LC472M	LC472M
AJB-LC472Y	LC472Y
AJB-LC472XLBK	LC472XLBK

EUR	BK	Brother DCP-J1200W/J1200WE
	C	
	M	
	Y	
	BK	Brother MFC-J4335DW/J4340DW/J4535DW/J4540DW
	C	
	M	
	Y	
	BK	
	C	
	M	
	Y	Brother MFC-J5955DW/J6955DW/J6957DW/J6959DW Brother HL-J6010DW
	BK	
	C	
	M	
AP	Y	Brother MFC-J2340DW/J3540DW/J3940DW
	BK	
	C	
	M	
	Y	
	BK	
	C	Brother DCP-J1050DW/J1140DW/J1700DW Brother MFC-J1010DW
	M	
	Y	
	BK	
	C	
	M	
ME	Y	Brother MFC-J4340DW/J4540DW
	BK	
	C	
	M	
	Y	
	BK	
	C	Brother MFC-J2340DW/J2740DW/J3540DW/J3940DW
	M	
	Y	
	BK	
	C	
	M	
	Y	Brother MFC-J2340DW/J3540DW/J3940DW
	BK	
	C	
	M	

AJB-LC472XLC	LC472XLC	AUS	C	Brother DCP-J1050DW/J1140DW Brother MFC-J1010DW	
AJB-LC472XLM	LC472XLM		M		
AJB-LC472XLY	LC472XLY		Y		
AJB-LC431BK	LC431BK		BK		
AJB-LC431C	LC431C		C		
AJB-LC431M	LC431M		M		
AJB-LC431Y	LC431Y		Y		
AJB-LC431XLBK	LC431XLBK		BK		
AJB-LC431XLC	LC431XLC		C		
AJB-LC431XLM	LC431XLM		M		
AJB-LC431XLY	LC431XLY		Y		
AJB-LC432BK	LC432BK		BK	Brother MFC-J5340DW/5740DW/6540DW/6740DW/6940DW	
AJB-LC432C	LC432C		C		
AJB-LC432M	LC432M		M		
AJB-LC432Y	LC432Y		Y		
AJB-LC432XLBK	LC432XLBK		BK		
AJB-LC432XLC	LC432XLC		C		
AJB-LC432XLM	LC432XLM		M	Brother DCP-J1200W	
AJB-LC432XLY	LC432XLY		Y		
AJB-LC434BK	LC434BK		BK		
AJB-LC434C	LC434C		C	Brother MFC-J4340DW/J4440DW/J4540DW/ J5855DW/J5955DW/J6555DW/J6955DW/J6957DW	
AJB-LC434M	LC434M		M		
AJB-LC434Y	LC434Y		Y		
AJB-LC436BK	LC436BK		BK		
AJB-LC436C	LC436C		C		
AJB-LC436M	LC436M		M		
AJB-LC436Y	LC436Y		Y		
AJB-LC436XLBK	LC436XLBK		BK		
AJB-LC436XLC	LC436XLC		C		
AJB-LC436XLM	LC436XLM		M		
AJB-LC436XLY	LC436XLY		Y		
for Mimaki Series Inkjet Cartridge					
Product Code	OEM Product Code	Region	Color	For Use in Printers	Chip Photo
AJMI-LUS120K	LUS120K		BK	MIMAKI UJF-6042MkII UJF-3042MkII UJF-3042MkII EX	
AJMI-LUS120C	LUS120C		C		
AJMI-LUS120M	LUS120M		M		
AJMI-LUS120Y	LUS120Y		Y		
AJMI-LUS120LC	LUS120LC		LC		
AJMI-LUS120LM	LUS120LM		LM		
AJMI-LUS120W	LUS120W		W	MIMAKI UJV500-160/JFX200-2531	
AJMI-LUS120CL	LUS120CL		CL		
AJMI-LUS150K	LUS150K		BK		
AJMI-LUS150C	LUS150C		C		
AJMI-LUS150M	LUS150M		M		
AJMI-LUS150Y	LUS150Y		Y		
AJMI-LUS150LC	LUS150LC		LC	MIMAKI UCJV300 Series/UCJV150-160	
AJMI-LUS150LM	LUS150LM		LM		
AJMI-LUS150W	LUS150W		W		
AJMI-LUS170K	LUS170K		BK		
AJMI-LUS170C	LUS170C		C		
AJMI-LUS170M	LUS170M		M		
AJMI-LUS170Y	LUS170Y		Y		
AJMI-LUS170LC	LUS170LC		LC		
AJMI-LUS170LM	LUS170LM		LM		
AJMI-LUS170W	LUS170W		W		
AJMI-LUS170CL	LUS170CL		CL		

AJMI-LUS175K	LUS175K
AJMI-LUS175C	LUS175C
AJMI-LUS175M	LUS175M
AJMI-LUS175Y	LUS175Y
AJMI-LUS175LC	LUS175LC
AJMI-LUS175LM	LUS175LM
AJMI-LUS175W	LUS175W
AJMI-LUS175CL	LUS175CL
AJMI-LUS200K	LUS200K
AJMI-LUS200C	LUS200C
AJMI-LUS200M	LUS200M
AJMI-LUS200Y	LUS200Y
AJMI-LUS200W	LUS200W
AJMI-SB54K	SB54K
AJMI-SB54C	SB54C
AJMI-SB54M	SB54M
AJMI-SB54Y	SB54Y
AJMI-BS4K	BS4K
AJMI-BS4C	BS4C
AJMI-BS4M	BS4M
AJMI-BS4Y	BS4Y
AJMI-BS4KXL	BS4KXL
AJMI-BS4CXL	BS4CXL
AJMI-BS4MXL	BS4MXL
AJMI-BS4YXL	BS4YXL
AJMI-CS100K	CS100K
AJMI-CS100C	CS100C
AJMI-CS100M	CS100M
AJMI-CS100Y	CS100Y
AJMI-SB300K	SB300K
AJMI-SB300C	SB300C
AJMI-SB300M	SB300M
AJMI-SB300Y	SB300Y
AJMI-SB300LC	SB300LC
AJMI-SB300LM	SB300LM
AJMI-SB310K	SB310K
AJMI-SB310C	SB310C
AJMI-SB310M	SB310M
AJMI-SB310Y	SB310Y
AJMI-SB320K	SB320K
AJMI-SB320C	SB320C
AJMI-SB320M	SB320M
AJMI-SB320Y	SB320Y
AJMI-SB410K	SB410K
AJMI-SB410C	SB410C
AJMI-SB410M	SB410M
AJMI-SB410Y	SB410Y
AJMI-SB411K	SB411K
AJMI-SB411C	SB411C
AJMI-SB411M	SB411M
AJMI-SB411Y	SB411Y
AJMI-SB420K	SB420K
AJMI-SB420C	SB420C
AJMI-SB420M	SB420M
AJMI-SB420Y	SB420Y
AJMI-SB420LC	SB420LC
AJMI-SB420LM	SB420LM

WW

BK	MIMAKI UCJV300 Series/UCJV150-160
C	
M	
Y	
LC	
LM	
W	MIMAKI UCJV300 Series/JFX200/500
CL	
BK	
C	
M	MIMAKI CJV300/CJV150
Y	
W	
BK	JV300 Series JV150 Series
C	
M	
Y	
BK	
C	
M	SWJ-320 Series
Y	
W	
BK	Tx500-1800
C	
M	
Y	
LC	TS500P-3200
LM	
BK	
C	
M	Tx500P-3200DS
Y	
W	
BK	TS300P-1800
C	
M	
Y	TS300P-1800
BK	
C	
M	
Y	Tx300P-1800B Tx300P-1800
BK	
C	
M	
Y	
LC	
LM	



AJMI-SB610K	SB610K		BK	TS55-1800	
AJMI-SB610C	SB610C		C		
AJMI-SB610M	SB610M		M		
AJMI-SB610Y	SB610Y		Y		
AJMI-SB610LM	SB610LC		LC		
AJMI-SS21LK	SS21LM		LM	CJV300 Series	
AJMI-SS21OR	SS21OR		OR	CJV150 Series	
AJMI-LUS210K	LUS210K		BK	UJV100-160	
AJMI-LUS210C	LUS210C		C		
AJMI-LUS210M	LUS210M		M		
AJMI-LUS210Y	LUS210Y		Y		
AJMI-LUS210W	LUS210W		W		
AJMI-ES3W	ES3W		W	CJV300 Series	
AJMI-LX101K	LX101K		BK	JV400-130/160LX	
AJMI-LX101C	LX101C		C		
AJMI-LX101M	LX101M		M		
AJMI-LX101Y	LX101Y		Y		
AJMI-LX101W	LX101W		W		
AJMI-LX101OR	LX101OR		OR	JV400SUV Series	
AJMI-LX101GR	LX101GR		GR		
AJMI-SU100K	SU100K		BK	JV400SUV Series	
AJMI-SU100C	SU100C		C		
AJMI-SU100Y	SU100Y		Y		
AJMI-SB53K	SB53K	WW	BK	Mimaki JV33/CJV30/TS34	
AJMI-SB53BL	SB53BL		BL		
AJMI-SB53M	SB53M		M		
AJMI-SB53Y	SB53Y		Y		
AJMI-SB53LB	SB53LB		LB		
AJMI-SB53LM	SB53LM		LM		

Note:

1. The red words mean the new models updated by this version.

2. Copyright ©2004-2024 Geehy Microelectronic Inc.

The information contained herein is subject to change without prior notification. We shall not be liable for technical or editorial errors or omissions contained herein. Photographed products may not always match the description. And other brand or product names mentioned are intended to show compatibility only.