

Fresh &

## LIQUID SILICONE LID WITH DETACHABLE SNAPS

Experience Unbounded Storage:Glass storage container features a flexible liquid silicone lid, expanding your storage possibilities beyond traditional limits!

## **DISASSEMBLY DIAGRAM**

#### Glass container with silicone film lid > > >

1050ml/35.5oz/4.4cup Size:20.7x15.7x74.8cm



#### **DETACHABLE SNAPS**

Easy to open and close with an ergonomic lid design

#### SILICONE FILM

Featuring a detachable silicone surface this product is easy to clean and replace

#### HIGH BOROSILICATE GLASS

Safely handle oven temperature up to 560°C/1040°F

# CONDITIONS OF USE OF THE PRODUCT

BPA FREE

MICROWAVE Microwave safe with lid open

DISHWASHER Dishwasher Safe Without Contact With Sharpness

**REFRIGERATOR** The temperature can't go below minus 10 degrees binds us to each toge on't be afraid to ener taking chances that forwe

the second se

## **PAIN POINT**

#### Too much food to cover




## **PROBLEM SOLVING**

• Use the elasticity of liquid silicone to increase the freedom of storage. • The high elastic silicone film lid increases the capacity by about 1/3.



## **FEATURES** Glass Container with Liquid Silicone Lid







### **STEP ONE**

Unlock the snaps and remove the lid.

### **STEP TWO** Place food inside the container.

## STEP THREE A Note: Please avoid direct contact between sharp edges and the liquid silicone lid.

Place the lid on and secure the snaps.

## **STEP FOUR**

Store the container in the refrigerator to keep food fresher and longer.

# **LIQUID S' LO CONE LID** WITH DETAC STATES AND APS



1050ml/35.5oz/4.4cup Size:20.7x15.7x74.8cm





