



ANM-B2

Insulating Body: Plastic
Applicable: For ANM, ANMH




ANM-C2

Insulating Body: Plastic
Applicable: For ANM, ANMH
• Two spare fuses ready for use attached on both side of outer shell



ANM-C2Y

Insulating Body: Plastic
Applicable: For ANM, ANMH
• Two spare fuses ready for use attached on both side of outer shell




ANM-C4

Insulating Body: Plastic




BANL-B

Insulating Body: Plastic
Applicable: For ANL




BANL-C

Insulating Body: Plastic
Applicable: For ANL
• One spare fuse ready for use attached on outer shell




BANL-F

Insulating Body: Plastic
Applicable: For ANL




BANL-E

Insulating Body: Bakelite
Applicable: For ANL



BANL-B6

Insulating Body: Bakelite
Applicable: For ANL



BANL-C6

