



www.xtema.de

THOMAS LEBHERZ TEXTILMASCHINEN e.K.

GERMANY

**spare parts
for the
textile industry**

flexible rapier looms (Optimax and Gammax)




spare parts

are manufactured in Europe by our selected and certified workshops, ensuring the best possible quality at eye level with the OEM (Original Equipment Manufacturer), but with a great price advantage – your value addition.

We are in a process of continuous development including the scheduled expansion of the existing product-range as well as the short-term implementation of new program lines.

Xtema spare parts enjoy an excellent reputation. The sustainability of our products will benefit your production, your efficiency and your performance.



INDEX

Optimax FF Free Flight	4-5
Optimax GC Guided	6-7
Optimax FF Free Flight & GC Guided	8-9
Optimax & Gammax	10-13
Gammax FF Free Flight	14-15
Gammax GC Guided	16-17
Gammax FF Free Flight & GC Guided	18-19

OPTIMAX FF FREE FLIGHT

Pos	Xtema Code	Description
01	P-01.95.20	Gripper Head cpl. Optimax FF
02	P-01.95.21	Plate Optimax FF
03	P-01.95.22	Housing Optimax FF
04	P-01.95.24	Sole LHS Optimax FF
05	P-01.95.25	Clamp Lover Optimax FF
06	P-01.95.28	Clamp Optimax FF
07	P-01.95.30	Gripper Back
08	P-01.95.50	Gripper Head cpl. RHS Optimax FF
09	P-01.95.51	Spoon RHS Optimax FF
10	P-01.95.52	Hook RHS Optimax FF
11	P-01.95.53	Housing RHS Optimax FF
12	P-01.95.54	Sole Optimax FF RHS
13	P-01.95.55	Wearing Plate RHS Optimax FF
14	P-01.95.56	Pressure Spring RHS Optimax FF
15	P-01.95.57	Gripper Back RHS Optimax FF
16	P-01.95.61	Gripper Cpl. RHS Optimax FF
17	P-01.95.77	Rapier Tape LHS 220-230 Optimax FF
18	P-01.95.78	Rapier Tape RHS 220-230 Optimax FF
19	P-01.95.79	Rapier Tape RHS 220-230 Optimax FF
20	P-01.95.93	Guide Bar Fiber
21	P-01.95.94	Rail 2012 Optimax FF
22	P-01.95.95	Plate 2012
23	P-01.95.96	Plate 2013
24	P-01.95.97	Plate
25	P-01.95.99	Fixation Knob M6 x 25mm Optimax FF
26	P-01.96.53	Opener Optimax FF
27	P-01.96.70	Suction Nozzle LHS Optimax FF
28	P-01.96.71	Supporting Plate Optimax FF
29	P-01.96.93	Driving Wheel 372x50x4 mm Z:107 Plastic Optimax FF
30	P-01.96.94	Driving Wheel 372x50x4 mm Z:107 Optimax FF
31	P-01.97.21	Gripper Head LHS 2009 Optimax FF
32	P-01.99.05	Bolt M3
33	P-01.99.75	Slide LHS L: 755 Optimax FF
34	P-01.99.76	Slide RHS L: 755 Optimax FF



Pos 1



Pos 1



Pos 4



Pos 8



Pos 12

OPTIMAX GC GUIDED

Pos	Xtema Code	Description
01	P-02.95.01	Rapier Head Optimax 2 LHS
02	P-02.95.02	Rapier Body LHS Optimax GC
03	P-02.95.03	Rapier Connection Plate Aluminium Optimax GC
04	P-02.95.04	Composite piece carbon LHS Optimax GC
05	P-02.95.05	Movable Gripper Clamp Optimax GC
06	P-02.95.07	Gripper Head LHS Optimax GC adjust grooved
07	P-02.95.08	Movable Gripper Clamp Optimax GC 4 grooved
08	P-02.95.09	Movable Gripper Clamp Optimax GC
09	P-02.95.12	Screw 2.5 X 6 mm
10	P-02.95.13	Screw 2.5 X 8 mm
11	P-02.95.14	Set Screw 3 X 4 mm
12	P-02.95.15	Screw 2.5 X 4 mm
13	P-02.95.16	Rapier Head Optimax 2 GC LHS double weft
14	P-02.95.17	Gripper head Optimax GC LHS Adjust Grooved 4
15	P-02.95.31	Gripper Optimax GC 5V LHS
16	P-02.95.32	Gripper Head Optimax LHS GC 5V
17	P-02.95.33	Gripper Sam. Optimax LHS GC 5V
18	P-02.95.38	Suction Nozzle 5V Optimax
19	P-02.95.39	Opener Optimax LHS GC 5V Fiber
20	P-02.95.40	Rapier connection plate Aluminium Optimax GC
21	P-02.95.41	Screw 2,5 x 12 mm Optimax GC
22	P-02.95.42	Hexagon Nut End 4
23	P-02.95.43	Gripper LHS Optimax GC
24	P-02.95.67	Rapier Tape RHS 3000 - 3800 Optimax GC
25	P-02.95.68	Rapier Tape LHS 3000 - 3800 Optimax GC
26	P-02.95.75	Rapier Tape RHS 190-220-230 Optimax GC
27	P-02.95.76	Rapier Tape LHS 190-220-230 Optimax GC
28	P-02.96.01	Rapier Head Optimax 2 RHS
29	P-02.96.02	Rapier Heady Body RHS Optimax GC
30	P-02.96.03	Rapier Lever Weft Holder RHS Optimax GC
31	P-02.96.04	Composite piece carbon RHS Optimax GC
32	P-02.96.05	Rapier connection plate RHS Aluminium
33	P-02.96.11	Driving Wheel 370 x 50 x 2 mm Z:121 Optimax GC
34	P-02.96.12	Bushing Optimax GC
35	P-02.96.13	Cutter Blade Optimax GC
36	P-02.96.14	Pressure Spring Optimax GC
37	P-02.96.15	Spring Holder Optimax GC
38	P-02.96.19	Cutter Blade long Optimax GC
39	P-02.96.20	Cutter Blade long Optimax GC
40	P-02.96.23	Guide Piece Optimax GC
41	P-02.96.31	Hook/Guide Optimax GC
42	P-02.98.45	Plate Optimax GC
43	P-02.98.97	Slide LHS L:755 Optimax GC
44	P-02.98.98	Slide RHS L:755 Optimax GC

Pos 4

Pos 6

Pos 6

Pos 16

Pos 31

Pos 18

Pos 35

Pos 38

Pos 28

Pos 39

Pos 40

Pos 31



OPTIMAX FF FREE FLIGHTt & GC GUIDED

Pos	Xtema Code	Description
01	P-03.95.06	Rail LHS carbon
02	P-03.95.10	Teflon plate LHS long
03	P-03.95.48	Rail Optimax
04	P-03.95.88	Reed Holder D: 19 Optimax
05	P-03.96.06	Rail RHS carbon Optimax
06	P-03.96.07	Spring RHS Optimax GC
07	P-03.96.08	Pin Optimax GC
08	P-03.96.10	Teflon Plate RHS short
09	P-03.97.34	Warp Sensor Optimax
10	P-03.99.41	Hook/Guide Optimax FF
11	P-03.99.71	Reed Holder D: 18 Optimax
12	P-03.99.72	Reed Holder G.M. Gammax

Pos 8



Pos 10




Pos 5



Pos 1

Pos 2



OPTIMAX & GAMMAX

Pos	Xtema Code	Description
01	P-04.96.16	Guide Plate
02	P-04.96.17	Heddle 151*3,2*0,3mm
03	P-04.96.18	Selvedge Motion
04	P-04.96.25	Frame Wood 160x80mm
05	P-04.96.26	Frame Wood 160x60mm
06	P-04.96.27	Rod Ceramic
07	P-04.96.34	Rod Guide
08	P-04.96.35	Harness Guide
09	P-04.96.38	Guide plate long (for rapier rod)
10	P-04.96.40	Spring
11	P-04.96.41	Guide
12	P-04.96.44	Filter
13	P-04.96.63	Guide Pi
14	P-04.96.92	Blowing Nozzle
15	P-04.97.33	Waste Pulley Porcelain
16	P-04.97.52	Crank Arm
17	P-04.97.53	Guide Piece
18	P-04.97.54	Plate Elsy
19	P-04.97.60	Crank
20	P-04.97.97	Clamp Piece
21	P-04.97.98	Brake Disc Aluminium
22	P-04.97.99	Brake
23	P-04.98.00	Filter
24	P-04.98.01	Filter Cover
25	P-04.98.02	Filter Housing
26	P-04.98.03	Filter Element
27	P-04.98.04	Filter
28	P-04.98.05	Shaft
29	P-04.98.06	Washer
30	P-04.98.07	Spring Clip
31	P-04.98.08	Connecting Piece
32	P-04.98.09	Cylindrical pin 6x32
33	P-04.98.10	Filter Outer Cover
34	P-04.98.11	Spocer Ring
35	P-04.98.14	Cylindrical Pin 6x32
36	P-04.98.15	Filter Cover
37	P-04.98.16	Seal
38	P-04.98.17	Handle
39	P-04.98.18	Seal
40	P-04.98.35	Sword
41	P-04.98.70	Cutter
42	P-04.98.71	Step Motor

Pos 2




Pos 3



Pos 9



Pos 15



OPTIMAX & GAMMAX

Pos	Xtema Code	Description
01	P-04.98.71	Step Motor
02	P-04.98.72	Cutter Blade Short
03	P-04.98.73	Cutter Blade Short RHS
04	P-04.98.74	Screw 3x12
05	P-04.98.75	Cutter Blade RHS
06	P-04.98.76	Shaft Bolt
07	P-04.98.77	Bushing
08	P-04.98.78	Washer
09	P-04.98.79	Lock Nut
10	P-04.98.80	Spring Holder
11	P-04.98.81	Eccentric
12	P-04.98.82	Pin
13	P-04.98.83	Set Screw 3 X 4 mm
14	P-04.98.84	Connecting Rod
15	P-04.98.85	Ball Bearing
16	P-04.98.86	Ball Bearing (4/9)
17	P-04.98.87	Bushing D6xD4
18	P-04.98.88	Bolt M4
19	P-04.98.89	Collar Nut
20	P-04.98.90	Screw 3x10
21	P-04.98.91	Guide Plate
22	P-04.98.92	Cutter RHS
23	P-04.98.93	Spring RHS
24	P-04.98.94	Cutter Blade
25	P-04.98.95	Moving Cutter Blade
26	P-04.98.96	Guide Plate
27	P-04.99.07	Lever
28	P-04.99.08	Lever
29	P-04.96.64	Waste Pulley Gear Z:7ece
30	P-04.96.90	Lever



Pos 1

Pos 10



Pos 11



Pos 22



GAMMAX FF FREE FLIGHT

Pos	Xtema Code	Description
01	P-05.95.66	Rapier Tape LHS 220 Gammax FF
02	P-05.95.89	Gammax Back LHS VV Carbon Gammax FF
03	P-05.95.90	Gammax Back LHS VV Carbon Gammax FF
04	P-05.96.21	Cutter Blade Short Gammax FF
05	P-05.96.22	Cutter Blade Short Gammax FF
06	P-05.96.54	Opener Gammax FF
07	P-05.97.42	Gripper cpl. LHS Gammax FF
08	P-05.97.61	Gripper RHS cpl. Gammax FF
09	P-05.97.66	Gripper cpl. RHS Gammax FF
10	P-05.98.46	Slide LHS L:705 2000 Gammax FF
11	P-05.98.47	Slide RHS L:705 2000 Gammax FF
12	P-05.98.62	Sole RHS Gammax FF
13	P-05.99.28	Gripper Head LHS 2005 Gammax FF
14	P-05.99.39	Button M6x10 Gammax FF
15	P-05.99.42	Rail RHS Gammax
16	P-05.99.73	Slide LHS L: 695 2000 Gammax FF
17	P-05.99.74	Slide RHS L: 695 2000 Gammax FF
18	P-05-95-69	Rapier Tape LHS 220 Gammax FF

Pos 5



Pos 7



Pos 9



Pos 12



Pos 15



GAMMAX GC GUIDED

Pos	Xtema Code	Description
01	P-06.95.70	Rapier Tape LHS 190 (d: 144 mm) Gammax GC
02	P-06.95.71	Rapier Tape RHS 190 (d: 130 mm) Gammax GC
03	P-06.95.72	Rapier Tape RHS 190 (d: 145,8 mm) Gammax GC
04	P-06.95.73	Rapier Tape LHS 190 (d: 144 mm) Gammax GC
05	P-06.95.74	Rapier Tape RHS 220 (d: 135 mm) Gammax GC
06	P-06.98.56	Rapier Lever Weft Holder RHS Gammax GC
07	P-06.98.57	Rapier Head Body RHS Gammax GC
08	P-06.98.58	Rapier Weft Holder LHS
09	P-06.98.59	Rapier Weft Holder LHS
10	P-06.99.30	Rapier Head complete LHS Gammax GC
11	P-06.99.31	Rapier Head complete RHS Gammax GC
12	P-06.99.32	Rapier Connection Aluminium
13	P-06.99.33	Rapier Connection RHS Aluminium
14	P-06.99.35	Fixation Bar RHS Gammax GC
15	P-06.99.40	Fixation Knob M4x20
16	P-06.99.46	Supporting Plate RHS Gammax GC
17	P-06.99.90	Sole LHS Gammax GC
18	P-06.99.91	Sole RHS Gammax GC

Pos 10



Pos 11



Pos 17



Pos 18



GAMMAX FF FREE FLIGHT & GC GUIDED

Pos	Xtema Code	Description
01	P-07.95.09	Suction Nozzle
02	P-07.95.11	Teflon 6 x 150 mm Gammax
03	P-07.95.49	Grease Piece
04	P-07.96.32	Nut Gammax
05	P-07.96.33	Bolt 3X16 Gammax
06	P-07.96.46	Gammax Carbon LHS
07	P-07.97.35	Warp Sensor Gammax
08	P-07.98.52	Slide LHS L:725 2002 Gammax
09	P-07.98.53	Slide RHS L:725 2002 Gammax
10	P-07.98.54	Rail G
11	P-07.99.00	Driving Wheel 398x50x5 mm Z97 Gammax
12	P-07.99.04	Teflon 15x150mm Gammax
13	P-07.99.36	Hooks Bottom Gammax
14	P-07.99.37	Hooks Top Gammax
15	P-07.99.44	Hook/Guide Gammax new 14,5

Pos 3



Pos 4



Pos 5



Pos 6



Pos 15



online catalogue available at

www.xtema.de

Xtema - Textilmaschinen

represents a family tradition over three generations in trading and servicing the textile industry since 1956.

We are a privately owned company providing accumulated experience and know-how in marketing and world-wide sales to the entire customer satisfaction.

Textile machinery & spare parts

Xtema works for you!



Xtema - Textilmaschinen Thomas Lebherz e.K.
Textile Machinery, spare parts, trade, evaluations and technical Service

**Dammstr. 4G
91083 Baiersdorf / Germany**

**Tel. + 49 - (0)9133 - 769 88 - 64
Fax. + 49 - (0)9133 - 769 88 - 65**

**Email: spare.parts@xtema.de
Web: www.xtema.de**

